

Discover 125 BS IV



Discover 125 BS IV

Bajaj Auto Limited

Akurdi, Pune - 411 035, India.

Tel : +91 20 27472851

Fax : +91 20 27407385

Toll Free : 1800 233 2453

Website : www.bajajauto.com

CIN L65993PN2007PLC130076

Spare Parts Catalogue



Notice

All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71112615

REV. 06, JUNE 17

Copy rights : All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

Foreword

Discover 125 BS IV

We have pleasure in presenting the Spare Parts Catalogue for 'Discover 125 BS IV' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instructions

Discover 125 BS IV

1. **How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

2. **How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

3. **Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

4. **Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

Discover 125 BS IV

[illegible]

Discover 125 BS IV

[illegible]

Discover 125 BS/IV

[illegible]

Discover 125 BS IV

[illegible]

Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	SAI System	4
3	Cylinder Head	6
4	Valve	8
5	Camshaft / Tensioner	10
6	Cylinder & Piston	12
7	Crankshaft	14
8	Transmission	16
9	Change Drum & Shift Fork	18
10	Gear Change Mechanism	20
11	Engine Assembly & Crankcase RH	22
12	Crankcase LH	24
13	Cover Clutch	26
14	Cover Magneto	28
15	Clutch Assembly	30
16	Kick Starter Mechanism	32
17	Carburettor Assembly	34
18	Air Cleaner Complete	36
19	EVAP Mechanism	38
20	Silencer Assembly	40
21	Oil Pump	42
22	Starter Assembly	44
23	Magneto, CDI, Spark Plug & H.T. Coil	46
24	Seat Assembly & Seat Lock	48
25	Engine Mountings	50
26	Frame & Frame Fitting	52
27	Swing Arm & Rear Shock Absorber	54
28	Rider Foot Rest	56
29	Pillion Foot Rest & Holder	58
30	Mudguard - Front & Rear	60
31	Stand Assembly	62

Plate No.	Description	Page No.
32	Tyre / Tube / Rim	64
33	Front Hub (Disc Brake)	66
34	Front Master Cylinder	68
35	Front Disc Brake Caliper Assembly	70
36	Front Hub (Drum Brake)	72
37	Rear Hub	74 - 76
38	Rear Brake Pedal	78
39	Handle Bar	80 - 82
40	Front Fork	84
41	Petrol Tank Cap & Gauge Fuel	86
42	Fittings - Petrol Tank, Side Covers & Cover Seat	88
43	Speedometer Assembly	90
44	Control Cables	92
45	Chain Case	94
46	Head Lamp & Fairing	96 - 98
47	Indicator Light Assembly	100
48	Tail Lamp Assembly, Front & Rear Number Plate	102
49	Electrical Equipments	104
50	Accessories & Grab Handle	106
51	Tool Kit	108
52	Painted Parts and Decals	110 - 112
53	Consumable Parts	113 - 116
	Kit List	117 - 120
	Amendment Sheet (Parts Added)	121
	Amendment Sheet (Parts Deleted)	122
	Part Index	123 - 136

Pictorial Index

Discover 125 BS IV

PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 1
--------------------------------------	---------------




PLATE NO. : 2 SAI SYSTEM	PAGE NO. 3
-----------------------------	---------------




PLATE NO. : 3 CYLINDER HEAD	PAGE NO. 5
--------------------------------	---------------





PLATE NO. : 4 VALVE	PAGE NO. 7
------------------------	---------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 5 CAMSHAFT / TENSIONER	PAGE NO. 9
---------------------------------------	---------------




PLATE NO. : 6 CYLINDER & PISTON	PAGE NO. 11
------------------------------------	----------------




PLATE NO. : 7 CRANKSHAFT	PAGE NO. 13
-----------------------------	----------------





PLATE NO. : 8 TRANSMISSION	PAGE NO. 15
-------------------------------	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 9 CHANGE DRUM & SHIFT FORK	PAGE NO. 17
---	----------------



PLATE NO. : 10 GEAR CHANGE MECHANISM	PAGE NO. 19
---	----------------




PLATE NO. : 11 ENGINE ASSEMBLY & CRANKCASE RH	PAGE NO. 21
--	----------------





PLATE NO. : 12 CRANKCASE LH	PAGE NO. 23
--------------------------------	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 13 COVER CLUTCH	PAGE NO. 25
--------------------------------	----------------




PLATE NO. : 14 COVER MAGNETO	PAGE NO. 27
---------------------------------	----------------




PLATE NO. : 15 CLUTCH ASSEMBLY	PAGE NO. 29
-----------------------------------	----------------





PLATE NO. : 16 KICK STARTER MECHANISM	PAGE NO. 31
--	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 17 CARBURETOR ASSEMBLY	PAGE NO. 33
---------------------------------------	----------------




PLATE NO. : 18 AIR CLEANER COMPLETE	PAGE NO. 35
--	----------------




PLATE NO. : 19 EVAP MECHANISM	PAGE NO. 37
----------------------------------	----------------





PLATE NO. : 20 SILENCER ASSEMBLY	PAGE NO. 39
-------------------------------------	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 21 OIL PUMP	PAGE NO. 41
----------------------------	----------------




PLATE NO. : 22 STARTER ASSEMBLY	PAGE NO. 43
------------------------------------	----------------



PLATE NO. : 23 MAGNETO, CDI, SPARK PLUG & H.T. COIL	PAGE NO. 45
---	----------------





PLATE NO. : 24 SEAT ASSEMBLY & SEAT LOCK	PAGE NO. 47
---	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 25 ENGINE MOUNTINGS	PAGE NO. 49
------------------------------------	----------------




PLATE NO. : 26 FRAME & FRAME FITTINGS	PAGE NO. 51
--	----------------




PLATE NO. : 27 SWING ARM & REAR SHOCK ABSORBER	PAGE NO. 53
--	----------------





PLATE NO. : 28 RIDER FOOT REST	PAGE NO. 55
-----------------------------------	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 29 PILLION FOOT REST & HOLDER	PAGE NO. 57
--	----------------




PLATE NO. : 30 MUDGUARD - FRONT & REAR	PAGE NO. 59
---	----------------




PLATE NO. : 31 STAND ASSEMBLY	PAGE NO. 61
----------------------------------	----------------





PLATE NO. : 32 TYRE / TUBE / RIM	PAGE NO. 63
-------------------------------------	----------------



Pictorial Index

Discover 125 BS IV

PLATE NO. : 33
FRONT HUB (DISC BRAKE)

PAGE NO.
65




PLATE NO. : 34
FRONT MASTER CYLINDER

PAGE NO.
67




PLATE NO. : 35
FRONT DISC BRAKE CALIPER ASSLY

PAGE NO.
69





PLATE NO. : 36
FRONT HUB (DRUM BRAKE)

PAGE NO.
71



Pictorial Index

Discover 125 BS IV

PLATE NO. : 37
REAR HUB

PAGE NO.
73 - 75




PLATE NO. : 38
REAR BRAKE PEDAL

PAGE NO.
77




PLATE NO. : 39
HANDLE BAR

PAGE NO.
79 - 81








PLATE NO. : 40
FRONT FORK

PAGE NO.
83



Pictorial Index

Discover 125 BS IV

PLATE NO. : 41 PETROL TANK CAP & GAUGE FUEL	PAGE NO. 85	PLATE NO. : 42 FITTINGS - PETROL TANK, SIDE COVERS & COVER SEAT	PAGE NO. 87
			
PLATE NO. : 43 SPEEDOMETER ASSEMBLY	PAGE NO. 89	PLATE NO. : 44 CONTROL CABLES	PAGE NO. 91
			

Pictorial Index

Discover 125 BS IV





PLATE NO. : 45 CHAIN CASE	PAGE NO. 93	PLATE NO. : 46 HEAD LAMP & FAIRING	PAGE NO. 95 - 97
			
PLATE NO. : 47 INDICATOR LIGHT ASSEMBLY	PAGE NO. 99	PLATE NO. : 48 TAIL LAMP ASSEMBLY, FRONT & REAR NUMBER PLATE	PAGE NO. 101
			




PLATE NO. : 49 ELECTRICAL EQUIPMENTS	PAGE NO. 103
	
PLATE NO. : 50 ACCESSORIES & GRAB HANDLE	PAGE NO. 105
	

PLATE NO. : 51 TOOL KIT	PAGE NO. 107


PLATE NO. : 52 PAINTED PARTS AND DECALS	PAGE NO. 109 - 111

PLATE NO. : 53 CONSUMABLE PARTS	PAGE NO. 113
	

Cover Cylinder Head




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5110 29	Cover Cylinder Head	1	1	
2	59 0400 38	Bolt	4	4	
3	JD 5110 10	Gasket Head Cover	1	1	
4	JA 5110 08	Bolt Head Mounting	4	4	
5	PA 5110 39	Plate Cylinder Head	1	1	
6	JZ 5810 04	Hose C' case Breather	1	1	
7	DG 1210 02	Clamp	1	1	
8	59 0400 50	Flange Bolt	1	1	



SAI System


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JH 5822 00	Unit SAI	1	1	
2	JE 5810 39	Band Clip SAI Hose Outlet Tube	3	3	
3	JZ 5824 05	Tube Metallic SAI	1	1	
4	JE 5110 67	Gasket Sai Flange	1	1	
5	KAEG0614	Bolt Flanged Small	2	2	
6	JZ 5824 04	Hose Connector SAI	1	1	
7	JZ 5824 00	Hose Intake SAI	1	1	
8	JY 5810 28	Clamp	1	1	
9	DG 1210 03	Clamp	2	1	
10	JZ 5824 01	Hose Manifold SAI	1	1	
11	KA DF06 30	Bolt Flanged	2	2	
12	JD 1138 15	Sleeve SAI Unit	4	4	
13	JD 1138 14	Grommet SAI Unit	2	2	
14	KC GA06 06	Nut Hex Flanged	2	2	
15	JZ 5810 54	Cover AF D101b SAI	1	1	
16	JH 5826 01	Plate Supporting SAI	1	1	
17	KB RA42 19	Screw Tapping Pan Cross	1	1	
18	JH 5826 02	Foam Element SAI	1	1	

Cylinder Head




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	36 JZ01 82	Head Cylinder Complete	1	1	Refer Kit Details
2	JA 5110 28	Stud	2	2	
3	JD 5110 08	Gasket Cylinder Head	1	1	
4	JZ 5814 07	Intake Manifold	1	1	
5	JA 5814 06	Bolt Flange	2	2	
6	JZ 5812 10	Sleeve (Carb - Duct Rubber)	1	1	
7	DH 1210 38	Clamp (Klipco Norma 45 To 48)	1	1	
8	39 2539 21	'O' Ring (Intake Pipe)	1	1	
9	JB 5110 18	Sleeve Spark Plug R.H	1	1	
10	39 2608 01	Grub Screw	1	1	
11	39 2629 21	'O' Ring Sleeve	1	1	
12	39 1283 21	'O' Ring Sleeve	1	1	

Valve




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JA 5112 11	Shaft Rocker Arm Exhaust	2	2	Refer Kit List Refer Kit List
2	JZ 5112 03	Rocker Arm with Roller	2	2	
3	DG 1010 29	Cotter Valve (Collet)	4	4	
4	36 JZ00 01	Valve Kit	1	1	
5	36 JZ00 04	Valve Repair Kit	1	1	
6	39 2017 19	Seal Valve Stem	2	2	

Camshaft / Tensioner




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5110 04	Camshaft Complete	1	1	
2	JA 5112 16	Spacer Cam Sprocket	1	1	
3	DS 1012 76	Sprocket Cam Shaft	1	1	
4	DK 1013 86	Bolt Allen Bolt	1	1	
5	DH 1010 48	Special Washer ('O' Washer)	1	1	
6	36 JE00 03	Guide Chain Kit	1	1	Refer Kit List
7	DH 1013 92	Bolt Special	1	1	
8	JH 5210 05	Chain Tensioner	1	1	
9	CS 1011 28	Gasket	1	1	
10	DD 1010 62	Bolt	1	1	
11	KA ED06 20	Flange Bolt	2	2	
12	39 0594 17	Circlip for Camshaft	1	1	
13	39 2669 21	'O' Ring (Tensioner)	1	1	
14	DS 1099 05	Cam Chain (94 Link)	1	1	
15	39 2683 20	Bearing Ball	1	1	
16	39 1880 20	Bearing Ball	1	1	



Cylinder & Piston


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JD 5210 02	Gasket Cylinder	1	1	Refer Kit List
2	39 1000 06	Dowel Pin	4	4	
3	36 JE00 02	Piston Ring Set	1	1	
4	DP 1011 65	Wire Circlip	2	2	
5	36 JZ01 66	Cylinder Block / Piston Assembly	1	1	
6	JE 3514 03	Engine Temperature Sensor	1	1	
7	JA 5210 15	Damper	2	2	



Crankshaft


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	59 1500 14	Flange Nut	2	2	Refer Kit List
2A	59 1200 03	Belleville Washer	2	2	
2B	59 1100 08	Plain Washer	1	1	
3	31 1011 73	Woodruff Key	1	1	
4	JZ 5310 07	Crank Shaft Assly	1	1	
5	39 1864 20	Ball Bearing	2	2	
6	DS 1011 54	Parallel Key	1	1	
7	36 JZ00 23	Set Primary Drive / Driven	1	1	
8	JA 5310 12	Spring	1	1	
9	JA 5310 15	Pin (C/S Plunger)	1	1	
10	JB 5310 21	Plunger Oil	1	1	
11	JD 5310 04	Spacer Crankshaft Clutch Side	1	1	

Transmission




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5510 10	Shaft Input W/O Gun hole	1	1	
2	JZ 5512 02	Gear 4th Drive	1	1	
3	39 0987 17	Ring Snap	5	5	
4	JA 5510 02	Spline Washer	4	4	
5	JE 5512 01	Gear 3rd Drive	1	1	
5A	JZ 5512 13	Gear 5th Drive-Forged	1	1	
6	JZ 5512 00	Gear 2nd Drive	1	1	
7	JA 5510 04	Washer Thrust 2nd Drive	1	1	
8	JZ 5510 08	Shaft Output Forging Route	1	1	
9	JZ 5512 10	Bush 2nd Driven	1	1	
9A	JZ 5512 06	Gear 2nd Driven	1	1	
10	JZ 5512 11	Gear 5th Driven-Forged	1	1	
11	JE 5512 06	Gear 3rd Driven	1	1	
12	JZ 5512 08	Gear 4th Driven	1	1	
13	JZ 5512 05	Bush 1st Driven	1	1	
14	JZ 5512 04	Gear 1st Driven	1	1	
15	JA 5510 08	Washer Thrust 1st Driven	1	1	
16	JA 5510 09	Collar Sprocket Drive	1	1	
17	59 2100 24	'O' Ring Collar Sprocket	1	1	
18	JZ 5510 04	Sprocket Drive	1	1	
19	DU 1012 13	Plate Lock Sprocket	1	1	
20	DS 1013 55	Socket Head Bolt	2	2	

Change Drum & Shift Fork




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	PA 5610 00	Drum Complete Gear Shift	1	1	
2	39 0992 06	Dowel (Pin Drum Change)	4	4	
3	JD 5610 11	Special Bolt	1	1	
4	JD 5610 06	Shaft Gear Shift Fork	2	2	
5	JD 5610 04	Fork Gear Shift Output	2	2	
6	JZ 5610 02	Fork Gear Shift Input	1	1	
7	JE 5610 05	Cam Drum Change	1	1	



Gear Change Mechanism


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	52 JZ02 64	Lever Complete Gear Shift	1	1	
2	JW 5612 06	Extension Spring	1	1	
3	JW 5612 08	Spring Gear Shift Return	1	1	
4	PA 5612 09	Inhibitor Complete Gear Shift	1	1	
5	JD 5612 04	Spring Inhibitor	1	1	
6	LD B000 44	Plain Washer	1	1	
7	BF 5612 19	Bolt Dent Lever	1	1	
8	JZ 5614 15	Lever Complete Gear Shifter	1	1	
9	DH 1015 09	Damper	1	1	
10	JH 5614 04	Damper	1	1	
11	39 1902 04	Bolt Flange M6	1	1	

Engine Assembly & Crankcase RH




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5010 13	Engine Assly	1	1	
2	36 JZ01 68	C'case Clutch Side NRB + Bush	1	1	
3	59 2000 36	Bearing Ball	1	1	
4	JA 5410 11	Needle Roller Bearing	1	1	
5	JA 5410 10	Stopper Plate	1	1	
6	39 1000 06	Dowel Pin	2	2	
7	PF 5410 18	Bushing Drum	1	1	
8	DH 1013 80	Screw	1	1	
9	59 0400 38	Bolt Flange	1	1	
10	52 JA00 29	Bolt Pre - Coated	1	1	
11	JA 5410 12	Guide Kick	1	1	
12	39 1964 04	Hexagon Bolt	2	2	

Crankcase LH




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	36 JZ01 67	Kit C'case Mag Side NRB + Bush	1	1	
2	39 2562 20	Needle Roller Bearing	1	1	
3	59 2000 36	Ball Bearing	1	1	
4	39 1715 19	Seal Oil	1	1	
5	31 2010 81	Neutral Switch	1	1	
6	DH 1017 84	Gasket Neutral Switch	1	1	
7	39 2190 19	Oil Seal	1	1	
8	JA 5410 05	Bush Starter Clutch	1	1	
9	39 0747 01	Pan Head Screw	2	2	
10	JA 5410 34	Stopper Gear Starter Clutch	1	1	
11	39 1000 06	Hollow Dowel Pin	4	4	
12	39 0999 06	Hollow Dowel Pin	4	4	
13	JG 5710 24	Mesh Oil Filter Assembly	1	1	
14	LJ A000 04	Strainer 'O' Ring	1	1	
15	JV 5410 06	Cap Strainer	1	1	
16	59 0400 38	Bolt	6	6	
17	39 1759 04	Bolt	1	1	
18	59 2100 23	'O' Ring Cap Strainer	1	1	
19	JA 5410 27	Damper Crankshaft	1	1	

Cover Clutch




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	52 JE00 18	Clutch Cover	1	1	
2	JE 5412 11	Decal Clutch Cover	1	1	
3	39 1041 19	Oil Seal Clutch Lever	1	1	
4	30 1011 42	Oil Seal (Kick Shaft)	1	1	
5	JV 5412 08	Shaft Clutch Release	1	1	
6	DP 1012 69	Rod Push	1	1	
7	DG 1014 18	Gauge	1	1	
8	DS 1012 15	Wire Circilp	1	1	
9	39 2443 11	Washer Plain	1	1	
10	JE 5412 14	Spring Torsion Clutch Lever	1	1	
11	JA 5412 11	Cap Oil Filler	1	1	
12	JA 5412 25	'O' Ring Cap Oil Filler	1	1	
13	JA 5412 12	Gasket Clutch Cover	1	1	
14	59 0400 38	Bolt	8	8	
15	JV 5412 09	Bracket Clutch Cable	1	1	
16	DD 1211 81	Oil Filter Element	1	1	
17	39 1671 21	'O' Ring	1	1	
18	JE 5412 08	Cap Oil Filter	1	1	
19	39 1673 04	Bolt Flange M6	3	3	
20	39 1001 20	Bearing Push Rod	1	1	
21	39 0999 06	Pin Hollow Dowel	2	2	

Cover Magneto




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	52 JE00 17	Cover Magneto	1	1	
2	KA ED06 40	Bolt Flange	8	8	
3	JA 5412 05	Gasket Magneto Cover	1	1	
4	59 0400 38	Bolt	2	2	
5	JZ 5412 35	Cover LH Rear Complete	1	1	
6	JA 5410 05	Bush	1	1	
7	JA 5412 33	Cap TDC Finder	1	1	
8	30 1011 95	'O' Ring	1	1	
9	JW 2330 00	Gear Shift Label	1	1	
10	JE 5412 12	Decal Magneto Cover	1	1	



Clutch Assembly


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5514 13	Clutch Complete	1	1	
2	JA 5514 06	Collar Clutch	1	1	
3	39 2600 11	Washer	1	1	
4	36 JZ00 37	Friction Plate	1	1	
5	JB 5514 08	Wheel Clutch	1	1	
6	30 1010 96	Plate Clutch	4	4	
7	JB 5514 11	Hub Clutch	1	1	
8	JZ 5514 15	Compression Spring	6	6	
9	JB 5514 06	Holder	1	1	
10	39 0980 04	Bolt Flange	6	6	
11	PF 5514 01	Clutch Hsg Assembly Complete	1	1	
12	JA 5514 20	Plain Washer	1	1	
13	JE 5514 09	Washer Belleville	1	1	
14	52 JA00 28	Nut Pre - Coated	1	1	
15	39 1001 20	Bearing Clutch Lifter	1	1	
16	36 JZ00 23	Set Primary Drive & Driven	1	1	
17	JD 5514 00	Spacer Clutch Assly	1	1	
18	JZ 5514 14	Assembly Clutch Plate	1	1	



Kick Starter Mechanism


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JA 6212 01	Lever Assly Kick	1	1	
2	59 0400 25	Bolt Special	1	1	
3	36 DU10 07	Boss Kick Set	1	1	
4	22 1502 41	Plain Washer	1	1	
5	39 0993 11	Plain Washer Small	3	3	
6	39 0738 17	Circlip Shaft	2	2	
7	JD 6210 01	Shaft Kick	1	1	
8	DS 1011 17	Spring Kick Starter	1	1	
9	JA 6210 02	Ratchet	1	1	
10	JZ 6210 00	Gear Spur Kick Starter	1	1	
11	JA 6210 06	Washer Thrust	1	1	
12	39 2408 17	Circlip	1	1	
13	DD 1010 97	Kick Rubber	1	1	
14	JE 5410 08	Spring Kick Starter Return	1	1	

Carburettor Assembly




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5812 41	Carburettor Assembly EVAP	1	1	
2	36 JZ00 20	Adjuster Throttle Cable Kit	1	1	
3	DH 1211 69	Pilot Screw Kit	1	1	
4	36 JZ00 31	Jet Kit	1	1	
5	36 JZ00 16	Idling Screw Kit	1	1	
6	JA 5812 21	Valve Complete Float	1	1	
7	24 1213 65	Float Complete	1	1	
8	CB 1210 39	Screw Washers Bowl M4x14	2	2	
11	36 Jz00 32	Throttle Valve Kit	1	1	
12	24 1210 69	Float Pin	1	1	
13	JA 5813 14	Drain Screw	1	1	
14	JZ 5812 20	Hose Drain	1	1	
15	JZ 5812 16	Spring	1	1	
16	JA 5812 32	O-Ring (FCB)	1	1	

Air Cleaner Complete




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5810 56	Air Filter Assembly	1	1	
2	DS 1211 16	Air Filter Duct	1	1	
3	JZ 5810 10	Assembly Cartridge Air filter	1	1	
4	JZ 5810 11	Element Air Filter	1	1	
5	DX 1210 11	Flame Arrester	1	1	
6	JZ 5810 12	Tube Drain	1	1	
7	DS 1211 26	Plug	1	1	
8	DG 1210 02	Clamp	1	1	
9	JZ 5810 04	Hose Breather	1	1	
10	39 0071 04	Hex Head Screw - M5	3	3	
11	39 1765 11	Washer	3	3	
12	DH 1210 38	Clamp	1	1	
13	DS 1610 69	Bracket Side Cover Mtg.	1	1	
14	JZ 5810 06	Connecting Tube	1	1	
15	39 1779 02	Self Tapping Screw	2	2	
16	JZ 5810 55	Assembly Cover Air Filter	1	1	
17	JZ 5810 29	'O' Ring	1	1	

EVAP Mechanism




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JY 1710 77	Canister	1	1	
2	JY 1710 69	Spring Band Clamp 15 x 10	1	1	
3	PA 1716 10	Tube Inline Connector To Purge	1	1	
4	JY 1710 90	Spring Band Clamp 13 x 12	3	3	
5	JH 1710 48	Grommet Purge Valve	1	1	
6	PD 1716 16	Valve Purge	1	1	
7	PA 1716 11	Tube Canister Breather	1	1	
8	PA 1716 07	Tube Purge Valve To Carburetor	1	1	
9	JY 1710 70	Spring Band Clamp 9 x 8.4	7	7	
10	PA 1716 05	Tube Y Connector To Canister	1	1	
11	GL 1710 36	Connector For Breather & Vapor Tube	1	1	
12	PA 1718 08	Tube Drain	1	1	
13	JY 1718 25	Plug Fuel Drain	1	1	
14	PA 1718 10	Tube Tank To Y Connector	1	1	
15	PA 1716 09	Tube Canister Drain	1	1	
16	DG 1210 40	Clamp - Canister Breather	1	1	
17	DH 1614 29	Strap Canister	1	1	




Silencer Assembly

No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	YJ Z280 01	Silencer Assly without Shield	1	1	
2	JE 5910 02	Gasket Exhaust Mounting	1	1	
3	39 2295 15	Nut Flange M8	2	2	
4	JZ 5910 43	Shield Silencer	1	1	
5	JW 5910 28	Truss Screw	2	2	
6	JB 5910 59	Damper Shield Muffler	2	2	
7	39 2754 04	Bolt Hex with Flange M5	1	1	
8	39 2492 11	Plain Washer	1	1	
9	39 1850 04	Bolt - Hexagon With Flange	1	1	
10	JB 1130 05	Washer	2	2	
11	36 DK00 09	Hardware Kit	1	1	
12	DD 1610 71	U Nut M10 x 1.25	1	1	
13	DH 1611 57	Tube Silencer Mtg.	1	1	
14	DH 1611 55	Damper Silencer	1	1	
15	JB 5910 68	Washer Nylon Shield Silencer	2	2	

Oil Pump




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 5710 00	Oil Pump Assly	1	1	
2	JA 5410 16	Gasket Case Oil Pump	1	1	
3	FD 1010 78	Pan Head Screw	3	3	
4	39 0999 06	Dowel	2	2	
5	JZ 5710 01	Gear Driven + Shaft	1	1	



Starter Assembly


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JA 6214 14	Body Complete Starter Clutch	1	1	
2	DH 1017 81	Plate Roller Clutch	1	1	
3	JZ 6214 05	Gear Starter Clutch	1	1	
4	JA 6214 02	Washer	2	2	
5	JA 6214 06	Drive Assly	1	1	
6	36 JZ00 08	Starter Clutch Repair Kit	1	1	
7	JV 3516 00	Motor Assly	1	1	
8	KA ED06 20	Bolt	2	2	

Magneto, CDI, Spark Plug & H.T. Coil




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 3510 01	Rotor Assembly	1	1	
2	JP 3510 07	Stater Assembly Complete	1	1	
3	39 1675 04	Bolt Flange	2	2	
4	DH 1013 80	Pan Head Screw	3	3	
5	PA 3512 01	H. T. Coil with Cable LH	1	1	
6	PA 3512 02	H. T. Coil with Cable RH	1	1	
7	JZ 3512 14	C.D.I. Assly	1	1	
8	DD 1110 18	Spark Plug PRZ9 HC	2	2	
9	DD 1110 48	Spark Plug Cap LH	1	1	
	DH 1110 15	Spark Plug Cap RH	1	1	
10A	DD 1110 11	Grommet Spark Plug Cap LH	1	1	
10B	DH 1110 13	Grommet Spark - Plug Cap RH	1	1	
11	DD 1110 12	Grommet for HT Cable	2	2	
12	39 1943 04	Bolt Flange	2	2	
13	JK 4020 00	Regulator Assembly	1	1	
14	JA 5410 28	Lock Plate	1	1	
15	59 0400 14	Bolt Flange (N.I.)	4	4	
16	JD 3512 06	Grommet Sleeve Spark Plug	1	1	

Seat Assembly & Seat Lock




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1910 30	Seat Assembly Complete	1	1	
2	DS 2110 07	Damper Seat Front	1	1	
3	JZ 1910 11	Damper Seat I	6	6	
4	JZ 1910 10	Damper Seat II	2	2	
5	DS 2110 06	Lock Assembly Seat	1	1	
6	39 1902 04	Flanged Bolt	2	2	
7	DH 1612 33	Reinf. Seat Lock	1	1	



Engine Mountings


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JA 1134 03	Flange Bolt M10 x 110	2	2	
2	39 2723 15	Flanged Nut	2	2	
3	39 1556 04	Bolt Flanged	8	8	
4	LA D000 52	Bolt Flange	1	1	
5	39 1970 15	Nut Flanged	4	4	
6	JA 1134 04	Bolt Flanged	2	2	
7	LA D000 41	Bolt Flanged	1	1	
8	JZ 1134 00	BKT Comp LH Engine Front	1	1	
9	JZ 1134 03	BKT Comp RH Engine Front	1	1	
10	JZ 1134 02	Engine Mtg. BKT Rear Top	2	2	
11	JZ 1134 05	Bracket Comp LH Top	1	1	
12	JZ 1134 07	Bracket Comp RH Top	1	1	

Frame & Frame Fittings




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1112 78	Frame Assembly Complete	1	1	
2	DS 1810 18	Nut Fork	1	1	
3	DH 1810 14	Cup - Steering	1	1	
4	36 3140 05	Bearing Cone Kit With Grease	1	1	
5	36 3140 02	Ball Steel Kit	1	1	
6	DP 1710 06	Silent Bush	2	2	
7	DP 1612 60	End Cap	2	2	
8	PA 1138 00	Hook Clutch Cable	1	1	
9	39 2060 04	Bolt M5	1	1	

Swing Arm & Rear Shock Absorber




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JB 1220 16	Hex Bolt / Flange - M10	2	2	
2A	JB 1220 11	Plain Washer	4	4	
2B	JB 1220 10	Plain Washer	4	4	
3	JN 1220 00	Rear Shock Absorber	2	2	
4	39 0258 11	Plain Washer	2	2	
5	JN 1220 06	Swing Arm Assembly	1	1	
6	DS 1710 15	Cap Swing Arm	2	2	
7	JB 1220 09	Domed Cap Nut	2	2	
8	39 2726 12	Spring Washer	2	--	
	39 0789 12	Spring Washer	--	2	
9	DS 1710 07	Chain Slider	1	1	
10	39 0553 02	Screw	2	2	
11	39 0454 11	Plain Washer	2	2	
12	DS 1710 13	Shaft Swing Arm	1	1	
13	39 1358 15	Hex Nut Flanged	1	1	
14	DJ 1510 36	Adjuster Chain LH	1	1	
15	DJ 1510 37	Adjuster Chain RH	1	1	
16	39 0292 15	Hexagon Nut	4	4	
17	DS 1710 14	Mud Flap	1	1	
18	39 2060 04	Flange Bolt	2	2	
19	DJ 1510 47	Plate Chain Adjuster	2	2	

Rider Foot Rest




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1130 01	Main Step LH	1	1	
2	LA D001 26	Flange Bolt	2	2	
3	JZ 1130 11	Main Step RH	1	1	
4	DF 1614 13	Rubber Main Step	2	2	
5	DH 1611 94	Kick Stopper	1	1	
6	KA DD08 20	Bolt Flanged	2	2	
7	KD CB08 16	Washer Spring	2	2	



Pillion Foot Rest & Holder


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1130 15	Holder LH Step	1	1	
2	JZ 1130 17	Holder RH Step	1	1	
3	DJ 1611 29	Step Assembly RH	1	1	
4	DJ 1611 22	Rubber Pillion Step	2	2	
5	DD 1613 81	Pin Pillion Step	2	2	
6	DH 1611 00	Spacer	2	2	
7	39 0784 08	Split Pin	2	2	
8	39 2722 04	Socket Head Bolt	4	4	
9	30 1410 31	'O' Ring	2	2	
10	39 1040 11	Washer Plain	2	2	
11	DJ 1611 28	Step Assembly LH	1	1	

Mudguard - Front & Rear




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	DS 1611 25	Cable Guide	1	1	
2	JB 1814 21	Brace Fender	–	1	
	JB 1814 16	Brace Fender	1	–	
3	39 1075 04	Bolt Flange Small	4	4	
4	JZ 1814 02	Fender Rear Front	1	1	
5	DS 1612 87	Flange Bolt	2	2	
6	39 0798 15	Flange Nut	2	2	
7	39 0211 11	Plain Washer	2	2	
8	PA 1814 26	Fender Rear EVAP	1	1	
9	39 1943 04	Flange Bolt	2	2	
10	DJ 1610 69	Nail for Cable Guide	1	1	
11	39 0326 15	Nyloc Nut	3	3	
12	JB 1814 03	Flap Front Fender	1	1	
13	DH 1611 58	Grommet Side Cover RR	2	2	
14	JZ 1814 06	Grommet Saree Guard	1	1	
15	39 0242 11	Washer	6	6	
16	39 2420 01	Screw	3	3	
17	DJ 2011 73	Grommet For Cables - Rear Fender	2	2	

Stand Assembly




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	DS 1611 13	Center Stand	1	1	
2	DS 1611 12	Shaft Stand	1	1	
3	39 0797 08	Pin Cotter	1	1	
4	DH 1611 21	Spring Main Stand	1	1	
5	DH 1611 45	Cover Spring Main Stand	1	1	
6	DS 1610 77	Stand Side	1	1	
7	DH 1610 66	Spring Side Stand with Cover	1	1	
8	DF 1611 02	Bolt	1	1	
9	39 0422 15	Nut	1	1	
10	JN 1132 00	Damper Main Stand	1	1	
11	DH 1611 46	Cover Side Stand Spring	1	1	

Tube / Tyre / Rim




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	56 JZ2Z 7D	Wheel Front	-	1	
	56 JZ2Y 7D	Wheel Front Drum	1	-	
2	DS 1510 48	Tyre Front	1	1	
3	DS 1510 49	Tube Front	1	1	
4	56 JZ3A 7D	Wheel Rear	1	1	
	56 JZ3B 7D	Wheel Rear Drum	1	-	
5	DS 1510 31	Tyre Rear	-	1	
	DS 1510 52	Tyre Rear	1	-	
6	DS 1510 29	Tube Rear	-	1	
	DS 1510 53	Tube Rear	1	-	

Front Hub (Disc Brake)




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	30 1510 33	Seal Oil	-	1	
2	KP BB63 01	Bearing Ball	-	2	
3	DE 1510 06	Spacer Assembly	-	1	
4	DE 1510 12	Plate Drive	-	1	
5	DE 1510 08	Seal Oil	-	1	
6	30 1510 41	Meter Gear	-	1	
7	DS 1510 38	Speedo Gear	-	1	
8	LA C000 02	Hex. Soc. Head Bolt	-	5	
9	JW 1318 06	Disc (200 mm Dia)	-	1	
10	JB 1310 18	Plain Washer	-	1	
11	DS 1510 58	Spacer	-	1	
12	JB 1310 17	Axle	-	1	
13	59 1500 03	'U' Nut M12	-	1	
14	JW 1812 41	Cover Disc	-	1	
15	JN 1812 11	Clip Nut	-	1	
16	LB U000 04	Step Bolt	-	1	
17	LB U000 05	Truss Screw	-	1	
18	36 DU15 04	Front Hub Bushing Kit	-	1	
19	JZ 1316 11	Case Meter Assly- Screw Mtg	-	1	



Front Master Cylinder


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	36 DJ40 31	Major Kit - M Cyl. with Grease	-	1	
2	JW 1318 05	Hose Brake Front	-	1	
3	DJ 1910 59	Lever Grip RH	-	1	
4	DJ 1910 25	Banjo Bolt	-	2	
5	DJ 1910 26	Washer Copper	-	4	
6	DJ 1910 27	Clamp Holder RH	-	1	
7	DJ 1910 28	Bolt Clamp Holder	-	2	
8	DJ 1910 29	Bolt Front Brake Lever	-	1	
9	DJ 1910 30	Nut Flanged	-	1	
10	DJ 1910 31	Screw	-	2	
11	DJ 1910 58	Cylinder Master with Lever	-	1	
12	DJ 2011 09	Front Brake Switch	-	1	
13	DJ 1910 34	Reservoir Cover	-	1	
14	DJ 1910 35	Diaphragm	-	1	
15	DJ 1910 38	Window Oil Level	-	1	
16	JN 1318 04	Clamp Hose Pipe - Upper	-	1	
17	DJ 2011 08	Cable Assly for Switch	-	1	N.I.



Front Disc Brake Caliper Assembly


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JW 1318 01	Caliper Assembly Front	-	1	Caliper Mounting
2	DH 1510 39	Bolt Flanged Pre - Coated	-	2	
3	DE 1510 48	Spring Pad	-	1	
4	DE 1510 46	Bleeder Screw	-	1	
5	DE 1510 47	Bleeder Cap	-	1	
6	JW 1318 07	Brake Pad Set	-	1	
7	DE 1510 43	Insulator	-	1	
8	DE 1510 45	Dust Cover	-	1	
9	JW 1318 09	Minor Kit - Caliper	-	1	
10	36 DJ40 33	Major Kit - Caliper With Grease	-	1	
11	36 PD00 45	Kit Caliper Bracket	-	1	Refer Kit List
12	JW 1318 01	Caliper Bracket	-	1	

Front Hub (Drum Brake)




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	59 1500 03	U Nut (M12)	1	—	
1A	JB 1310 17	Axle Front Wheel	1	—	
2	JB 1310 18	Plain Washer	1	—	
3	DS 1510 56	Dust Cover Front	1	—	
4	JB 1310 22	Spacer Assembly	1	—	
5	39 2688 20	Bearing Ball	2	—	
5A	30 1510 33	Oil Seal	1	—	
6	30 1510 32	Collar Bearing	1	—	
7	JA 1316 06	Bushing Speedo Gear	1	—	
8	30 1510 68	Shoe Brake	1	—	
9	30 1510 69	Spring	2	—	
10	30 1510 35	Oil Seal	1	—	
11	30 1510 04	Cam Brake Assly.	1	—	
12	JA 1316 05	Panel Front Brake	1	—	
13	30 1510 38	Ring 'O'	1	—	
14	DD 1510 09	Indicator	1	—	
15	39 0775 04	Bolt	1	—	
16	JA 1316 07	Lever Brake Cam	1	—	
17	39 0798 15	Nut	1	—	
18	39 0840 01	Screw Pan Cross	1	—	
19	39 0900 12	Washer Spring	1	—	
20	30 1511 18	Stopper for Bushing	1	—	
21	30 1510 41	Screw	1	—	
22	DL 1510 14	Speedometer Gear	1	—	
23	30 1510 35	Seal Oil	1	—	
24	30 1510 42	Washer Plain	2	—	
25	39 1013 21	'O' Ring	1	—	

Rear Hub




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1410 03	Drive Chain Lock	1	1	
2	36 JZ00 26	Chain Sprocket Kit	1	1	
3	39 0801 15	Nut - Hexagon - M20 x 1	1	1	
4	39 2567 11	Plain Washer	1	1	
5	DJ 1510 35	Collar Assly	1	1	
6	39 2240 20	Bearing Ball	1	1	
	KP BB62 02	Bearing Ball	--	1	
7	DS 1510 68	Coupling	1	1	
8	DS 1510 73	'D' Bolt	4	4	
9	LC B000 05	Hex Lock Nut	4	4	
10	PF 1312 20	Washer	2	2	
11	DJ 1510 33	Sleeve	1	1	
12	39 2686 20	Bearing Ball	1	1	
13	30 1510 75	Collar Bearing	1	1	
14	DK 1510 94	Damper	1	1	
15	39 2687 20	Bearing Ball	--	1	
	KP BB63 02	Bearing Ball	1	--	
16	30 1510 69	Spring	2	2	
17	30 1510 68	Shoe Brake Assembly	2	2	
18	DS 1510 69	Panel Rear Brake	1	1	
19	30 1510 11	Cam Brake Assembly	1	1	
19A	39 0722 11	Plain Washer	1	1	
20	30 1510 38	Ring 'O'	1	1	
21	30 1510 05	Indicator	1	1	
22	JZ 1318 91	Lever Brake	1	1	
23	39 2447 04	Bolt	1	1	
24	JN 1312 11	Axle	1	1	

Rear Hub




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
25	DX 1510 22	Collar	1	1	
26	LD B000 01	Plain Washer	1	1	
27	DJ 1710 33	'U' Nut	1	1	

Rear Brake Pedal




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JA 1610 03	Pad Lever Brake	1	1	
2	PA 1610 12	Brake Pedal	1	1	
3	39 1680 04	Hex. Bolt	1	1	
4	DG 1910 45	Washer	1	1	
5	DS 1910 11	Brake Pedal Spring	1	1	
6	JZ 1610 04	Rod Brake	1	1	
7	30 1910 38	Pin	1	1	
8	39 0198 11	Plain Washer	2	2	
9	39 0808 08	Split Pin	1	1	
10	30 1910 35	Spring	1	1	
11	15 1910 26	Pin	1	1	
12	30 1910 36	Brake Adjuster Nut	1	1	
13	DS 1510 25	Rod Torque	1	1	
14	DH 1510 29	Step Bolt	1	1	
15	39 0789 12	Spring Washer	2	2	
16	39 0694 15	Nut Hex. Lock	2	2	
17	39 0807 08	Pin Snap	2	2	
18	30 1510 96	Hex. Bolt	1	1	
19	39 1540 11	Plain Washer	1	1	
20	JZ 1610 06	Sleeve Brake Return Spring	1	1	
21	36 DH40 14	Brake Adjusting Kit	1	1	

Handle Bar




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	DS 1810 44	Handle Bar	1	1	
2	JB 4014 00	Control Switch LH	1	1	
3	JZ 4014 08	Control Switch RH	1	1	
4	JZ 1610 23	Lever & Holder Assembly LH	1	1	
5	DS 1910 15	Grip LH	1	1	
6	DJ 1910 83	Lever Grip Left	1	1	
7	JZ 4014 03	Clutch Switch with Vertical Base	1	1	
8	DS 1910 52	Boot for Lever LH	1	1	
9	DJ 2210 03	Mirror Assly. LH	1	1	
10	DJ 2210 04	Mirror Assly. RH	1	1	
11	36 DS18 01	Kit Holder Handle	2	2	
12	DS 1910 18	Boot for Lever RH	1	--	
13	39 1714 04	Flange Bolt	4	4	
14	DS 1810 07	Washer Handle Upper	2	2	
15	DS 1810 08	Damper Handle Upper	2	2	
16	DS 1810 09	Damper Handle Lower	2	2	
17	DS 1810 10	Washer Handle Lower	2	2	
18	39 2249 15	Nylock Nut	2	2	
19	DL 1910 14	Stud Lever LH	1	1	
20	30 1910 48	Band	2	2	
21	JZ 2326 01	Lock Set + Tank Cap	1	1	
22	LA E000 21	Flange Bolt	2	2	
23	JZ 1510 23	Holder Fork Upper	1	1	
24	DU 2010 46	Plunger With Spring	1	1	
25	DX 1910 01	Throttle Pipe	1	1	

Handle Bar




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
26	DS 1910 16	Hand Grip RH	1	1	
27	DH 1810 22	Handel Bar Weight	2	2	
28	39 2427 04	Socket Bolt	2	2	
29	DX 1910 09	Lever Assembly RH	1	-	
30	DD 1911 42	Lever Grip RH	1	-	
31	DS 1910 38	Holder RH	1	-	
32	JD 4022 17	Band (L 150)	1	1	

Front Fork




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 1210 56	Fork Front	1	–	
	JZ 1210 55	Fork Front	–	1	
2	36 DZ00 20	Front Fork Seal Kit	1	1	
3	30 1810 28	Gasket	2	2	
4	30 1810 25	Bolt	2	2	
5	JA 1510 13	Fork Pipe Inner	2	2	
6	DJ 1811 04	Spring Front Fork	2	2	
7	DS 1810 12	Bolt Fork	2	2	
8	DS 1810 15	Cap Nut Fork	1	1	
9	DS 1810 16	Plain Washer	1	1	
10	JZ 1510 23	Holder Fork upper	1	1	
11	30 1810 09	Bearing Cone	1	1	
12	JZ 1510 36	Under Bracket Fork	1	1	
13	39 0789 12	Spring Washer	2	2	
14	39 1181 01	Bolt	2	2	
15	JZ 1210 59	Outer Tube LH	–	1	
	JZ 1210 63	Outer Tube LH	1	–	
16	JZ 1210 60	Outer Tube RH	–	1	
	JZ 1210 64	Outer Tube RH	1	–	
17	JK 1210 07	Anti Friction Bush	2	2	
18	JW 1510 23	Cylinder Complete Fork	2	–	
	36 JZ00 40	Cylinder Complete Fork	–	2	
19	JK 1210 09	Washer Anti Friction Bush	2	2	
20	30 1810 29	'O' Ring	2	2	
21	JZ 1210 57	Leg Assembly LH	–	1	
	JZ 1210 61	Leg Assembly LH	1	–	
22	JZ 1210 58	Leg Assembly RH	–	1	
	JZ 1210 62	Leg Assembly RH	1	–	

Petrol Tank Cap & Gauge Fuel




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	PF 1716 01	Cap Assly. Tank	1	1	Not Serviceable BS IV
	JZ 2326 01	3 In 1 Lock Set + Tank Cap	1	1	
	2	AP 1012 55	2	2	
	3	39 2179 24	2	2	
	4	JZ 1718 09	1	1	
5	JZ 2326 00	3 In 1 Lock Set with Key	1	1	BS IV
	JZ 2326 01	3 In 1 Lock Set + Tank Cap	1	1	
6	DD 1412 27	Bolt Flanged	2	2	
7	39 0740 11	Washer (Non-Metallic)	2	2	
8	DS 2010 79	Tank Unit With New O Ring	1	1	
8A	JH 1710 17	O Ring Fuel Gauge	1	1	
9	DS 1410 13	Seat Tape	1	1	
10	KC GA05 05	Flanged Nut	4	4	
11	JZ 1718 22	Tube Fuel	1	1	
12	DK 1410 41	Pipe Clip	2	2	
13	36 JZ00 22	Kit fuel cock seal - Advik	1	1	
14	JZ 1710 20	Bush	1	1	
15	JZ 1710 21	Washer	1	1	
16	JH 1710 49	O Ring	1	1	

Fittings - Petrol Tank, Side Covers & Cover Seat




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	36 DS14 01	Grommet Kit for Side Cover	1	1	
2	DG 1611 21	Screw	1	1	
3	39 1943 04	Flanged Bolt	2	2	
4	JN 1710 00	Damper Rear	1	1	
5	39 1789 24	Washer Nylon	3	3	
6	39 0983 08	Pin Snap	1	1	
7	39 1054 11	Plain Washer	1	1	
8	DJ 1410 08	Damper Front	2	2	
9	31 1610 18	Damper	1	1	
10	DS 1610 35	Clip Nut	1	1	
11	DH 1612 31	Lock Side Cover	1	1	

Speedometer Assembly




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 4024 03	Speedometer Assly.	1	1	
2	JZ 1812 00	Flap Cowling	1	1	
3	JZ 4024 06	Speedo Machine With Dial Minda	1	1	Minda
	36 JZ00 39	Speedo Machine With Dial Pricol	1	1	Pricol
4	JZ 4024 07	Fuelgauge Machine with Minda	1	1	
	36 JZ00 38	Fuelgauge Machine with Pricol	1	1	
5	PA 4024 03	Speedo meter Top Cover	1	1	Pricol
	PA 4024 19	Speedo meter Top Cover	1	1	Minda
6	PA 4024 04	Speedometer wiring harness	1	1	Pricol
	PA 4024 20	Speedometer wiring harness	1	1	Minda
7	CL 2010 42	Bulb 12V - 1.2 W	4	4	
8	DL 1910 20	Bulb 12V - 3 W	2	2	
9	39 0798 15	Flanged Nut	2	2	
10	PA 4024 05	Speedometer Bracket	1	1	
11	DS 1810 60	Foam side Flap	1	1	N.I.
12	JN 1810 14	Foam Speedo Flap	2	2	N.I.
13	JN 1814 06	Beading Speedo Flap	4	4	N.I.
14	PA 4024 10	Cover Speedo Black	1	1	Pricol
	PA 4024 14	Cover Speedo Black	1	1	Minda
15	PA 4024 11	Assly Speedo Case	1	1	Pricol
	PA 4024 15	Assly Speedo Case	1	1	Minda
16	PA 4024 12	Trip Meter Knob	1	1	Pricol
	PA 4024 16	Trip Meter Knob	1	1	Minda
17	PA 4024 13	Screw Trip Meter Knob	1	1	Pricol
	PA 4024 17	Screw Trip Meter Knob	1	1	Minda

Control Cables




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	DS 1910 53	Speedometer Cable	1	-	
	JZ 1612 10	Speedometer Cable	-	1	
2	JZ 1612 03	Cable Clutch	1	1	
3	JZ 1612 21	Cable Accelerator	1	1	
4	DS 1910 54	Brake Cable	1	-	
5	30 1910 67	Oil Seal	1	-	

Chain Case




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	52 JZ09 60	Chain Case Assly Kit	1	1	
2	15 1610 69	Rubber Cap	1	1	
3	DH 1612 83	Bolt	4	4	
4	DX 1610 52	Beading Chain Case	1	1	

Head Lamp & Fairing



No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JN 1810 01	Wind Shield	1	1	
2	JZ 1812 06	Screw S.S.	4	4	
3	39 2141 24	Non Metallic Washer	4	4	
4	JZ 1810 03	Well Nut	4	4	
5	JN 1810 10	Bush-1 for Well Nut	2	2	
	JN 1810 11	Bush-2 for Well Nut	2	2	
6	35 1610 60	Clip Nut	5	5	
7	39 2238 01	Screw M.S.	2	2	
8	JZ 4010 12	Head Lamp Assly	1	1	
9	39 0454 11	Washer Metallic	6	6	
10	39 1778 02	Screw Tapping	2	2	
11	JN 1810 05	Bracket Head Lamp Mounting	1	1	
12	CL 2010 23	Lamp 12V 35/35W-HS1	1	1	
13	JZ 1810 04	Foam on Head Lamp	6	6	
14	JN 1810 19	Foam	1	1	
15	JZ 4010 15	Head Lamp Harness Branch	1	1	
16	JN 1810 03	Bracket Fairing Top	1	1	
17	JN 1810 17	Bracket Flap Support LH	1	1	
18	JN 1810 18	Bracket Flap Support RH	1	1	
19	JN 1810 21	Bolt Flange	2	2	
20	39 1943 04	Bolt Flange	2	2	
21	JN 1810 23	Bracket H/L Mtg Lower LH	1	1	
22	JN 1810 24	Bracket H/L Mtg Lower RH	1	1	
23	59 0100 05	Screw Mushroom Head	2	2	
24	JN 1810 04	Bracket Cowling	1	1	
25	39 0219 11	Washer	2	2	


Head Lamp & Fairing



 Front Wheel Direction


No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
26	39 2060 04	Bolt Hex	2	2	
27	JZ 1812 08	Bracket Cowling Lower	1	1	
28	39 1943 04	Bolt Flange	2	2	
29	39 1961 04	Bolt Hex Flange	1	1	
30	39 1907 01	Mushroom Head Screw	3	3	
31	39 2141 24	Washer Non-Metallic	4	4	
32	39 1508 11	Washer for H/L Adjustment Bolt	2	2	
33	39 0798 15	Hex Flange Nut	1	1	
34	JN 1810 19	Foam (N.I.)	1	1	
35	39 1508 11	Washer for H/L Adjustment Bolt	2	2	

Indicator Light Assembly




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 4010 00	Indicator Assly Front LH	1	1	
2	JZ 4010 01	Indicator Assly Front RH	1	1	
3	DJ 2012 06	Indicator Assly Rear LH	1	1	
4	DJ 2012 07	Indicator Assly Rear RH	1	1	
5	GH 2010 12	Lamp 12 V - 10W	4	4	
6	39 1225 15	Hex Nut with Flange	2	2	
7	31 2010 01	Collar	2	2	
8	LA D000 26	Bolt Flange	2	2	
9	JZ 1510 24	Blinker Mounting Bracket	1	1	
10	39 1943 04	Flange Bolts	2	2	

Tail Lamp Assembly, Front & Rear Number Plate




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 4010 45	Tail Lamp W/O Bulb	1	1	
2	DD 2010 11	Damper	2	2	
3	31 2010 01	Collar	2	2	
4	39 2124 15	Flange Nut	1	1	
5	DJ 1610 72	Bracket Rear No. Plate	1	1	
6	39 1553 04	Bolt Flange	2	2	
7	DP 1611 45	Number Plate Rear	1	1	
8	39 2476 04	Hex Flanged Bolt	2	2	
9	DP 1611 44	Number Plate Front	1	1	
10	JN 2328 01	Front No. Plate Mtg Bracket	1	1	
11	39 1783 01	Truss Screw Front No. Plate	2	2	
12	JW 4010 11	No. Plate Lamp with 2 Point Coupler	1	1	
13	DJ 2010 72	Bulb 12V/ 5W	1	1	
14	39 0705 01	Screw	2	2	
15	39 0711 11	Plain Washer	2	2	
16	39 1309 11	Washer	2	2	
17	39 0740 11	Washer (Non Metallic)	4	4	
18	39 0746 01	Screw Pan Cross	4	4	
19	JZ 1810 04	Foam Strip	1	1	
20	JZ 2328 05	Foam Rear Number Plate	1	1	
21	JZ 4010 46	Bulb Holder With Cable	1	1	
22	20 2010 29	Lamp 12V - 21/5W	1	1	

Electrical Equipments




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 4016 00	Horn LH with Stay	1	1	
2	39 1945 04	Flange Bolt	1	1	
3	JZ 4022 64	Wiring Harness	1	1	
4	31 2010 79	Rear Brake Switch	1	1	
5	DS 1910 07	Spring Brake Switch	1	1	
6	JL 4020 04	Light Control Module	1	1	
7	DS 2010 81	Battery 5 AH	1	1	
8	DX 1610 32	Base Battery	1	1	
9	DX 1610 44	Band Battery	1	1	
10	DX 1610 45	Battery Arrester	1	1	
11	39 1507 11	Plain Washer	1	1	N.I.
12	39 2208 04	Bolt Flange	2	2	
13	JK 3516 00	Starter Relay	1	1	
14	CB 2010 26	Fuse Box	2	2	
15	GF 2010 53	Fuse	2	2	
16	JK 4022 05	Cable St Relay to Motor	1	1	
17	JV 4022 05	Cable Assly. (Battery to Earth)	1	1	
18	30 1910 48	Band (Harness)	5	5	
19	30 2010 64	Band (Harness)	3	3	
20	JD 4018 03	Adapter Vent Tube	1	1	
21	39 1942 04	Bolt Flanged	1	1	
22	JG 4018 08	Foam Battery Bkt. 35 x 15 x 3	3	3	
23	JH 1710 47	Cable Tie Fixed Length	1	1	
24	JZ 1814 60	Rubber Grommet	2	2	
25	39 1551 04	Bolt Flanged M6 x 10	—	1	
	39 1942 04	Bolt Flanged	1	—	

Accessories & Grab Handle




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	JZ 2312 01	Leg Guard	1	1	
2	JZ 2312 02	Saree Guard	1	1	
3	39 1556 04	Flange Bolt	2	2	
4	DS 1611 88	Grab Handle with Foam	1	1	
5	39 1681 04	Flange Bolt	4	4	
6	DJ 1610 79	Foam LH	1	1	
7	DJ 1610 80	Foam RH	1	1	
8	JZ 2312 04	Small Saree Guard	1	1	
9	39 2495 04	Socket Head Bolt	1	1	
10	JA 1134 04	Flange Bolt	1	1	
11	39 1970 15	Hex Nut	1	1	
12	39 2553 04	Bolt Flange	1	1	
13	DS 2210 01	Plug	1	1	

Tool Kit




No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	DJ 2210 19	Tool Kit	1	1	
2	DP 2210 11	Band Tool Kit	1	1	

Painted Parts and Decals



No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
1	52 JZ15 16	Fuel Tank with BI Blue Decal	1	1	
	52 JZ15 17	Fuel Tank with BI Red Decal	1	1	
	52 JZ15 19	Fuel Tank with FI Red Decal	1	1	
	52 JZ15 20	Fuel Tank with EI Blue Decal	1	1	
2	52 JZ09 46	Side Cover LH BI Blue	1	1	
	52 JZ09 47	Side Cover LH BI Red	1	1	
	52 JZ09 48	Side Cover LH EI Blue	1	1	
	52 JZ09 49	Side Cover LH FI Red	1	1	
3	52 JZ09 50	Side Cover RH BI Blue	1	1	
	52 JZ09 51	Side Cover RH BI Red	1	1	
	52 JZ09 52	Side Cover RH EI Blue	1	1	
	52 JZ09 53	Side Cover RH FI Red	1	1	
4	52 JZ09 38	Seat Cowl BI Blue	1	1	
	52 JZ09 39	Seat Cowl BI Red	1	1	
	52 JZ09 40	Seat Cowl EI Blue - Blue	1	1	
	52 JZ09 41	Seat Cowl FI Red - Red	1	1	
5	PA 7201 3F	Fender Front FI Red	1	1	
	56 JZ05 3E	Fender Front EI Blue	1	1	
	PA 7201 3B	Fender Front Black	1	1	
6	52 JZ09 26	Head Lamp Cowling BI Blue	1	1	
	52 JZ09 27	Head Lamp Cowling BI Red	1	1	
	52 JZ09 28	Head Lamp Cowling Elec Blue- Blue	1	1	
	52 JZ09 29	Head Lamp Cowling FI Red with Red	1	1	
7	36 JZ01 47	Kit Tank Decal BI Blue	1	1	
	36 JZ01 48	Kit Tank Decal BI Red	1	1	
	36 JZ01 49	Kit Tank Decal Elec Blue with Blue	1	1	
	36 JZ01 50	Kit Tank Decal FI Red with Red	1	1	

Painted Parts and Decals



No.	Part No.	Description	DIS 125		Remarks
			DRUM	DISC	
8	36 JZ01 52	Kit Fairing Decal BI Blue	1	1	
	36 JZ01 53	Kit Fairing Decal BI Red	1	1	
	36 JZ01 54	Kit Fairing Decal Elec Blue - Blue	1	1	
	36 JZ01 55	Kit Fairing Decal FI Red with Red	1	1	
9	36 JZ01 60	Kit Cover Side Decal BI Blue	1	1	
	36 JZ01 61	Kit Cover Side Decal BI Red	1	1	
	36 JZ01 62	Kit Cover Side Decal EI Blue	1	1	
	36 JZ01 63	Kit Cover Side Decal FI Red-Red	1	1	
10	36 JZ01 56	Kit Seat Cowl Decal BI Blue	1	1	
	36 JZ01 57	Kit Seat Cowl Decal BI Red	1	1	
	36 JZ01 58	Kit Seat Cowl Decal EI Blue - Blue	1	1	
	36 JZ01 59	Kit Seat Cowl Decal FI Red - Red	1	1	
11	JZ 2334 95	Discover 3D Decal	2	2	

Consumable Parts

1		2		3	
4		5		6	
7		8		9	
10		11		12	

No.	Part No.	Description	Supply Unit	Application
1	36 0010 61 83 0204 11 83 0203 34	Bajaj Genuine Oil 10W50 Bajaj Genuine Oil 10W30 Bajaj Genuine Oil 20W50 (BGO to be ordered to HPCL)	1.5 Ltr. 1 Ltr. 1 Ltr.	Dominar 400 100cc Models 125cc and above models
2	36 0010 58	Bajaj Coolant Koolex	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61 83 0203 25	Brake Fluid DOT4 Brake Fluid DOT3	100 ml 100 ml	Disc Brake Top-up/Replace Disc Brake Top-up/Replace
4	36 0010 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 83 0203 68	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 0010 52	HP Lithon RR Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04	Fork oil	160 ml	Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

Consumable Parts

13		14		15	
16		17		18	
19		20		21	
22		23		24	

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray		For Cleaning Carburetor
24	37 2540 39	Corrosion Protection Spray Proto quick LTP902 (To be ordered on Vendor)	--	For Preventing vehicle parts from rusting

Kit List

Discover 125 BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JE0002	Piston Ring Set (For D125)	JE521202 JE521203 JE521204	Ring Piston Top Ring Piston Second Ring Piston Oil	1 1 1
2	36JZ0005	Piston Ring Set	JZ521204 JZ521205 JZ521206	Ring Piston Top Ring Piston Second Ring Piston Oil	1 1 1
3	36JZ0023	Set Primary Drive & Driven (For D125)	PF551401 JZ531006	Housing Complete Clutch Gear Primary Drive	1 1
4	36JZ0014	Set Primary Drive & Driven	JZ551410 JZ531006	Housing Complete Clutch Gear Primary Drive	1 1
5	36JZ0031	Jet Kit For (For D125)	JZ581234 JZ581230 JZ581231 JZ581233	Needle Jet Holder Needle Jet Jet Main Jet Pilot	1 1 1 1
6	36JZ0017	Jet Kit	JZ581213 JZ581219 JZ581218 JZ 581214	Needle Jet Holder Needle Jet Jet Main Jet Pilot	1 1 1 1
7	36JZ0026	Chain Sprocket Kit (D125)	DJ151086 JZ551004 JZ141003	Sprocket Hub (43T) Sprocket Drive (14T) Chain 120 Link - 428 Series	1 1 1
8	36JZ0007	Chain Sprocket Kit	DJ151086 JZ551004 DS151082	Sprocket Hub (43T) Sprocket Drive (14T) Chain 120 Link - 420 Series	1 1 1
9	36JZ0001	Valve Kit	JZ511200 JZ511201	Valve Intake Valve Exhaust	1 1
10	36JZ0004	Valve Repair Kit	39201719 DG101029 JA511203 28101129 JZ511202	Seat Valve Stem Cotter Valve Retainer Valve Spring Seat Valve Spring Spring Washer	2 2 2 2 2
11	36JE0003	Kit Guide Cam Chain	JW541012 JA521002	Guide Cam Chain (Slack Side) Guide Cam Chain (Tight Side)	1 1
12	DH121169	Pilot Screw Kit	DH121131 DH121130 DH121186 DH121187 DH121188	Screw Adjuster 'O' - Ring Spring Compr Coil Plain Washer 'O' - Ring	1 1 1 1 1
13	36JZ0019	Throttle Valve Kit	JZ581221	Valve Piston	1

Kit List

Discover 125 BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			DD121054 JZ581222 DD121055 JZ581215 JZ581222 24121370	E-Ring Holder Spring Compression Packing Jet Needle Ring	1 1 1 1 1 1
14	36JZ0032	Throttle Valve Kit D125	JZ581232 DD121054 JZ581211 DD121055 JZ581223 JZ581222 24121370	Valve Piston E-Ring Holder Spring Compression Packing Jet Needle Ring	1 1 1 1 1 1 1
15	36JZ0016	Idling Screw Kit	JZ581217 DH121130 CB121044	Screw Stop 'O' - Ring Spring Compression	1 1
16	36DS2101	Seat Damper Kit	DS211004 DS211005	Damper Seat - I Damper Seat - II	7 2
17	36311401	Bearing Cone Kit	DH181025 DH181026 DH181024	Bearing cone Bearing race Upper bearing race	1 1 1
18	36DS1801	Holder Handle Set	DS181019 DS181006	Holder Handle Holder Handle	2 2
19	36DS1401	Grommet Kit - Side Cover	DS141012 DS161082	Grommet Side Cover Front Grommet Side Cover Rear	2 2
20	36DS4020	Case Chain Kit	DS161269 DS161270	Case Chain Upper Assy. Case Chain Lower Assy.	1 1
21	36JZ0021	Carb. Gasket- 'O' Ring Kit	JA581232 DH121130 JA581240 DH121118 JA581238	Gasket Float Chamber 'O' - Ring Idling Screw 'O' - Ring Auto Choke 'O' Ring Drain screw 'O' Ring TPS	1 2 1 1 1
22	36DU1007	Boss Kick Set	30101233 30101234 30101236 30101235 39085517	Boss Kit Spring Ball Steel Pin E - Type Clip	1 1 1 1 1
23	36JZ0008	Starter Clutch Repair Kit	JA621411 DH101163 DH101164 DJ101109	Bush Spring Starter Clutch Roller Clutch Spring Bush For Spring Starter Clutch	5 5 5 5

Kit List

Discover 125 BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
24	36JZ0020	Cable Adjuster Kit	JA581315 JA581261 JZ531215	Nut Cable Adjuster Mixing Cap Assembly	1 1 1
25	36JE0005	Friction Plate Kit	DP101110 DP101109	Plate Friction Plate Friction	4 1
26	36JZ0037	Kit Friction Plate Disco 125	Jz551416	Plate Friction	5
27	36JZ0164	Kit Chain Case-Jz131071+72	JZ181371 JZ181372	Assembly Chain Case Lower Assembly Chain Case Upper	1 1
28	36JZ0165	Kit Cyl Head-D125 Sil	JZ511031 JA511028 31101064	Cylinder Head Machined D125 2V Stud M8X1.25X45L Plug	1 2 1
29	36JZ0166	Kit Cyl Bl-Piston-125 Sil	JE521008 JZ521207	Cylinder Block With Damper Assembly Piston Disco-125	1 1
30	36JZ0167	Kit Assly C'Case Lh	39256220 JZ541029 JA541036 JZ541005 JA541005	Bearing - Needle Roller Crankcase Lh D125 2V Plug (Oil Control) Nozzle Oil Jet Bush Bendix	1 1 1 1 1
31	36JZ0168	Kit Assly C'Case Rh	JA541015 JZ541031 JA541011 31101064 PF541018	Stud Inhibitor Mounting Crankcase Rh D125 2V Needle Roller Bearing Hk1212 Plug Bushing Drum Bm150 4 Spd	1 1 1 1 1
32	36JZ0182	Kit Assly Cy Head	JZ511032 JA511028	Cylinder Head Stud	1 2

Kit List

Discover 125 BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

Discover 125 BS/IV

[illegible]

Discover 125 BS IV

[illegible]

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
15 1610 69	2	94	30 1511 18	20	72
15 1910 26	11	78	30 1810 09	11	84
20 2010 29	22	102	30 1810 25	4	84
22 1502 41	4	32	30 1810 28	3	84
24 1210 69	12	34	30 1810 29	20	84
24 1213 65	7	34	30 1910 35	10	78
30 1010 96	6	30	30 1910 36	12	78
30 1011 42	4	26	30 1910 38	7	78
30 1011 95	8	28	30 1910 48	20	80
30 1410 31	9	58	30 1910 48	18	104
30 1510 04	11	72	30 1910 67	5	92
30 1510 05	21	74	30 2010 64	19	104
30 1510 11	19	74	31 1011 73	3	14
30 1510 32	6	72	31 1610 18	9	88
30 1510 33	1	66	31 2010 01	7	100
30 1510 33	5A	72	31 2010 01	3	102
30 1510 35	10	72	31 2010 79	4	104
30 1510 35	23	72	31 2010 81	5	24
30 1510 38	13	72	35 1610 60	6	96
30 1510 38	20	74	36 3140 02	5	52
30 1510 41	6	66	36 3140 05	4	52
30 1510 41	21	72	36 DH40 14	21	78
30 1510 42	24	72	36 DJ40 31	1	68
30 1510 68	8	72	36 DJ40 33	10	70
30 1510 68	17	74	36 DK00 09	11	40
30 1510 69	9	72	36 DS14 01	1	88
30 1510 69	16	74	36 DS18 01	11	80
30 1510 75	13	74	36 DU10 07	3	32
30 1510 96	18	78	36 DU15 04	18	66

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 DZ00 20	2	84	36 JZ01 59	10	112
36 JE00 02	3	12	36 JZ01 60	9	112
36 JE00 03	6	10	36 JZ01 61	9	112
36 JZ00 01	4	8	36 JZ01 62	9	112
36 JZ00 04	5	8	36 JZ01 63	9	112
36 JZ00 08	6	44	36 JZ01 66	5	12
36 JZ00 16	5	34	36 JZ01 67	1	24
36 JZ00 20	2	34	36 JZ01 68	2	22
36 JZ00 22	13	86	36 JZ01 82	1	6
36 JZ00 23	7	14	36 PD00 45	11	70
36 JZ00 23	16	30	39 0071 04	10	36
36 JZ00 26	2	74	39 0198 11	8	78
36 JZ00 31	4	34	39 0211 11	7	60
36 JZ00 32	11	34	39 0219 11	25	96
36 JZ00 37	4	30	39 0242 11	15	60
36 JZ00 38	4	90	39 0258 11	4	54
36 JZ00 39	3	90	39 0292 15	16	54
36 JZ00 40	18	84	39 0326 15	11	60
36 JZ01 47	7	110	39 0422 15	9	62
36 JZ01 48	7	110	39 0454 11	11	54
36 JZ01 49	7	110	39 0454 11	9	96
36 JZ01 50	7	110	39 0553 02	10	54
36 JZ01 52	8	112	39 0594 17	12	10
36 JZ01 53	8	112	39 0694 15	16	78
36 JZ01 54	8	112	39 0705 01	14	102
36 JZ01 55	8	112	39 0711 11	15	102
36 JZ01 56	10	112	39 0722 11	19A	74
36 JZ01 57	10	112	39 0738 17	6	32
36 JZ01 58	10	112	39 0740 11	7	86

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 0740 11	17	102	39 1001 20	20	26
39 0746 01	18	102	39 1001 20	15	30
39 0747 01	9	24	39 1013 21	25	72
39 0775 04	15	72	39 1040 11	10	58
39 0784 08	7	58	39 1041 19	3	26
39 0789 12	8	54	39 1054 11	7	88
39 0789 12	15	78	39 1075 04	3	60
39 0789 12	13	84	39 1181 01	14	84
39 0797 08	3	62	39 1225 15	6	100
39 0798 15	6	60	39 1283 21	12	6
39 0798 15	17	72	39 1309 11	16	102
39 0798 15	9	90	39 1358 15	13	54
39 0798 15	33	98	39 1507 11	11	104
39 0801 15	3	74	39 1508 11	32	98
39 0807 08	17	78	39 1508 11	35	98
39 0808 08	9	78	39 1540 11	19	78
39 0840 01	18	72	39 1551 04	25	104
39 0900 12	19	72	39 1553 04	6	102
39 0980 04	10	30	39 1556 04	3	50
39 0983 08	6	88	39 1556 04	3	106
39 0987 17	3	16	39 1671 21	17	26
39 0992 06	2	18	39 1673 04	19	26
39 0993 11	5	32	39 1675 04	3	46
39 0999 06	12	24	39 1680 04	3	78
39 0999 06	21	26	39 1681 04	5	106
39 0999 06	4	42	39 1714 04	13	80
39 1000 06	2	12	39 1715 19	4	24
39 1000 06	6	22	39 1759 04	17	24
39 1000 06	11	24	39 1765 11	11	36

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 1778 02	10	96	39 2141 24	31	98
39 1779 02	15	36	39 2179 24	3	86
39 1783 01	11	102	39 2190 19	7	24
39 1789 24	5	88	39 2208 04	12	104
39 1850 04	9	40	39 2238 01	7	96
39 1864 20	5	14	39 2240 20	6	74
39 1880 20	16	10	39 2249 15	18	80
39 1902 04	11	20	39 2295 15	3	40
39 1902 04	6	48	39 2408 17	12	32
39 1907 01	30	98	39 2420 01	16	60
39 1942 04	21	104	39 2427 04	28	82
39 1942 04	25	104	39 2443 11	9	26
39 1943 04	12	46	39 2447 04	23	74
39 1943 04	9	60	39 2476 04	8	102
39 1943 04	3	88	39 2492 11	8	40
39 1943 04	20	96	39 2495 04	9	106
39 1943 04	28	98	39 2539 21	8	6
39 1943 04	10	100	39 2553 04	12	106
39 1945 04	2	104	39 2562 20	2	24
39 1961 04	29	98	39 2567 11	4	74
39 1964 04	12	22	39 2600 11	3	30
39 1970 15	5	50	39 2608 01	10	6
39 1970 15	11	106	39 2629 21	11	6
39 2017 19	6	8	39 2669 21	13	10
39 2060 04	9	52	39 2683 20	15	10
39 2060 04	18	54	39 2686 20	12	74
39 2060 04	26	98	39 2687 20	15	74
39 2124 15	4	102	39 2688 20	5	72
39 2141 24	3	96	39 2722 04	8	58

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 2723 15	2	50	56 JZ05 3E	5	110
39 2726 12	8	54	56 JZ2Y 7D	1	64
39 2754 04	7	40	56 JZ2Z 7D	1	64
52 JA00 28	14	30	56 JZ3A 7D	4	64
52 JA00 29	10	22	59 0100 05	23	96
52 JE00 17	1	28	59 0400 14	15	46
52 JE00 18	1	26	59 0400 25	2	32
52 JZ02 64	1	20	59 0400 38	2	2
52 JZ09 26	6	110	59 0400 38	9	22
52 JZ09 27	6	110	59 0400 38	16	24
52 JZ09 28	6	110	59 0400 38	14	26
52 JZ09 29	6	110	59 0400 38	4	28
52 JZ09 38	4	110	59 0400 50	8	2
52 JZ09 39	4	110	59 1100 08	2B	14
52 JZ09 40	4	110	59 1200 03	2A	14
52 JZ09 41	4	110	59 1500 03	13	66
52 JZ09 46	2	110	59 1500 03	1	72
52 JZ09 47	2	110	59 1500 14	1	14
52 JZ09 48	2	110	59 2000 36	3	22
52 JZ09 49	2	110	59 2000 36	3	24
52 JZ09 50	3	110	59 2100 23	18	24
52 JZ09 51	3	110	59 2100 24	17	16
52 JZ09 52	3	110	AP 1012 55	2	86
52 JZ09 53	3	110	BF 5612 19	7	20
52 JZ09 60	1	94	CB 1210 39	8	34
52 JZ15 16	1	110	CB 2010 26	14	104
52 JZ15 17	1	110	CL 2010 23	12	96
52 JZ15 19	1	110	CL 2010 42	7	90
52 JZ15 20	1	110	CS 1011 28	9	10

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DD 1010 62	10	10	DG 1611 21	2	88
DD 1010 97	13	32	DG 1910 45	4	78
DD 1110 11	10A	46	DH 1010 48	5	10
DD 1110 12	11	46	DH 1013 80	8	22
DD 1110 18	8	46	DH 1013 80	4	46
DD 1110 48	9	46	DH 1013 92	7	10
DD 1211 81	16	26	DH 1015 09	9	20
DD 1412 27	6	86	DH 1017 81	2	44
DD 1510 09	14	72	DH 1017 84	6	24
DD 1610 71	12	40	DH 1110 13	10B	46
DD 1613 81	5	58	DH 1110 15	9	46
DD 1911 42	30	82	DH 1210 38	7	6
DD 2010 11	2	102	DH 1210 38	12	36
DE 1510 06	3	66	DH 1211 69	3	34
DE 1510 08	5	66	DH 1510 29	14	78
DE 1510 12	4	66	DH 1510 39	2	70
DE 1510 43	7	70	DH 1610 66	7	62
DE 1510 45	8	70	DH 1611 00	6	58
DE 1510 46	4	70	DH 1611 21	4	62
DE 1510 47	5	70	DH 1611 45	5	62
DE 1510 48	3	70	DH 1611 46	11	62
DF 1611 02	8	62	DH 1611 55	14	40
DF 1614 13	4	56	DH 1611 57	13	40
DG 1010 29	3	8	DH 1611 58	13	60
DG 1014 18	7	26	DH 1611 94	5	56
DG 1210 02	7	2	DH 1612 31	11	88
DG 1210 02	8	36	DH 1612 33	7	48
DG 1210 03	9	4	DH 1612 83	3	94
DG 1210 40	16	38	DH 1614 29	17	38

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DH 1810 14	3	52	DJ 1910 83	6	80
DH 1810 22	27	82	DJ 2010 72	13	102
DJ 1410 08	8	88	DJ 2011 08	17	68
DJ 1510 33	11	74	DJ 2011 09	12	68
DJ 1510 35	5	74	DJ 2011 73	17	60
DJ 1510 36	14	54	DJ 2012 06	3	100
DJ 1510 37	15	54	DJ 2012 07	4	100
DJ 1510 47	19	54	DJ 2210 03	9	80
DJ 1610 69	10	60	DJ 2210 04	10	80
DJ 1610 72	5	102	DJ 2210 19	1	108
DJ 1610 79	6	106	DK 1013 86	4	10
DJ 1610 80	7	106	DK 1410 41	12	86
DJ 1611 22	4	58	DK 1510 94	14	74
DJ 1611 28	11	58	DL 1510 14	22	72
DJ 1611 29	3	58	DL 1910 14	19	80
DJ 1710 33	27	76	DL 1910 20	8	90
DJ 1811 04	6	84	DP 1011 65	4	12
DJ 1910 25	4	68	DP 1012 69	6	26
DJ 1910 26	5	68	DP 1611 44	9	102
DJ 1910 27	6	68	DP 1611 45	7	102
DJ 1910 28	7	68	DP 1612 60	7	52
DJ 1910 29	8	68	DP 1710 06	6	52
DJ 1910 30	9	68	DP 2210 11	2	108
DJ 1910 31	10	68	DS 1011 17	8	32
DJ 1910 34	13	68	DS 1011 54	6	14
DJ 1910 35	14	68	DS 1012 15	8	26
DJ 1910 38	15	68	DS 1012 76	3	10
DJ 1910 58	11	68	DS 1013 55	20	16
DJ 1910 59	3	68	DS 1099 05	14	10

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DS 1211 16	2	36	DS 1810 08	15	80
DS 1211 26	7	36	DS 1810 09	16	80
DS 1410 13	9	86	DS 1810 10	17	80
DS 1510 25	13	78	DS 1810 12	7	84
DS 1510 29	6	64	DS 1810 15	8	84
DS 1510 31	5	64	DS 1810 16	9	84
DS 1510 38	7	66	DS 1810 18	2	52
DS 1510 48	2	64	DS 1810 44	1	80
DS 1510 49	3	64	DS 1810 60	11	90
DS 1510 52	5	64	DS 1910 07	5	104
DS 1510 53	6	64	DS 1910 11	5	78
DS 1510 56	3	72	DS 1910 15	5	80
DS 1510 58	11	66	DS 1910 16	26	82
DS 1510 68	7	74	DS 1910 18	12	80
DS 1510 69	18	74	DS 1910 38	31	82
DS 1510 73	8	74	DS 1910 52	8	80
DS 1610 35	10	88	DS 1910 53	1	92
DS 1610 69	13	36	DS 1910 54	4	92
DS 1610 77	6	62	DS 2010 79	8	86
DS 1611 12	2	62	DS 2010 81	7	104
DS 1611 13	1	62	DS 2110 06	5	48
DS 1611 25	1	60	DS 2110 07	2	48
DS 1611 88	4	106	DS 2210 01	13	106
DS 1612 87	5	60	DU 1012 13	19	16
DS 1710 07	9	54	DU 2010 46	24	80
DS 1710 13	12	54	DX 1210 11	5	36
DS 1710 14	17	54	DX 1510 22	25	76
DS 1710 15	6	54	DX 1610 32	8	104
DS 1810 07	14	80	DX 1610 44	9	104

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DX 1610 45	10	104	JA 5410 27	19	24
DX 1610 52	4	94	JA 5410 28	14	46
DX 1910 01	25	80	JA 5410 34	10	24
DX 1910 09	29	82	JA 5412 05	3	28
FD 1010 78	3	42	JA 5412 11	11	26
GF 2010 53	15	104	JA 5412 12	13	26
GH 2010 12	5	100	JA 5412 25	12	26
GL 1710 36	11	38	JA 5412 33	7	28
JA 1134 03	1	50	JA 5510 02	4	16
JA 1134 04	6	50	JA 5510 04	7	16
JA 1134 04	10	106	JA 5510 08	15	16
JA 1316 05	12	72	JA 5510 09	16	16
JA 1316 06	7	72	JA 5514 06	2	30
JA 1316 07	16	72	JA 5514 20	12	30
JA 1510 13	5	84	JA 5812 21	6	34
JA 1610 03	1	78	JA 5812 32	16	34
JA 5110 08	4	2	JA 5813 14	13	34
JA 5110 28	2	6	JA 5814 06	5	6
JA 5112 11	1	8	JA 6210 02	9	32
JA 5112 16	2	10	JA 6210 06	11	32
JA 5210 15	7	12	JA 6212 01	1	32
JA 5310 12	8	14	JA 6214 02	4	44
JA 5310 15	9	14	JA 6214 06	5	44
JA 5410 05	8	24	JA 6214 14	1	44
JA 5410 05	6	28	JB 1130 05	10	40
JA 5410 10	5	22	JB 1220 09	7	54
JA 5410 11	4	22	JB 1220 10	2B	54
JA 5410 12	11	22	JB 1220 11	2A	54
JA 5410 16	2	42	JB 1220 16	1	54

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JB 1310 17	12	66	JD 5612 04	5	20
JB 1310 17	1A	72	JD 6210 01	7	32
JB 1310 18	10	66	JE 3514 03	6	12
JB 1310 18	2	72	JE 5110 67	4	4
JB 1310 22	4	72	JE 5410 08	14	32
JB 1814 03	12	60	JE 5412 08	18	26
JB 1814 16	2	60	JE 5412 11	2	26
JB 1814 21	2	60	JE 5412 12	10	28
JB 4014 00	2	80	JE 5412 14	10	26
JB 5110 18	9	6	JE 5512 01	5	16
JB 5310 21	10	14	JE 5512 06	11	16
JB 5514 06	9	30	JE 5514 09	13	30
JB 5514 08	5	30	JE 5610 05	7	18
JB 5514 11	7	30	JE 5810 39	2	4
JB 5910 59	6	40	JE 5910 02	2	40
JB 5910 68	15	40	JG 4018 08	22	104
JD 1138 14	13	4	JG 5710 24	13	24
JD 1138 15	12	4	JH 1710 17	8A	86
JD 3512 06	16	46	JH 1710 47	23	104
JD 4018 03	20	104	JH 1710 48	5	38
JD 4022 17	32	82	JH 1710 49	16	86
JD 5110 08	3	6	JH 5210 05	8	10
JD 5110 10	3	2	JH 5614 04	10	20
JD 5210 02	1	12	JH 5822 00	1	4
JD 5310 04	11	14	JH 5826 01	16	4
JD 5514 00	17	30	JH 5826 02	18	4
JD 5610 04	5	18	JK 1210 07	17	84
JD 5610 06	4	18	JK 1210 09	19	84
JD 5610 11	3	18	JK 3516 00	13	104

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JK 4020 00	13	46	JV 5410 06	15	24
JK 4022 05	16	104	JV 5412 08	5	26
JL 4020 04	6	104	JV 5412 09	15	26
JN 1132 00	10	62	JW 1318 01	1	70
JN 1220 00	3	54	JW 1318 01	12	70
JN 1220 06	5	54	JW 1318 05	2	68
JN 1312 11	24	74	JW 1318 06	9	66
JN 1318 04	16	68	JW 1318 07	6	70
JN 1710 00	4	88	JW 1318 09	9	70
JN 1810 01	1	96	JW 1510 23	18	84
JN 1810 03	16	96	JW 1812 41	14	66
JN 1810 04	24	96	JW 2330 00	9	28
JN 1810 05	11	96	JW 4010 11	12	102
JN 1810 10	5	96	JW 5612 06	2	20
JN 1810 11	5	96	JW 5612 08	3	20
JN 1810 14	12	90	JW 5910 28	5	40
JN 1810 17	17	96	JY 1710 69	2	38
JN 1810 18	18	96	JY 1710 70	9	38
JN 1810 19	14	96	JY 1710 77	1	38
JN 1810 19	34	98	JY 1710 90	4	38
JN 1810 21	19	96	JY 1718 25	13	38
JN 1810 23	21	96	JY 5810 28	8	4
JN 1810 24	22	96	JZ 1112 78	1	52
JN 1812 11	15	66	JZ 1130 01	1	56
JN 1814 06	13	90	JZ 1130 11	3	56
JN 2328 01	10	102	JZ 1130 15	1	58
JP 3510 07	2	46	JZ 1130 17	2	58
JV 3516 00	7	44	JZ 1134 00	8	50
JV 4022 05	17	104	JZ 1134 02	10	50

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JZ 1134 03	9	50	JZ 1718 22	11	86
JZ 1134 05	11	50	JZ 1810 03	4	96
JZ 1134 07	12	50	JZ 1810 04	13	96
JZ 1210 55	1	84	JZ 1810 04	19	102
JZ 1210 56	1	84	JZ 1812 00	2	90
JZ 1210 57	21	84	JZ 1812 06	2	96
JZ 1210 58	22	84	JZ 1812 08	27	98
JZ 1210 59	15	84	JZ 1814 02	4	60
JZ 1210 60	16	84	JZ 1814 06	14	60
JZ 1210 61	21	84	JZ 1814 60	24	104
JZ 1210 62	22	84	JZ 1910 10	4	48
JZ 1210 63	15	84	JZ 1910 11	3	48
JZ 1210 64	16	84	JZ 1910 30	1	48
JZ 1316 11	19	66	JZ 2312 01	1	106
JZ 1318 91	22	74	JZ 2312 02	2	106
JZ 1410 03	1	74	JZ 2312 04	8	106
JZ 1510 23	23	80	JZ 2326 00	5	86
JZ 1510 23	10	84	JZ 2326 01	21	80
JZ 1510 24	9	100	JZ 2326 01	1	86
JZ 1510 36	12	84	JZ 2326 01	5	86
JZ 1610 04	6	78	JZ 2328 05	20	102
JZ 1610 06	20	78	JZ 2334 95	11	112
JZ 1610 23	4	80	JZ 3510 01	1	46
JZ 1612 03	2	92	JZ 3512 14	7	46
JZ 1612 10	1	92	JZ 4010 00	1	100
JZ 1612 21	3	92	JZ 4010 01	2	100
JZ 1710 20	14	86	JZ 4010 12	8	96
JZ 1710 21	15	86	JZ 4010 15	15	96
JZ 1718 09	4	86	JZ 4010 45	1	102

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JZ 4010 46	21	102	JZ 5610 02	6	18
JZ 4014 03	7	80	JZ 5614 15	8	20
JZ 4014 08	3	80	JZ 5710 00	1	42
JZ 4016 00	1	104	JZ 5710 01	5	42
JZ 4022 64	3	104	JZ 5810 04	6	2
JZ 4024 03	1	90	JZ 5810 04	9	36
JZ 4024 06	3	90	JZ 5810 06	14	36
JZ 4024 07	4	90	JZ 5810 10	3	36
JZ 5010 13	1	22	JZ 5810 11	4	36
JZ 5110 04	1	10	JZ 5810 12	6	36
JZ 5110 29	1	2	JZ 5810 29	17	36
JZ 5112 03	2	8	JZ 5810 54	15	4
JZ 5310 07	4	14	JZ 5810 55	16	36
JZ 5412 35	5	28	JZ 5810 56	1	36
JZ 5510 04	18	16	JZ 5812 10	6	6
JZ 5510 08	8	16	JZ 5812 16	15	34
JZ 5510 10	1	16	JZ 5812 20	14	34
JZ 5512 00	6	16	JZ 5812 41	1	34
JZ 5512 02	2	16	JZ 5814 07	4	6
JZ 5512 04	14	16	JZ 5824 00	7	4
JZ 5512 05	13	16	JZ 5824 01	10	4
JZ 5512 06	9A	16	JZ 5824 04	6	4
JZ 5512 08	12	16	JZ 5824 05	3	4
JZ 5512 10	9	16	JZ 5910 43	4	40
JZ 5512 11	10	16	JZ 6210 00	10	32
JZ 5512 13	5A	16	JZ 6214 05	3	44
JZ 5514 13	1	30	KA DD08 20	6	56
JZ 5514 14	18	30	KA DF06 30	11	4
JZ 5514 15	8	30	KA ED06 20	11	10

Parts Index

Discover 125 BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KA ED06 20	8	44	PA 1718 08	12	38
KA ED06 40	2	28	PA 1718 10	14	38
KA EG06 14	5	4	PA 1814 26	8	60
KB RA42 19	17	4	PA 3512 01	5	46
KC GA05 05	10	86	PA 3512 02	6	46
KC GA06 06	14	4	PA 4024 03	5	90
KD CB08 16	7	56	PA 4024 04	6	90
KP BB62 02	6	74	PA 4024 05	10	90
KP BB63 01	2	66	PA 4024 10	14	90
KP BB63 02	15	74	PA 4024 11	15	90
LA C000 02	8	66	PA 4024 12	16	90
LA D000 26	8	100	PA 4024 13	17	90
LA D000 41	7	50	PA 4024 14	14	90
LA D000 52	4	50	PA 4024 15	15	90
LA D001 26	2	56	PA 4024 16	16	90
LA E000 21	22	80	PA 4024 17	17	90
LB U000 04	16	66	PA 4024 19	5	90
LB U000 05	17	66	PA 4024 20	6	90
LC B000 05	9	74	PA 5110 39	5	2
LD B000 01	26	76	PA 5610 00	1	18
LD B000 44	6	20	PA 5612 09	4	20
LJ A000 04	14	24	PA 7201 3B	5	110
PA 1138 00	8	52	PA 7201 3F	5	110
PA 1610 12	2	78	PD 1716 16	6	38
PA 1716 05	10	38	PF 1312 20	10	74
PA 1716 07	8	38	PF 1716 01	1	86
PA 1716 09	15	38	PF 5410 18	7	22
PA 1716 10	3	38	PF 5514 01	11	30
PA 1716 11	7	38	YJ Z280 01	1	40