

DOMINAR
400

BAJAJ
MOTORCYCLES

DOMINAR
400

Bajaj Auto Limited
Akurdi Pune 411 035 India
Tel +91 20 27472851
Fax +91 20 27407385
www.bajajauto.com
CIN L65993PN2007PLC130076

Spare Parts Catalogue



Notice



All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71112643

REV. 06, JUNE 17

Copy rights : All rights reserved. No part of this publicatin may be reproduced, stored in a retrival system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

Foreword



We have pleasure in presenting the Spare Parts Catalogue for 'Dominar 400' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instructions



- 1. How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

- 2. How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

- 3. Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

- 4. Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

JOMINR
400

[illegible]

DOMINAR 400

[illegible]

DOMINAR
400

DOMINAR 400

Index



Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Valve	6 - 10
4	Camshaft & Tensioner	12
5	Cylinder & Piston	14
6	Crankshaft	16
7	Transmission	18
8	Change Drum / Shift Fork	20
9	Gear Change Mechanism	22
10	Engine Assembly / Crankcase RH	24
11	Crankcase LH	26 - 28
12	Balancer Idler Gear & Water Pump	30
13	Oil Pump & Evacuation Pump	32
14	Cooling System	34 - 36
15	Cover Clutch	38
16	Cover Magneto	40
17	Clutch Assembly	42
18	Throttle Body & Sensors	44
19	Air Cleaner Assembly	46
20	Silencer Assembly & Belly Pan	48
21	Starter Assembly	50
22	Magneto, Regulator & ECU	52
23	H.T. Coils	54
24	Seat Assembly & Seat Lock	56
25	Engine Mountings	58
26	Frame & Frame Fittings	60
27	Swing Arm & Rear Shock Absorber	62
28	Pillion Foot Rest	64
29	Front Fender	66
30	Side Stand Assembly	68
31	Tubeless Tyre & Rim	70

Index



Plate No.	Description	Page No.
32	Front Hub	72
33	Master Cylinder - Front Disc Brake	74
34	Caliper Assembly - Front Disc Brake	76
35	Anti Brake Lock System	78
36	Rear Disc Brake Assembly	80
37	Rear Hub	82
38	Rear Brake Pedal	84
39	Handle Bar Assembly	86
40	Front Fork	88 - 90
41	Petrol Tank, Cap Tank & Gauge Fuel	92
42	EVAP Mechanism	94
43	Fitting - Petrol Tank Cover	96
44	Fitting - Side Covers, Seat Cowls & Under Tray Front	98
45	Speedometer Assembly	100
46	Control Cables & Chain Case	102
47	Head Lamp Assembly & Front Number Plate	104
48	Indicator Light Assembly	106
49	Tail Lamp Assembly & Rear Number Plate	108
50	Electrical Equipments	110 - 112
51	Tool Kit	114
52	Accessories - Mirror, Leg Guards, Grab Handles & Saree Guard	116
53	Painted Parts & Decals	118 - 120
54	Consumable Parts	121 - 124
	Kit List	125 - 128
	Amended Sheet (Parts Added)	129
	Amended Sheet (Parts Deleted)	130
	Part Index	131 - 146

Pictorial Index



PLATE NO. : 1
COVER CYLINDER HEAD

PAGE NO.
1




PLATE NO. : 2
CYLINDER HEAD

PAGE NO.
3




PLATE NO. : 3
VALVE

PAGE NO.
5 - 10




PLATE NO. : 4
CAMSHAFT & TENSIONER

PAGE NO.
11



Pictorial Index



PLATE NO. : 5
CYLINDER & PISTON

PAGE NO.
13




PLATE NO. : 6
CRANKSHAFT ASSEMBLY

PAGE NO.
15



PLATE NO. : 7
TRANSMISSION

PAGE NO.
17





PLATE NO. : 8
CHANGE DRUM / SHIFT FORK

PAGE NO.
19



Pictorial Index



PLATE NO. : 9 GEAR CHANGE MECHANISM	PAGE NO. 21
--	----------------




PLATE NO. : 10 ENGINE ASSEMBLY / CRANKCASE RH	PAGE NO. 23
--	----------------




PLATE NO. : 11 CRANKCASE LH	PAGE NO. 26 - 28
--------------------------------	---------------------





PLATE NO. : 12 BALANCER IDLER GEAR & WATER PUMP	PAGE NO. 29
--	----------------



Pictorial Index



PLATE NO. : 13 OIL PUMP & EVACUATION PUMP	PAGE NO. 33
--	----------------




PLATE NO. : 14 COOLING SYSTEM	PAGE NO. 33 - 35
----------------------------------	---------------------




PLATE NO. : 15 COVER CLUTCH	PAGE NO. 37
--------------------------------	----------------





PLATE NO. : 16 COVER MAGNETO	PAGE NO. 39
---------------------------------	----------------



Pictorial Index



PLATE NO. : 17
CLUTCH ASSEMBLY

PAGE NO.
41




PLATE NO. : 19
AIR CLEANER ASSEMBLY

PAGE NO.
45




PLATE NO. : 18
THROTTLE BODY & SENSORS

PAGE NO.
43





PLATE NO. : 20
SILENCER ASSEMBLY & BELLY PAN

PAGE NO.
48



Pictorial Index



PLATE NO. : 21
STARTER ASSEMBLY

PAGE NO.
49




PLATE NO. : 23
H.T. COILS

PAGE NO.
53




PLATE NO. : 22
MAGNETO, REGULATOR & ECU

PAGE NO.
51





PLATE NO. : 24
SEAT ASSEMBLY & SEAT LOCK

PAGE NO.
55



Pictorial Index



PLATE NO. : 25 ENGINE MOUNTINGS	PAGE NO. 57
------------------------------------	----------------

PLATE NO. : 26 FRAME & FRAME FITTINGS	PAGE NO. 59
--	----------------

PLATE NO. : 27 SWING ARM & REAR SHOCK ABSORBER	PAGE NO. 61
---	----------------

PLATE NO. : 28 PILLION FOOT REST	PAGE NO. 63
-------------------------------------	----------------

Pictorial Index



PLATE NO. : 29 FRONT FENDER	PAGE NO. 65
--------------------------------	----------------

PLATE NO. : 30 SIDE STAND ASSEMBLY	PAGE NO. 67
---------------------------------------	----------------

PLATE NO. : 31 TUBELESS TYRE & RIM	PAGE NO. 69
---------------------------------------	----------------

PLATE NO. : 32 FRONT HUB	PAGE NO. 71
-----------------------------	----------------

Pictorial Index



PLATE NO. : 33 MASTER CYLINDER - FRONT DISC BRAKE	PAGE NO. 73
---	----------------

PLATE NO. : 34 CALIPER ASSEMBLY - FRONT DISC BRAKE	PAGE NO. 75
--	----------------

- PISTON SEAL
- DUST SEAL
- BLEEDER CAP
- PROTECTION BOOT
- INSULATOR
- CALIPER PISTON
- BLEEDER SCREW
- PAD SPRING

PLATE NO. : 35 ANTI BRAKE LOCK - System	PAGE NO. 77
--	----------------

PLATE NO. : 36 REAR DISC BRAKE ASSEMBLY	PAGE NO. 79
--	----------------

- PISTON SEAL
- DUST SEAL
- BLEEDER CAP
- PROTECTION BOOT
- INSULATOR
- CALIPER PISTON
- BLEEDER SCREW
- PAD SPRING

Pictorial Index



PLATE NO. : 37 REAR HUB	PAGE NO. 81
----------------------------	----------------

PLATE NO. : 38 REAR BRAKE PEDAL	PAGE NO. 83
------------------------------------	----------------

PLATE NO. : 39 HANDLE BAR ASSEMBLY	PAGE NO. 85
---------------------------------------	----------------

PLATE NO. : 40 FRONT FORK	PAGE NO. 87 - 89
------------------------------	---------------------

Pictorial Index



PLATE NO. : 41
PETROL TANK, CAP TANK &
GAUGE FUEL

PAGE NO.
91




PLATE NO. : 42
EVAP MECHANISM

PAGE NO.
93




PLATE NO. : 43
FITTING - PETROL TANK COVER

PAGE NO.
95





PLATE NO. : 44
FITTING - SIDE COVERS, SEAT COWLS &
UNDER TRAY FRONT

PAGE NO.
97



Pictorial Index



PLATE NO. : 45
SPEEDOMETER ASSEMBLY

PAGE NO.
99




PLATE NO. : 46
CONTROL CABLES & CHAIN CASE

PAGE NO.
101




PLATE NO. : 47
HEAD LAMP ASSEMBLY &
FRONT NUMBER PLATE

PAGE NO.
103





PLATE NO. : 48
INDICATOR LIGHT ASSEMBLY

PAGE NO.
105



Pictorial Index



PLATE NO. : 49 TAIL LAMP ASSEMBLY & REAR NUMBER PLATE	PAGE NO. 107
---	-----------------

PLATE NO. : 50 ELECTRICAL EQUIPMENTS	PAGE NO. 109 - 111
---	-----------------------

PLATE NO. : 51 TOOL KIT	PAGE NO. 113
----------------------------	-----------------

JG231006	Screw Driver
JG231014	Tool Wrench 22 A/F
JG231003	Spark Plug Spanner
JG231008	Tool Bar
JG231009	Spanner Flat 13 x 14
JG231010	Spanner Flat 08 x 10
JG231011	Key Allen - 5 MM
JG231012	Key Allen - 6 MM
JG231013	Key Allen - 10 MM

PLATE NO. : 52 ACCESSORIES - MIRROR, LEG GUARDS, GRAB HANDLES & SAREE GUARD	PAGE NO. 115
---	-----------------

Pictorial Index




PLATE NO. : 53 PAINTED PARTS & DECALS	PAGE NO. 117 - 119
--	-----------------------

PLATE NO. : 54 CONSUMABLE PARTS	PAGE NO. 121
------------------------------------	-----------------

PLATE NO. : 54 CONSUMABLE PARTS	PAGE NO. 123
------------------------------------	-----------------


--	--

Cover Cylinder Head




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 5110 41	Cover Cylinder Head Comp.	1	1	
2	JF 5110 46	Head Cover Gasket (Rubber)	1	1	
3	LA D001 41	Bolt Flanged (Small Length)	2	2	
4	LA D001 42	Bolt Flanged (Long Length)	2	2	
5	JG 5110 21	Washer	4	4	

Cylinder Head




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	36 JF00 50	Kit Assembly Cylinder Head	1	1	Refer Kit List
2	JG 5110 46	Stud	2	2	
3	LA C001 06	Hex Flange Head Bolt M10	4	4	
4	LA C001 07	Stud Bolt M6	2	2	
5	LD A000 14	Washer	4	4	
6	LD A000 15	Washer	2	2	
7	JF 5110 49	Gasket Cylinder Head	1	1	
8	JG 3514 00	Coolant Water Temp Sensor	1	1	
9	JG 5110 20	'O' Ring	1	1	
10	DK 1012 25	Oil Pressure Switch	1	1	
11	DK 1013 40	'O' Ring	1	1	
12	DT 5814 01	Pipe Intake	1	1	
13	LB C000 03	Screw	3	3	
14	JF 5110 52	Sleeve Spark Plug	1	1	
15	KJ AC18 24	'O' Ring	1	1	
16	39 2608 01	Grub Screw	1	1	
17	39 1568 06	Spring Dowel	2	2	
18	39 1283 21	'O' Ring	1	1	
19	JL 4022 19	Pigtail Oil Pressure Switch	1	1	Not Illustrated.

Valve




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	CB 1010 09	Seal Valve Stem	4	4	Refer Kit List
2	JF 5112 04	Valve Intake	2	2	
3	JF 5112 08	Valve Exhaust	2	2	
4	JF 5112 33	Assembly Rocker Arm Intake	1	1	
5	JF 5112 34	Assembly Rocker Arm Exhaust	1	1	
6	JF 5110 42	Rocker Arm Shaft	2	2	
7	CB 1010 22	Cotter Valve	8	8	
8	36 JF00 58	Kit Valve Repair	1	1	
9	DH 1012 95	Wave Washer	2	2	
10	39 2440 11	Plain Washer	4	4	
11	LJ A000 09	'O' Ring	2	2	
12	LA D001 63	Bolt Flanged	2	2	
13	36 JY00 29	Kit Shim 2 mm	1	1	
14	36 JY00 30	Kit Shim 2.04 mm	1	1	
15	36 JY00 31	Kit Shim 2.08 mm	1	1	
16	36 JY00 32	Kit Shim 2.12 mm	1	1	
17	36 JY00 33	Kit Shim 2.16 mm	1	1	
18	36 JY00 34	Kit Shim 2.20 mm	1	1	
19	36 JY00 35	Kit Shim 2.24 mm	1	1	
20	36 JY00 36	Kit Shim 2.28 mm	1	1	
21	36 JY00 56	Kit Shim 2.30 mm	1	1	
22	36 JY00 37	Kit Shim 2.32 mm	1	1	
23	36 JY00 57	Kit Shim 2.34 mm	1	1	
24	36 JY00 38	Kit Shim 2.36 mm	1	1	
25	36 JY00 58	Kit Shim 2.38 mm	1	1	
26	36 JY00 39	Kit Shim 2.40 mm	1	1	
27	36 JY00 59	Kit Shim 2.42 mm	1	1	
28	36 JY00 40	Kit Shim 2.44 mm	1	1	
29	36 JY00 60	Kit Shim 2.46 mm	1	1	

Valve




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
30	36 JY00 41	Kit Shim 2.48 mm	1	1	
31	36 JY00 61	Kit Shim 2.50 mm	1	1	
32	36 JY00 42	Kit Shim 2.52 mm	1	1	
33	36 JY00 62	Kit Shim 2.54 mm	1	1	
34	36 JY00 43	Kit Shim 2.56 mm	1	1	
35	36 JY00 63	Kit Shim 2.58 mm	1	1	
36	36 JY00 44	Kit Shim 2.60 mm	1	1	
37	36 JY00 64	Kit Shim 2.62 mm	1	1	
38	36 JY00 45	Kit Shim 2.64 mm	1	1	
39	36 JY00 46	Kit Shim 2.68 mm	1	1	
40	36 JF00 89	Kit Shim 2.70 mm	1	1	
41	36 JY00 47	Kit Shim 2.72 mm	1	1	
42	36 JF00 90	Kit Shim 2.74 mm	1	1	
43	36 JY00 48	Kit Shim 2.76 mm	1	1	
44	36 JF00 91	Kit Shim 2.78 mm	1	1	
45	36 JY00 49	Kit Shim 2.80 mm	1	1	
46	36 JF00 92	Kit Shim 2.82 mm	1	1	
47	36 JY00 50	Kit Shim 2.84 mm	1	1	
48	36 JF00 93	Kit Shim 2.86 mm	1	1	
49	36 JY00 51	Kit Shim 2.88 mm	1	1	
50	36 JF00 94	Kit Shim 2.90 mm	1	1	
51	36 JY00 52	Kit Shim 2.92 mm	1	1	
52	36 JF00 95	Kit Shim 2.94 mm	1	1	
53	36 JY00 53	Kit Shim 2.96 mm	1	1	
54	36 JF00 96	Kit Shim 2.98 mm	1	1	
55	36 JY00 54	Kit Shim 3.00 mm	1	1	
56	36 JF00 97	Kit Shim 3.02 mm	1	1	
57	36 JY00 55	Kit Shim 3.04 mm	1	1	

Valve




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
58	36 JF00 98	Kit Shim 3.06 mm	1	1	
59	36 JF00 99	Kit Shim 3.08 mm	1	1	
60	36 JF01 00	Kit Shim 3.10 mm	1	1	
61	36 JF01 01	Kit Shim 3.12 mm	1	1	
62	36 JF01 02	Kit Shim 3.14 mm	1	1	
63	36 JF01 03	Kit Shim 3.16 mm	1	1	
64	36 JF01 04	Kit Shim 3.18 mm	1	1	
65	36 JF01 05	Kit Shim 3.20 mm	1	1	



Camshaft & Tensioner


No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 5112 22	Assembly Camshaft	1	1	Refer Kit List
2	JC 1010 85	Ball Bearing (15 x 32 x 9)	1	1	
3	JC 1010 86	Ball Bearing (15 x 42 x 13)	1	1	
4	KE BB42 17	Circlip Internal	1	1	
5	KH DA03 06	Pin Dowel	1	1	
6	JF 5112 40	Camshaft Collar	1	1	
7	JF 5112 35	Sprocket Camshaft	1	1	
8	JG 5112 69	Bolt Special Flanged	1	1	
9	CS 1011 28	Gasket	1	1	
10	JF 5112 49	Tensioner Assembly	1	1	
11	KA EW06 20	Hex Bolt With Flange	2	2	
12	JF 5112 23	Chain Silent	1	1	
13	36 JF00 55	Kit Chain Guide	1	1	
14	JY 5410 09	Bolt Special Pivot Guide Chain	1	1	

Cylinder & Piston




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	36 JF00 59	Kit Cylinder Block + Piston	1	1	Refer Kit List
2	39 2181 06	Hollow Dowel Pin	2	2	
3	JY 5210 06	Gasket Cylinder Block	1	1	
4	36 JF00 60	Kit Piston Ring	1	1	Refer Kit List
5	JF 5213 00	Circlip	2	2	

Crankshaft Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 5310 21	Balancer Drive Gear	1	1	
2	LD H000 02	Belleville Washer	1	1	
3	LD B000 33	Plain Washer	1	1	
4	JG 5310 40	Nut Balancer Drive Lock	1	1	
5	39 2606 07	Parallel Pin	1	1	
6	JY 5512 12	Gear Primary Drive	1	1	
7	LF B000 01	Sunk Key	1	1	
8	JF 5310 17	Crankshaft Sprocket	1	1	
9	JY 5310 08	Plain Washer	1	1	
10	DG 1012 75	Washer	1	1	
11	LC G000 02	Nut Sprocket Drive Lock	1	1	
12	JF 5310 20	Crankshaft Assembly Comp.	1	1	
13	36 JF00 54	Kit Primary Drive & Driven	1	1	Refer Kit List

Transmission




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JY 5510 22	Shaft Input	1	1	
2	JY 5512 30	Gear 5th Drive	1	1	
3	JY 5510 10	Bush 5th Drive	1	1	
4	JY 5512 14	Circlip	2	2	
5	JY 5512 29	Gear 3rd - 4th Drive	1	1	
6	JY 5510 21	Bush 6th Drive	1	1	
7	JY 5512 31	Gear 6th Drive	1	1	
8	JY 5512 28	Gear 2nd Drive	1	1	
9	JY 5512 15	Thrust Washer	1	1	
10	JY 5510 06	Bush 2nd Driven	1	1	
11	JY 5512 33	Gear 2nd Driven	1	1	
12	JY 5510 08	Shaft Output T/M With Plug	1	1	
13	JY 5512 37	Gear 6th Driven	1	1	
14	JY 5512 35	Gear 4th Driven	1	1	
15	JY 5510 05	Thrust Washer 3rd Driven	1	1	
16	JY 5512 34	Gear 3rd Driven	1	1	
17	JY 5510 27	Bush 3rd Driven	1	1	
18	JY 5512 18	Circlip	1	1	
19	JY 5512 36	Gear 5th Driven	1	1	
20	JY 5512 05	Bush 1st Driven	1	1	
21	JY 5512 32	Gear 1st Driven	1	1	
22	JY 5512 17	Thrust Washer	1	1	
23	JY 5510 18	'O' RING	1	1	
24	36 JY01 02	Collar Sprocket	1	1	
25	JY 5510 29	Sprocket Output	1	1	
26	JY 5510 30	Plate Drive Sprocket	1	1	
27	LA E000 17	Bolt Flanged	2	2	

Change Drum / Shift Fork




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JG 5612 22	Guide Gear Shift	1	1	
2	LA C000 24	Socket Head Bolt	1	1	
3	JG 5610 10	Spacer	1	1	
4	39 2606 07	Parallel Pin	1	1	
5	JF 5610 00	Drum Gear Shift	1	1	
6	JG 5610 08	Gear Indicator Pin	1	1	
7	JY 5610 04	Shaft Input Gear Shift Fork	1	1	
8	JF 5610 01	Shaft Output Fork Shift	1	1	
9	JG 5612 15	Compression Spring	2	2	
10	JY 5610 08	Fork Shift Output	2	2	
11	JY 5610 02	Fork Gear Shift Input	1	1	

Gear Change Mechanism




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JY 5612 05	Lever Complete Change Shaft	1	1	
2	JG 5612 15	Spring Compression	1	1	
3	JG 5612 17	Bush Torsion Spring	1	1	
4	JG 5612 18	Torsion Spring	1	1	
5	JG 5612 16	Plain Washer	1	1	
6	52 JF03 48	Change Lever Complete Assy.	1	1	
7	KA DM06 22	Bolt Flange M6	1	1	
8	JL 5614 10	Washer Steel	1	1	
9	JL 5614 09	Bolt Gear Change Lever	1	1	
10	01 1009 05	'O' Ring	2	2	
11	JF 5614 10	Lever Change Assembly	1	1	
12	52 JF00 62	Tie Rod	1	1	
13	JF 5614 08	Change Arm Assembly	1	1	
14	DT 5612 05	Damper	1	1	

Engine Assembly / Crankcase RH




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	36 JF00 52	Kit Assembly Crankcase RH	1	1	Refer Kit List Not Illustrated
2	JF 5010 11	Assembly Engine	1	1	
3	39 2185 20	Deep Groove Ball Bearing	1	1	
4	39 2562 20	Needle Roller Bearing	1	1	
5	39 2601 20	Ball Bearing	1	1	
6	39 1864 20	Ball Bearing 20 X 52 X 15	1	1	Refer Kit List
7	KP BF63 04	Ball Bearing	1	1	
8	JY 5410 47	Stopper I/P Shaft Bearing	3	3	
9	AA 1014 37	Bolt Flanged	3	3	
10	JG 6010 07	Special Shaft Seal	1	1	
11	JL 6010 10	Water Seal Double Lip	1	1	
12	36 JF00 57	Kit Engine Gasket	1	1	
13	DP 1011 91	Bolt Shifter	1	1	
14	JG 5710 14	Oil Filter	1	1	
15	JG 5710 16	'O' RING	1	1	
16	JL 5710 01	Cap Oil Filter	1	1	
17	KA EW06 16	Flange Bolt	2	2	
18	LA E000 01	Bolt Flanged	1	1	
19	JG 5612 26	Spring Stopper Drum	1	1	
20	39 2005 11	Washer	1	1	
21	JG 5610 09	Stopper Drum Complete	1	1	
22	JG 5612 05	Washer	1	1	
23	JG 5612 04	Bolt Stopper Drum	1	1	

Crankcase LH




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	36 JF00 51	Kit Assembly Crankcase LH	1	1	Refer Kit List
2	LJ A000 02	'O' Ring	2	2	
3	JY 5710 08	Strainer Evacuation	1	1	
4	LJA00006	'O' Ring	1	1	
5	JY 5710 09	Cap Strainer Evacuation	1	1	
6	39 1043 19	Oil Seal	1	1	
7	JY 5410 58	Oil Seal	1	1	
8	KE BA37 15	Circlip Internal	1	1	
9	JY 5410 31	Chain Guard	1	1	
10	LB B000 07	Screw Pan Cross	3	3	
11	JY 5710 30	Mesh Oil Filter Assembly	1	1	
12	LJ A000 04	'O' Ring	1	1	
13	JA 5410 48	Strainer Cap With 'O' Ring	1	1	
14	DT 3518 00	Neutral Switch + Pick Up Coil	1	1	
15	LA D000 63	Bolt Flanged	2	2	
16	AA 1014 37	Bolt M5 x 13	5	5	
17	JY 5410 81	Bracket Harness	1	1	
18	JY 5410 80	Plate Harness	1	1	
19	JY 5410 82	Bracket Harness	1	1	
20	LP B000 03	Bearing Ball	1	1	
21	LP B000 02	Bearing Ball	1	1	
22	39 2562 20	Needle Roller Bearing	1	1	

Crankcase LH




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
23	JF 5410 17	Bracket	1	1	
24	LB B000 07	Screw Pan Cross	1	1	
25	39 2181 06	Hollow Dowel Pin	4	4	
26	KA EW06 35	Bolt Flange Small	15	15	M6 x 1 x L35 x Bright
27	LA E000 02	Bolt Flanged	5	5	M6 x 1 x 75
28	JY 5710 29	Oil Rail	1	1	
29	LJ A000 02	O Ring	1	1	
30	JF 5410 16	Nozzle	1	1	Not Serviced Separately

Balancer Idler Gear & Water Pump




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 5312 00	Body Balancer Assembly	1	1	
2	KP BF63 04	Ball Bearing	2	2	
3	36 JL00 39	Rotor Water Pump	1	1	
4	JG 5312 15	Washer	1	1	
5	JG 6010 05	Domed Nut	1	1	
6	JG 6010 12	'O' Ring	1	1	
7	39 2606 07	Parallel Pin	2	2	
8	JL 6010 05	Cover Water Pump	1	1	
9	39 1665 11	Washer	1	1	
10	LA E000 48	Bolt	1	1	
11	LA E000 56	Bolt	5	5	
12	DS 1011 54	Key	1	1	
13	LD B000 51	Washer	1	1	
14	LA C000 86	Bolt Socket	1	1	
15	JF 5312 13	Scissor Gear Assembly	1	1	

Oil Pump & Evacuation Pump




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JY 5710 15	Evacuation Oil Pump Assly.	1	1	
2	LH D000 01	Pin Parallel	3	3	
3	39 0999 06	Pin Dowel	4	4	
4	LA E000 18	Bolt Flanged M6 Pre Coated	6	6	
5	JY 5710 24	Shaft Oil Pump	1	1	
6	JY 5710 12	Oil Pump Assembly Complete	1	1	
7	JY 5710 23	Gear Oil Pump Drive	1	1	
8	LD A000 17	Washer Plain	1	1	
9	KE AB10 10	Circlip External	1	1	

Cooling System




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 6012 05	Radiator Core	1	1	
2	JY 6012 48	Bracket Fan Mounting	2	2	
3	JY 6012 49	Bracket Fan Mounting	1	1	
4	JG 6012 35	Pressure Cap Radiator	1	1	
5	JY 6012 41	Flange Nut	3	3	
6	JG 6012 09	Clamp DIA 24	2	2	
7	JF 6012 03	Hose Thermostat To Radiator	1	1	
8	JG 6012 10	Clamp DIA 28	3	3	
9	DT 6012 18	Hose Coolant	1	1	(Thermostat To T)
10	JG 6010 16	Clamp DIA 26	3	3	
11	JY 6012 15	Hose Engine To Thermostat	1	1	
12	JF 6012 02	Hose Pipe Radiator To T	1	1	
13	DT 6012 19	Pipe Coolant T Assembly	1	1	
14	JG 6012 37	Fan Radiator	1	1	
15	JL 6012 16	Rubber Damper	4	4	Radiator Mounting
16	JL 1812 56	Grommet For Radiator Cowl	2	2	
17	JW 1710 15	Collar Central Spoiler	2	2	
18	JG 6010 14	Thermostat Assembly	1	1	
19	JF 1812 57	Shroud Centre	1	1	
20	JL 6012 35	Tank Expansion	1	1	
21	JG 6012 11	Cap Expansion Tank	1	1	
22	56 JF24 6B	Shroud LH	1	1	
23	56 JF25 6B	Shroud RH	1	1	
24	JL 6012 13	Hose Expansion Tank	1	1	
25	JG 6012 13	Tube Drain - Expansion Tank	1	1	

Cooling System




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
26	JG 1710 29	Spring Band Clip 10 MM	3	3	M6x1xL25xBkt.
27	JF 1812 62	Shroud Mounting Bracket RH	1	1	
28	JL 6012 15	Clamp - Expansion Tank	1	1	
29	LB U000 53	Screw Button Head	4	4	
30	JY 1812 84	Washer Nylon	4	4	
31	LA E000 55	Bolt Flange Small	2	2	M6x1xL16xBRIGHT
32	JG 1812 59	Rivet Snap	4	4	
33	DJ 1810 65	Clip Nut M6	4	4	
34	LD B000 75	Washer	4	4	
35	LC G000 29	NUT - FLANGE - M6 X 1P	4	4	
36	LA E000 49	Bolt Flange	2	2	

Cover Clutch




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 5412 04	Assly Clutch Cover With Nozel	1	1	Refer Kit List
2	39 1990 20	Needle Bearing	1	1	
3	39 1041 19	Seal Oil	1	1	
4	LD B000 20	Washer	1	1	
5	JF 5412 10	Spring Lever Clutch	1	1	
6	JF 5412 08	Clutch Release Shaft Assembly	1	1	
7	39 1537 21	'O' Ring	1	1	
8	JG 5412 30	Cap Oil Filling	1	1	
9	JL 5412 22	Label Triple Spark	1	1	
10	JL 5412 27	Window Oil Gauge	1	1	
11	DS 1012 15	Wire Circlip	1	1	
12	39 2016 19	Seal Oil	1	1	
13	JY 5412 20	Plate Position	1	1	
14	AA 1014 37	Bolt Flanged Small	2	2	
15	JY 5412 25	Gasket Clutch Cover	1	1	
16	JF 5412 04	Bracket Clutch Cable	1	1	
17	KA EW06 35	Blot Flanged	12	12	

Cover Magneto




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 5412 03	Magneto Cover Assembly	1	1	
2	JL 5412 23	Label B - Bajaj	1	1	
3	30 1011 95	'O' Ring	1	1	
4	JG 5412 32	Cap TDC Finder	1	1	
5	JY 5412 76	Gasket Magneto Cover	1	1	
6	KA EW06 35	Bolt Flange	12	12	M6 x 1 x L35 x Bright
7	DT 5412 02	Cover LH RR	1	1	
8	KA EW06 50	Bolt Flange	3	3	M6 x 1 x L50 x Bright
9	JF 2330 36	Label Gear Shift 6 Speed	1	1	
10	39 0999 06	Pin - Hollow Dowel	2	2	

Clutch Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JY 5514 01	Bush Collared	1	1	Refer Kit List
2	36 JF00 54	Kit Primary Drive & Driven	1	1	
3	JY 5514 03	Washer Clutch	1	1	
4	JY 5514 35	Clutch Center	1	1	
5	JY 5514 42	Spring Seat Judder	1	1	
6	JY 5514 41	Spring Judder	1	1	Refer Kit List
7	36 JY01 03	Kit Friction Plate	1	1	
8	JY 5514 36	Pressure Plate - A	5	5	
9	JY 5514 37	Pressure Plate - B	1	1	
10	JF 5515 00	Clutch Assembly	1	1	
11	LC G000 09	Nut Hex Flanged - M16 x 1.5	1	1	
12	LP A000 04	Thrust Bearing	1	1	
13	JY 5514 38	Plate Clutch Pressure	1	1	
14	JY 5514 04	Rod Pull	1	1	
15	JY 5514 39	Spring Clutch	3	3	
16	JY 5514 43	Plate Stopper	1	1	
17	LA D001 66	Bolt Flanged - M6 x 35	3	3	

Throttle Body & Sensors




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 6112 03	Throttle Body EVAP	1	1	
2	JY 6110 00	Fuel Injector	1	1	
3	JF 6112 01	Injector Cap & Quick Connector	1	1	
4	JG 5814 24	Fixing Screw M5 x 12	5	5	
5	JG 6112 06	Motor Stepper	1	1	
6	JG 3518 05	Sensor T MAP	1	1	
7	JG 5814 37	Fixing Screw	1	1	
8	DT 3518 03	Sensor Throttle Position	1	1	
9	JG 5814 23	Fixing Screw M5x12	2	2	

Air Cleaner Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 5810 20	Filter Top Cover	1	1	
2	JH 5812 02	Clamp Carb Sleeve Dia 44	1	1	
3	JF 5810 22	Entry Duct	1	1	
4	DT 5810 28	Seal Top Cover	2	2	
5	KB UA06 30	Screw Truss	4	4	
6	DT 5810 72	Assembly Breather Tube	1	1	
7	JF 5810 26	Clamp Breather Pipe	1	1	
8	JY 5810 28	Clamp	1	1	
9	DT 5810 62	Filter Element	1	1	
10	JY 5810 28	Clamp (Breather Tube)	1	1	
11	JP 5810 18	Assembly Tube Drain	1	1	
12	JY 5810 28	Clamp	2	2	
13	DT 5810 74	Assly Breather Oil Return Tube	1	1	
14	DT 5810 79	Assembly Air Filter Complete	1	1	
15	DT 1138 56	Bracket Filter Mounting	1	1	
16	39 0219 11	Washer Plain	4	4	
17	KA CF06 12	Bolt Socket	4	4	

Silencer Assembly & Belly Pan




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 5911 16	Pipe A Assembly	1	1	
2	JF 5911 35	Clamp	2	2	
3	JF 5911 34	Gasket	2	2	
3A	JG 5910 70	Gasket	1	1	
4	JF 5910 65	Muffler Assembly Complete	1	1	
5	JF 5911 20	End Chamber Assly. Comp.	1	1	
	YJ F040 03	End chamber without shield	1	1	
6	JG 511010	O2 Sensor	1	1	
7	JF 5910 33	Shield	1	1	
8	LD B000 68	Washer Plain	2	2	
9	LA C000 99	Bolth Socket - M6	2	2	
10	JF 1813 14	Assembly Belly Pan	1	1	
11	JF 1813 09	Bracket Belly Pan Mtg. Rear	1	1	
12	LA C000 08	Screw Button Head	2	2	M6 x 1 x L20
13	DT 1813 07	Bracket Belly Pan Mounting	1	1	
14	KA CA06 35	Bolt Master KAC	2	2	
15	39 0198 11	Plain Washer	5	5	
16	LB U000 55	Screw Button Head	2	2	M6 x 1 x L15
17	KA CF06 12	Bolt Socket - M6 x 1 x L12	2	2	
18	39 0198 11	Washer Plain	2	2	
19	JY 1812 55	Washer End Cap	4	4	
20	JF 1813 23	Foam Belly Pan	1	1	
21	JF 1813 24	Foam Belly Pan	1	1	

Starter Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 3516 00	Starter Motor	1	1	
2	KA DQ06 25	Bolt Flanged	2	2	
3	JY 5512 25	Gear Starter Counter 2	1	1	
4	JY 5512 26	Gear Starter Counter 1 Assy.	1	1	
5	31 1011 73	Key Woodruff	1	1	
6	JY 6214 11	Assembly Gear Starter Clutch	1	1	
7	JY 5410 40	Retainer Gear Starter	1	1	
8	LA E000 42	Bolt Flanged	1	1	

Magneto, Regulator & ECU




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 3510 13	Rotor Without Clutch & BSC	1	1	
2	JF 3510 11	Stator Assembly	1	1	
3	DK 1012 84	Hex Socket Head Screw	3	3	
4	JF 4020 04	Regulator Assembly	1	1	
5	KA ED06 30	Bolt - Flanged - Small	2	2	
6	52 JF03 28	Sub Assly Bkt ECU Mtg Lower	1	1	
7	JF 3514 05	EPM44 MTB Assembly - K10	1	1	
8	52 JY06 67	Sub Assly Bkt C Sample Top	1	1	
9	KC GA06 06	Nut Hex Flanged	4	4	
10	JF 4022 34	Magneto Pigtail to RR	1	1	
11	LD B000 41	Plain Washer	1	1	
12	LA D001 24	Bolt Flange	1	1	
13	JY 5412 22	Plate Harness	1	1	
14	JY 5412 08	Bracket Harness Magneto	1	1	
15	LA E000 16	Bolt	3	3	
16	39 0849 14	Washer	4	4	
17	LA C001 22	Bolt Socket	4	4	
18	JG 3510 19	Body Starter Clutch	1	1	
19	JY 5514 02	Clutch One Way Assly	1	1	

H.T. Coils




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 3512 10	Ignition Coil-2 with Cable	1	1	Twin Output
2	39 1913 04	Bolt Flange	4	4	
3	JF 3512 08	Ignition Coil-1 with Cable	1	1	
4	DK 1110 28	Spark Plug RG6HCC	2	2	
5	JL 3512 18	Spark Plug BOSCH central	1	1	
6	DD 1110 12	Grommet For H. T. Cable	2	2	
7	JD 3512 07	Spark Plug Cap	1	1	
8	AN 1110 15	Spark Plug Cap	1	1	
9	DH 1110 13	Grommet - Spark Plug	1	1	
10	JF 3512 12	Spark Plug Cap	1	1	
11	DH 1110 16	Grommet - Sleeve Spark Plug	1	1	
12	DD 1110 11	Grommet - Spark Plug Cap	1	1	
13	JF 3512 06	Grommet Spark Plug	1	1	

Seat Assembly & Seat Lock




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1910 09	Seat Assembly Front - K10	1	1	
2	JG 1910 08	Collar - Seat	2	2	
3	FD 2110 06	Grommet Seat	2	2	
4	JL 1910 17	Damper For Seat	4	4	
5	JK 1910 05	Damper Seat	2	2	
6	DK 2110 07	Damper Seat Front	1	1	
7	DS 1612 87	Flange Bolt - M6	2	2	
8	JF 1910 12	Seat Assembly Rear - K10	1	1	
9	JD 1910 06	Damper Round	2	2	
10	JL 1910 17	Seat Damper Front	2	2	
11	KA DF06 25	Bolt Flange	2	2	
12	DT 2326 05	Seat Lock	1	1	
13	JL 1510 23	Side Lock	1	1	
14	JL 2326 04	Cover Seat Lock	1	1	
15	JF 1138 17	Bracket Seat Lock	1	1	

Engine Mountings




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1134 14	Engine Hanger LH (Tubular)	1	1	
2	JF 1134 15	Engine Hanger RH (Tubular)	1	1	
3	KA EW08 35	Bolt - Flanged Small	4	4	
4	JF 1138 41	Cap Tube End	4	4	
5	JF 1111 75	Bolt Engine Mounting	1	1	
6	LD C000 01	Washer Leg Guard	1	1	
7	LD A000 12	Washer Plain	1	1	
8	LC A000 14	Nut Leg Guard Mounting	1	1	
9	KA DW10 B0	Bolt Flange M10x1.25xL110	2	2	
10	39 2723 15	Hex Nut / Flange	2	2	
11	DT 1138 27	Cover Seal Heat	1	1	

Frame and Frame Fittings




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 1111 34	Frame Assembly Complete	1	1	Without Bearing Race Refer Kit List
2	36 DV00 08	Kit Steering Cone	1	1	
3	DK 1810 50	Cage Bearing Steering Top	1	1	
4	DK 1810 51	Cage Bearing Steering Bottom	1	1	
5	DG 1810 03	Washer	1	1	
6	DG 1810 04	Seal Oil	1	1	
7	JL 1138 09	Grommet Air Filter Resting	1	1	
8	JF 1111 79	Grommet Frame	2	2	
9	JL 1810 27	Clip Nut	4	4	
10	JF 1138 28	Clip Nut	2	2	
11	JF 1138 21	Bracket Canister Mounting	1	1	
12	KA EA06 10	Bolt Flanged	2	2	
13	JZ 1710 55	Strap Canister	2	2	

Swing Arm & Rear Shock Absorber




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 1220 17	Swing Arm Assembly	1	1	
2	JF 1220 13	Shock Absorber Mono	1	1	
3	LA C001 05	Bolt Socket M10 x 1.25 x L55	2	2	
4	DG 1710 16	Sleeve	2	2	
5	DG 1710 18	Bearing - Needle	2	2	
6	DG 1710 19	Seal - Oil	4	4	
7	JF 1220 49	Adjuster Chain	2	2	
8	JF 1220 15	Stud Chain Adjuster	2	2	
9	KC AM08 06	Nut Hex Thick	2	2	M8 x 1.25 x HT.6.5
10	JF 1220 16	Slider Chain	1	1	
11	JF 1220 48	Spacer Swing Arm Central	1	1	
12	JL 1220 26	Shaft Swing Arm Assembly	1	1	
13	39 1053 15	Nut	1	1	
14	DT 1138 48	Cap Swing Arm Pivot	2	2	

Pillion Foot Rest




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1130 03	Holder Step LH	1	1	
	56 JF3X 1Y	Holder Step LH Slate Gray	1	1	
2	JL 1130 00	Step Assembly Main LH	1	1	
	56 JF3S 1Y	Rider Step Lh K10 Slate Grey	1	1	
3	LH E000 03	Pin Clevis With Hole	4	4	
4	JF 1130 12	Spring Torsion	2	2	
5	KD AA08 16	Washer Plain Small	4	4	
6	KH AA25 20	Pin Cotter	4	4	
7	JL 1130 14	Step Pillion Assy Complete LH	1	1	
	56 JF18 1Y	Step Pillion Lh K10 Slate Grey	1	1	
8	JL 1130 36	Rubber Pillion Step	2	2	
9	DT 1130 14	Lock Plate LH	1	1	
10	30 1410 31	Ring O	2	2	
11	JF 1130 15	Step Holder RH	1	1	
	56 JF3Y 1Y	Holder Step Rh Grey Slate	1	1	
12	JL 1130 07	Step Assembly Main RH	1	1	
	56 JF3T 1Y	Rider Step Rh Slate Grey	1	1	
13	JL 1130 16	Step Pillion Assy Complete RH	1	1	
	56 JF19 1Y	Step Pillion Rh K10 Slate Grey	1	1	
14	DT 1130 15	Lock Plate RH	1	1	
15	LA C000 78	Bolt Socket - M8x1.25xL20	4	4	
16	LA C000 79	Bolt Socket - M8x1.25xL35	2	2	
17	DH 1611 55	Damper Silencer	1	1	
18	DH 1611 57	Tube Silencer	1	1	
19	JF 1130 14	Bracket Reservoir Mounting	1	1	
20	KA DM06 16	Bolt Flanged	1	1	
21	JL 1318 78	Bracket Reservoir Cap	1	1	
22	KB BA05 12	Screw Pan Cross	1	1	

Front Fender




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	LB B000 15	Screw Pan Cross	3	3	
2	KD AE05 10	Washer Plain Small	6	6	
3	DS 1611 25	Guide - Cable	–	1	
4	DJ 1610 69	Nail Cable Guide	–	1	
5	JF 1814 34	Flap Fender Front	1	1	
6	JF 1814 33	Sleeve Fender Mounting	2	2	
7	JF 1814 29	Fender Brace	1	1	
8	DJ 1610 91	Grommet Front Fender	6	6	
9	KA AC08 25	Bolt - KAA ST-C Dia - 08 L-25	4	4	
11	LA C001 08	Bolt - Hexagon Socket M6	2	2	
12	DT 1814 33	Plug Front Fender	1	–	
13	39 0326 15	Nut Nyloc	3	3	
14	JF 1814 32	Sleeve Brace Fender	4	4	

Side Stand Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1132 04	Assembly Side Stand	1	1	(Side stand switch)
2	DT 1132 05	Bracket Side Stand.	1	1	
3	JZ 4036 01	Magnet Holder	1	1	
4	JL 1132 09	Spring Side Stand	1	1	
5	DF 1611 02	Bolt	1	1	
6	39 0422 15	Nut Nyloc M10	1	1	M8x1.25xL16xPRECOAT M8x1.25xL70xBright
8	LA D001 84	Bolt Flanged	1	1	
9	LA D002 00	Bolt Flanged	1	1	
10	KA DB05 16	Bolt Flanged M5	1	1	
11	JF 4014 05	Side Stand Switch	1	1	
12	JL 1138 18	Cover Side Stand Switch	1	1	
13	DH 1611 46	Cover Spring Side Stand	1	1	

Tubeless Tyre & Rim




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JG 1310 38	Tyre Front MRF VER 7	1	1	
2	DK 1510 26	Valve Tubeless Tyre	2	2	
3	JF 1310 12	Wheel Front 3.00 X 17	1	1	
4	JF 1312 17	Wheel Rear 4.00 X 17	1	1	
5	JG 1312 45	Tyre Rear MRF VER 7	1	1	

Front Hub




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1310 12	Wheel Front	1	1	M14 x 1.5 x L214.5
2	JF 1310 24	Axle Front	1	1	
3	JL 1310 00	Collar	1	1	
4	DG 1510 05	Seal Oil	2	2	
5	KP BC62 02	Bearing Ball C3 Clearance	2	2	
6	JG 1310 01	Spacer Assembly Front Wheel	1	1	M6 x 1 x L16
7	JF 1318 17	Disc Front Dia 320	1	--	
	JF 1318 46	Disc Front Dia 300	--	1	
8	DT 1318 67	Sensor Disc Front	1	--	
8A	JF 4024 13	Vehicle Speed Sensor	--	1	
9	JD 1318 11	Special Bolt M8	6	6	ID 15.2xOD30xT3
10	DT 1310 17	Collar Assembly Front Wheel	1	--	
11	DT 4024 04	Wheel Speed Sensor	1	--	
12	LA E000 55	Bolt Flange Small	1	--	
13	LD B000 57	Washer Plain	1	1	
14	LC J000 05	Nut U	1	1	M14x1.5xT12.5

Caliper Assembly - Front Disc Brake




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1318 57	Caliper Assy Brake Front	1	–	
	JF 1318 50	Caliper Assy Brake Front	–	1	
2	DE 1510 46	Screw Bleeder	1	1	
3	DE 1510 47	Bleeder Cap	1	1	
4	JL 1318 07	Boot	1	1	
5	JL 1318 32	Disc Pad	1	–	
	JL 1318 05	Disc Pad	–	1	
6	JL 1318 31	Minor Kit	1	–	
	DJ 1510 74	Minor Kit	–	1	
7	JL 1318 31	Major Kit	1	–	
	DJ 1510 75	Major Kit	–	1	
8	LA D001 98	Bolt Caliper Mounting	2	2	
9	36 JF00 88	Kit Bracket Sub Assembly	1	--	
	36 JF00 83	Kit Bracket Sub Assembly	--	1	
10	36 JF00 84	Kit Primary Pin	--	1	

Anti Brake Lock - Unit




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1318 15	Unit Abs Dry	1	--	
2	36 JF00 64	Hose ABS To FR Master Cyl.	1	--	
3	36 JF00 65	Hose ABS To FR Caliper	1	--	
4	36 JF00 66	Hose ABS To RR Master Cyl.	1	--	
5	36 JF00 78	Hose ABS To RR Caliper	1	--	
6	DT 1138 50	Bracket Front ABS Mounting	1	--	
7	KA ED06 12	Bolt Flanged Small	1	--	
8	KA ED06 08	Bolt Flanged Small	1	--	
9	LA E000 21	Bolt Flanged - M6 x 12	3	--	
10	DT 1318 75	Clamp For ABS Hose	1	--	
11	KAE W06 25	Bolt Flange Small - M6x1xL25	1	--	
12	DE 1910 10	Copper Washer	8	--	
13	DK 1510 69	Benjo Bolt	4	--	
14	DT 1318 78	Clamp W	1	--	
15	JF 1318 54	Clamp W	1	--	

Rear Disc Brake Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1318 58	Assembly Caliper	1	--	
	JL 1318 34	Assembly Caliper	--	1	
2	JF 1318 14	Assembly Master Cyl. Rear	1	1	
3	36 JF00 79	Hose Disc Brake Rear	--	1	
4	DK 1510 69	Banjo Bolt	2	2	
5	JG 1318 21	Reservoir Rear Brake	1	1	Without Cap
6	JL 1312 20	Hose - Reservoir	1	--	
	36 JF00 87	Kit Rear Reservoir	--	1	
7	DK 1510 63	Clip Reservoir	1	1	Cap Reservoir
8	DE 1910 10	Copper Washer	4	4	Banjo Bolt
9	DE 1510 47	Cap Bleeder Screw	1	1	
10	DE 1510 46	Bleeder Screw	1	1	
11	YJ L040 05	Kit Major Caliper	1	--	
12	YJ L040 06	Kit Minor Caliper	1	--	
13	DK 1510 85	Set Disc Pad	1	1	
14	30 1910 38	Pin	1	1	
15	39 0198 11	Washer	1	1	
16	39 0808 08	Split Pin	1	1	
17	36 JF00 85	Master Cyl. Major Kit	--	1	N.I.
18	36 DT00 40	Kit Minor M Cylinder	1	--	
19	DK 1510 74	Master Cyl. Minor Kit	1	1	N.I.
20	DK 1510 45	Cap Reservoir	1	1	
21	36 JF00 86	Kit Reservoir	--	1	
22	KA DD06 14	Screw Pan Cross	1	1	
23	JG 1812 39	Collar	1	1	
24	36 DT00 52	Bracket Caliper	--	1	
	DK 1510 86	Bracket Caliper	--	1	
25	36 JF00 85	Kit Push Rod	1	1	

Rear Hub




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1312 17	Wheel Rear 4.00 x 17	1	1	
2	JF 1312 30	Axle Rear M14 x 1.5 x L295	1	1	
3	LD B000 57	Washer Plain	2	2	
4	JF 1220 14	Chain Adjuster	2	2	
5	JL 1312 11	Spacer For Coupling	1	1	
6	36 JF00 56	Kit Chain Sprocket	1	1	Refer Kit List
7	DT 1312 13	Coupling	1	1	
8	DT 1312 10	Sleeve	1	1	
9	JU 1312 22	Damper 6 Rubber	6	6	
10	KP BC62 02	Bearing Ball - C3 Clearance	1	1	
11	JL 1312 16	Collar Bearing Assembly	1	1	
12	KP BC63 02	Bearing Ball - C3 Clearance	1	1	
13	30 1510 82	Seal Oil	1	1	
14	JL 1319 30	Disc Rear	1	1	
15	39 2038 04	Hexagon Socket Head Bolt M6	6	6	
16	JU 1318 02	Sensor Disc Rear	1	--	
17	JG 1312 20	Screw For ABS	3	--	
18	DK 1510 82	Spacer II	1	1	
19	DK 1510 81	Spacer I	1	1	
20	LC J000 05	Nut U	1	1	M14 x 1.5 x HT12.5
21	KP AC62 05	Coupling Bearing	1	1	
22	JG 1312 28	Bolt D	6	6	
23	LC L000 04	Nut	6	6	

Rear Brake Pedal




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1610 06	Brake Pedal	1	1	
2	LD B000 56	Washer Pivot Bolt	1	1	
3	39 1998 19	Seal - Oil	2	2	
4	JC 1910 09	Bolt Brake Pedal	1	1	
5	JF 1610 04	Brake Return Spring	1	1	
6	JL 4014 06	Brake Switch Rear	1	1	
7	JM 1910 14	Spring Brake Switch Rear	1	1	
8	JF 1610 07	Damper Brake Pedal	1	1	
9	JZ 1318 75	Pin	1	1	
10	KH AA20 15	Pin Snap	1	1	
11	JF 1318 51	Bracket Rear Brake Switch	1	1	

Handle Bar Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1510 41	Handle Bar	1	1	
2	JF 1610 08	Assy. Lever & Support Holder	1	1	
3	JG 1610 08	Clutch Lever	1	1	
4	JF 4014 10	Switch Control LH	1	1	
5	DH 1910 67	Handle Grip LH	1	1	
6	JL 1510 35	Handlebar Weight	2	2	
7	LA C001 25	Bolt Socket	2	2	
8	JF 4014 11	Switch Control RH	1	1	
9	JG 1510 22	Throttle Pipe	1	1	
10	DH 1910 68	Assembly Handle Grip RH	1	1	
11	LA C001 11	Bolt Socket M8 x 1.25 x L29	4	4	
12	JF 1510 42	Handle Holder Upper	1	1	
13	LA C000 91	Bolt Socket	2	2	
14	JF 1510 45	Handle Holder Bottom	1	1	
15	JF 1510 47	Washer Cup	4	4	
16	JF 1510 44	Damper Handle Holder Mtg.	4	4	
17	JF 1510 43	Spacer Handle Holder	2	2	
18	JF 1210 30	Upper Bracket	1	1	
19	JY 1210 11	Bolt Socket M8 x 1.25 x L30	2	2	
20	LC H000 01	Nut - Nyloc	2	2	
21	DT 2326 01	Ignition Switch	1	1	
22	LA D000 77	Bolt Flanged M6 x 16	2	2	
23	JF 2326 11	Lock Set 3 IN 1	1	1	
24	JY 4014 04	Clutch Switch	1	1	

Front Fork




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1210 29	Front Fork Assembly	1	1	
2	DT 1210 01	Tube Outer LH	1	1	
3	DT 1210 02	Tube Outer RH	1	1	
4	KA CF10 30	Bolt Socket	2	2	
5	DK 1810 07	Copper Washer	2	2	
6	DT 1210 16	Washer Seal	2	2	Refer Kit List
7	36 JF00 63	Kit Fork Oil Seals	2	2	
8	DT 1210 15	Guide Bush	2	2	
9	DT 1210 13	Washer	2	2	
10	JF 1210 38	Spacer Tube	2	2	
11	JF 1210 36	Fork Tube Inner	2	2	Refer Kit List
12	36 JF00 62	Kit Cylinder Comp Fork	2	2	
13	JF 1210 37	Main Spring	2	2	
14	DT 1210 20	Fork Bolt	2	2	
15	DT 1210 21	O' Ring	2	2	
16	JF 1210 33	Under Bracket Assembly	1	1	
17	JF 1812 85	Cover Cushion	4	4	
18	JF 1812 84	Cover Trail	4	4	
19	JF 1812 83	Tube Fork Cover	2	2	
20	LA D001 93	Bolt Steering Top	1	1	
21	DK 1810 25	Spring Washer	2	2	
22	KA CM10 35	Bolt	2	2	

Front Fork




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
23	JF 1210 34	Leg Assembly LH	1	1	
24	JF 1210 35	Leg Assembly RH	1	1	
25	JF 1210 29	Bolt Flanged	1	1	
26	PD 1510 06	Cup Steering	1	1	
27	DK 1810 75	Nut Steering	1	1	
28	JF 1510 48	Anti - Abrasive Tape	1	--	
29	JF 1210 45	Bracket Speed Sensor Cable	1	--	
30	JF 1210 19	Spring Washer	1	1	
31	36 JU00 19	Kit Fork Oil seal	2	2	Refer Kit Details
32	JF 1318 53	Bracket Hose Clamp	1	--	

Petrol Tank, Cap Tank & Gauge Fuel




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1710 33	Tank Assy	1	1	Will be supplied in lock set
2	JF 2326 11	Cap Tank	1	1	
3	KA CD05 16	Screw Allen	6	6	
4	JF 1718 02	Fuel Pump Module	1	1	
5	LA D001 54	Bolt Flange	6	6	
6	DT 1718 39	Plate Pressure Fuel Pump Mtg	1	1	M6 x 1 x L12.8
7	JF 6112 01	Assy Tube Filter To Injector	1	1	
8	DT 1710 89	Assy Tube Filter To Regulator	1	1	
9	DT 1710 87	Tube Pump to Filter	1	1	
10	DT 1718 14	Inline Fuel Filter	1	1	
11	JL 1710 19	Sleeve Tank Mtg Rear	2	2	M8 x 1.25 x L20
12	DT 1710 61	Drain Pipe	1	1	
13	DG 1410 28	Clamp	1	1	
14	KA DW08 20	Bolt Flange	3	3	
15	JF 1710 55	Sleeve Tank Mtg Front	1	1	
16	DT 1710 78	Grommet Tank Mtg Front	1	1	Refer Kit List
17	JL 1710 20	Grommet Tank Mtg Rear	2	2	
18	JF 1710 23	Tank Damper Top Front LH	1	1	
19	JF 1710 24	Tank Damper Top Front RH	1	1	
20	JF 1710 25	Tank Damper Top Central LH	1	1	
21	JF 1710 26	Tank Damper Top Central RH	1	1	Refer Kit List
22	JF 2326 11	Lock Set 3 IN 1	1	1	
23	JY 4022 35	Pig Tail Fuel Pump	1	1	
24	JF 1710 56	Foam	2	2	
25	JF 1813 20	Frame Cover Front	1	1	
26	LA E000 54	Step Bolt	1	1	

EVAP Mechanism




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JY 1710 77	Canister	1	1	
2	DT 1718 34	Tube Canister To Purge Valve	1	1	
3	JG 1716 01	Valve Purge	1	1	
4	JY 1710 69	Spring Band Clamp 15 x 10	1	1	
5	JY 1710 90	Spring Band Clamp 13 x 12	8	8	
6	JF 1716 05	Tube Purge Valve To Connector	1	1	
7	JG 1710 86	Connector Tube EVAP	1	1	
8	JF 1716 06	Tube Connector To Throttle Body	1	1	
9	JY 1710 70	Spring Band Clamp 9 x 8.4	3	3	
10	JY 1138 42	Connector Y Shape	1	1	
11	JF 1716 04	Tube Y Connector To Canister	1	1	
12	JF 1716 07	Tube Connector To Plug	1	1	
13	JY 1718 25	Plug Fuel Drain	1	1	
14	JF 1716 03	Tube Tank To Y Connector	1	1	
15	DT 1138 49	Strap ECU Canister	2	2	
16	JF 1716 13	Tube Drain	1	1	

Fitting - Petrol Tank Cover




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1710 35	Bracket Tank Side Cover LH	1	1	ST3.5 x L10
2	JF 1710 36	Bracket Tank Side Cover RH	1	1	
3	KA DA05 10	Bolt Flanged	6	6	
4	LD B000 74	Washer Plain	2	2	
5	JF 4024 07	Speedometer Tank Assembly	1	—	
	JF 4024 10	Speedometer Tank Assembly	--	1	
6	JF 1710 43	Bracket Secondary Speedo	1	1	
7	LB R000 10	Screw Tapping Pan Cross	17	17	
8	JF 1710 22	Tank Central Cover	1	1	
9	39 1907 01	Mushroom Head Screw	8	8	
10	JF 1710 28	Bracket Tank Cover Rear	1	1	
11	LB U000 65	Screw Truss - M5 x 0.8 x L14	2	2	
12	JF 1710 48	Collar Cover Tank	6	6	
13	JF 1710 29	Beading Fuel Tank	1	1	
14	JF 1710 47	Grommet Cover Tank	6	6	
15	JG 1812 59	Plug Push Pull	1	1	
16	JF 1710 37	Bolt Tank Cover Mounting	6	6	
17	JF 1710 57	Pad Tank Top Cover	1	1	
18	JF 1710 58	Anti Abrasive Tape	1	1	

Fitting - Side Covers, Seat Cowls & Under Tray Front




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	LB U000 69	Screw Truss	6	6	M6 x 1 x L12
2	LD B000 72	Plain Washer	12	12	
3	LB U000 65	Screw Truss	10	10	M5 x 0.8 x L14
4	DJ 1612 29	Clip Nut M5	10	10	
5	JZ 1812 71	Damper Side Cover	2	2	
6	JH 1812 55	Washer Retaining	2	2	
7	LA D002 02	Bolt Flanged	8	8	
8	DT 1810 07	Under Tray Front	1	1	
9	JF 1138 18	Bracket Rear Fender Mounting	1	1	

Speedometer Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 4024 06	Speedometer Assembly	1	–	OD15 x ID 5.5 x 1.2T
	JF 4024 09	Speedometer Assembly	--	1	
2	JZ 1813 65	Grommet Dashboard	3	3	
3	LD B000 07	Washer Plain	3	3	
4	KC AA05 04	Nut Hex Thick	3	3	
5	JF 1812 65	Speedo Flap	1	1	
6	JF 1812 69	Bracket Speedo Mounting Upper	1	1	
7	KD BA05 12	Washer Plain	2	2	
8	KB UB05 08	Screw Truss	2	2	
9	JF 1812 70	Bracket Mask Carrier Lower	1	1	
10	LA D001 02	Bolt Step	2	2	
11	YJ F040 01	Top cover with sealing ring & hardware	1	1	
12	YJ F040 02	Top cover with sealing ring & hardware - Tank Speedo	1	1	
13	JF 4024 07	Speedometer Tank Assembly	1	–	
	JF 4024 10	Speedometer Tank Assembly	--	1	
14	JB 4010 12	Foam			

Control Cables & Chain Case




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1612 05	Cable Throttle	1	1	
2	JF 1612 04	Cable Clutch	1	1	
3	JF 1612 07	Bracket Clutch Cable	1	1	
4	JF 1612 08	Bush T Clutch Cable	1	1	
5	DT 1813 08	Chain Cover Assembly	1	1	
6	JF 1813 16	Collar - Cover Chain Mounting	5	5	
7	LA C000 54	Screw Button Head	5	5	M6 x 1 x L16 x BRT5

Head Lamp Assembly & Front Number Plate




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JU 2328 00	Front Number Plate	1	1	
2	LB U000 65	Screw Truss M5 x 0.8 x L14	2	2	
3	LD B000 74	Washer Plain	2	2	
4	JF 1812 71	Bracket Number Plate Mtg.	1	1	
5	KB BP05 30	Screw Pan Cross	4	4	
6	KD AA05 10	Washer Plain Small	4	4	
7	DT 1813 06	Windshield	1	1	
8	JZ 2328 14	Pad Rubber Number Plate Bkt	2	2	
9	JF 1812 68	Side Mask LH	1	1	
10	JF 1812 67	Side Mask RH	1	1	
11	39 1501 11	Plain Washer	4	4	
12	LB U000 65	Screw Truss	4	4	
13	JF 1812 66	Mask Carrier	1	1	
14	KB UA06 14	Screw Truss	7	7	
15	LD B000 72	Plain Washer	4	4	
16	LB U000 55	Screw Button Head	2	2	M6 x 1 x L15
17	JF 1812 75	Decal Mask LH	1	1	
18	JF 1812 76	Decal Mask RH	1	1	
19	DT 4010 20	Head Lamp Assembly	1	1	
20	39 0255 11	Washer Plain	3	3	
	KD BA06 13	Washer Plain	3	3	ECR-N17JFCHA1299

Indicator Light Assembly




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 4010 02	Indicator Assembly Front LH	1	1	
2	DT 4010 03	Indicator Assembly Front RH	1	1	
3	LD A000 12	Washer Plain	4	4	
4	LD F000 02	Washer Toothed	4	4	
5	LC A000 05	Nut Hex M10 x 1.25	4	4	
6	JY 4010 24	Indicator Assembly RR LH	1	1	
7	JY 4010 25	Indicator Assembly RR RH	1	1	

Tail Lamp Assembly & Rear Number Plate




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 4010 21	Tail Lamp Assembly	1	1	
2	JF 1814 20	Fender Rear	1	1	
3	LB U000 65	Screw Truss	6	6	
4	JF 1814 21	Under Tray Fender Rear	1	1	
5	LD B000 72	Plain Washer	4	4	
6	LA D001 96	Bolt Flanged	4	4	
7	JF 1814 22	Reinforcement Rear Fender	1	1	
8	JG 4010 06	No. Plate Illumination Lamp	1	1	
9	LB R000 03	Screw CR Pan Head Tap	1	1	4 x 1.59
10	JF 1814 24	Flap Rear Fender	1	1	
11	LC G000 30	Nut Flange	2	2	
12	JF 1813 07	Bracket Rear Number Plate	1	1	
13	JG 4010 36	Reflector - Reflex	1	1	
14	LC G000 28	Nut	1	1	
15	JZ 2328 05	Foam Rear Number Plate	1	1	
16	DJ 2011 73	Grommet For Cables	2	2	Rear Fender
17	DP 1611 45	Number Plate Rear	1	1	
18	KA DA06 10	Bolt Flange M6	2	2	

Electrical Equipments




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 4022 35	Harness Wiring - Non ABS	-	1	
	JF 4022 45	Harness Wiring - ABS	1	-	
2	JL 4030 00	Relay	4	4	
3	36 DT00 04	Kit Band Wiring Harness	1	1	Refer Kit List
4	JG 4020 02	DC Flasher	1	1	
5	JF 4022 12	Cable Assy Relay To Motor	1	1	N.I.
6	JF 4022 11	Cable Earth	1	1	N.I.
7	JL 4032 00	Termination Unit	1	1	
8	PA 4016 00	Horn - 82 DIA	1	1	
9	LD B000 73	Washer - Plain	1	1	
10	KA DA08 14	Hex Head Bolt - Flanged M8	1	1	
11	JN 3516 04	Starter Relay - With Grommet	1	1	
12A	DT 4022 26	Fuse - 7.5A	5	5	Not Illustrated
12B	JG 4022 29	Fuse 15A	4	4	Not Illustrated
12C	JG 4022 30	Fuse 30A	2	2	Not Illustrated
13A	JG 4022 28	Fuse 10A	2	--	Not Illustrated
13B	JG 4022 34	Fuse 25A	1	--	Not Illustrated
14	DT 1138 51	Bracket Fuse Box Mtg Loose	1	--	
	DT 1138 25	Bracket Fuse Box Mtg Loose	--	1	
15	JY 4036 04	Roll Over Sensor	1	1	
16	JF 1138 42	Bracket Roll Over Sensor	1	1	
17	KA CF06 12	Bolt Socket	2	2	M6 x 1 x L12
18	LA C000 08	Screw Truss	2	2	M6 x 1 x L25
19	LD B000 72	Plain Washer	2	2	
20	KC GC06 06	Nut Hex Flanged	2	2	

Electrical Equipments




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
21	36 JU00 15	12V 8Ah VRLA Battery	1	1	
22	JF 1812 73	Assembly Battery Case	1	1	
23	JF 1813 08	Rubber Battery Case	1	1	
24	KA ED06 22	Bolt Flanged Small Length	2	2	
25	KA ED06 25	Bolt Flanged Long Length	2	2	
26	JL 1138 25	Band Battery Case Vertical	1	1	
27	DT 1810 22	Band Battery Case	1	1	
28	JF 1138 16	Horn Mounting Bracket	1	1	

Tool Kit



No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JG 2310 01	Tool Kit	1	1	Not Serviceable
2	JG 2310 02	Tool Bag	1	1	
3	DP 2210 11	Band Tool Kit	2	2	

Accessories - Mirror, Leg Guards, Grab Handles & Saree Guard



No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	DT 2314 07	Grab Handle LH	1	1	
2	DT 2314 10	Grab Handle RH	1	1	
3	LA C001 19	Bolt Master KAC	4	4	
4	JF 2312 08	Guard Sari	1	1	
5	KA CB06 22	Bolt Socket L-22	1	1	
6	KA CA08 18	Bolt Master KAC	2	2	
7	JL 2312 09	Plug Saree Guard	1	1	
8	JF 2312 11	Plug Saree Guard	2	2	
9	JL 2316 00	Mirror Assly LH	1	1	
10	JL 2316 01	Mirror Assly RH	1	1	
11	JF 2312 16	Guard Leg LH	1	1	
12	JF 2312 17	Guard Leg RH	1	1	
13	LD B000 76	Washer Plain	3	3	
14	LA C001 10	Bolt Socket - M6 x 1 x L35	2	2	
15	LA C001 09	Bolt Socket - M6x1xL10	1	1	
16	LC H000 04	Nut Nyloc - M8 x 1.25 x HT8	1	1	

Painted Parts and Decals



No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	JF 1710 22	Tank Central Cover	1	1	
2	56 JF22 W3	Tank Cover Top	1	1	Classic White
	56 JF22 1U	Tank Cover Top	1	1	Plum Red
	56 JF22 1V	Tank Cover Top	1	1	Twilight Blue
	56 JF22 8T	Tank Cover Top	1	1	Graphite Matt Black
3	JF 1710 19	Tank Cap Cover	1	1	
4	56 JF14 W3	Side Mask LH	1	1	Classic White
	56 JF14 1U	Side Mask LH	1	1	Plum Red
	56 JF14 1V	Side Mask LH	1	1	Twilight Blue
	56 JF14 8T	Side Mask LH	1	1	Graphite Matt Black
5	56 JF15 W3	Side Mask RH	1	1	Classic White
	56 JF15 1U	Side Mask RH	1	1	Plum Red
	56 JF15 1V	Side Mask RH	1	1	Twilight Blue
	56 JF15 8T	Side Mask RH	1	1	Graphite Matt Black
6	56 JF20 W3	Tank Side Cover LH	1	1	Classic White
	56 JF20 1U	Tank Side Cover LH	1	1	Plum Red
	56 JF20 1V	Tank Side Cover LH	1	1	Twilight Blue
	56 JF20 8T	Tank Side Cover LH	1	1	Graphite Matt Black
7	56 JF21 W3	Tank Side Cover RH	1	1	Classic White
	56 JF21 1U	Tank Side Cover RH	1	1	Plum Red
	56 JF21 1V	Tank Side Cover RH	1	1	Twilight Blue
	56 JF21 8T	Tank Side Cover RH	1	1	Graphite Matt Black
8	52 JF02 97	Side Cover LH	1	1	
	56 JF2B 4X	Side Cover LH Satin Black	1	1	
9	52 JF03 02	Side Cover RH	1	1	
	56 JF2C 4X	Side Cover RH Satin Black	1	1	

Painted Parts and Decals



No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
10	52 JF03 05	Assembly Seat Cowl LH	1	1	Classic White Plum Red Twilight Blue
	52 JF02 95	Assembly Seat Cowl LH	1	1	
	52 JF03 00	Assembly Seat Cowl LH	1	1	
	52 JF06 28	Seat Cowl LH Ebony Black	1	1	
11	52 JF03 06	Assembly Seat Cowl RH	1	1	Classic White Plum Red Twilight Blue
	52 JF02 96	Assembly Seat Cowl RH	1	1	
	52 JF03 01	Assembly Seat Cowl RH	1	1	
	52 JF06 29	Seat Cowl RH Ebony Black	1	1	
12	52 JF03 04	Assembly Front Fender	1	1	Classic White Plum Red Plum Red Twilight Blue
	52 JF02 94	Assembly Front Fender	1	--	
	52 JF03 20	Assembly Front Fender	--	1	
	52 JF02 99	Assembly Front Fender	1	1	
	52 JF06 26	Front Fender Satin Black	1	--	
	52 JF06 27	Front Fender Satin Black	--	1	
13	36 JF00 71	Kit DCL F Fender P White	1	--	
	36 JF00 76	Kit DCL F Fender P White	--	1	
	36 JF00 67	Kit DCL F Fender Plum Red	1	--	
	36 JF00 74	Kit DCL F Fender Plum Red	--	1	
	36 JF00 69	Kit DCL F Fender T Blue	1	--	
	36 JF00 75	Kit DCL F Fender T Blue	--	1	
14	36 JF00 68	Kit Dcl Seat Cowl Plum Red	1	1	
	36 JF00 70	Kit Dcl Seat Cowl T Blue	1	1	
15	JF 2330 99	Decal Cowl Seat Bottom 3D	2	2	
16	JF 2331 18	Decal Tank 3D Dominar	2	2	
17	56 JF24 6B	Shorud LH Moon Light Silver	1	1	
18	56 JF25 6B	Shroud RH Moon Light Silver	1	1	

Consumable Parts

1		2		3	
4		5		6	
7		8		9	
10		11		12	

No.	Part No.	Description	Supply Unit	Application
1	36 0010 61 83 0204 11 83 0203 34	Bajaj Genuine Oil 10W50 Bajaj Genuine Oil 10W30 Bajaj Genuine Oil 20W50 (BGO to be ordered to HPCL)	1.5 Ltr. 1 Ltr. 1 Ltr.	Dominar 400 100cc Models 125cc and above models
2	36 0010 58	Bajaj Coolant Koolex	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61 83 0203 25	Brake Fluid DOT4 Brake Fluid DOT3	100 ml 100 ml	Disc Brake Top-up/Replace Disc Brake Top-up/Replace
4	36 0010 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 83 0203 68	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 0010 52	HP Lithon RR Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04	Fork oil	160 ml	Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

Consumable Parts

13		14		15	
16		17		18	
19		20		21	
22		23		24	

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray		For Cleaning Carburetor
24	37 2540 39	Corrosion Protection Spray Proto quick LTP902 (To be ordered on Vendor)	--	For Preventing vehicle parts from rusting

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JF0050	ASSEMBLY CYLINDER HEAD	JF511016	CYLINDER HEAD COMPLETE	1
			JG511046	STUD (M8*1.25)	2
			JF511050	CAM GALLERY PLUG	1
			JY601214	PIPE COOLANT	1
			JY511073	PLUG	1
			39156806	SLEEVE - SPRING DOWEL	2
2	36JF0051	ASSEMBLY CRANKCASE LH	BA102003	PLUG - OIL HOLE	1
			JC101077	PLUG TAPER	2
			DT541009	CRANKCASE LH	1
			JF541016	NOZZLE	1
			JY541034	BUSH STARTER SHAFT	2
			JY541024	JET EVACUATION OIL	1
			JY541050	JET OIL	1
			JY541038	BUSH	1
			JY541052	JET TRANS	1
			JF541017	BRACKET	1
			LBB00007	SCREW PAN CROSS - M6x1xL12	1
3	36JF0052	ASSEMBLY CRANKCASE RH	JF541013	CRANKCASE RH SUB ASSEMBLY (PLUG + BREATHER PIPE)	1
			JY541023	BUSH CRANKSHAFT	1
			39256220	NEEDLE ROLLER BEARING	1
			JY541038	BUSH	1
			JY541018	BUSH INSERT	1
			JG601007	SPECIAL SHAFT SEAL RING (OIL)	2
			LEB00001	CIRCLIP INTERNAL	1
4	36JF0053	ASSEMBLY CLUTCH COVER WITH NOZEL	DT541204	CLUTCH COVER WITH PLUG	1
			39199020	BEARING - NEEDLE	1
			JG541021	OIL NOZZLE	2
5	36JF0054	PRIMARY DRIVE & DRIVEN	JY551212	GEAR PRIMARY DRIVE	1
			JF551412	CLUTCH OUTER COMPLETE	1
6	36JF0055	CHAIN GUIDE	JF511229	CHAIN GUIDE SLACK SIDE	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			JF511230	CHAIN GUIDE TIGHT SIDE	1
7	36JF0056	CHAIN SPROCKET	JG131236	SPROCKET 45T (6 MTG)	1
			JY551029	SPROCKET DRIVE	1
			JF141001	CHAIN DRIVE - K10	1
8	36JF0057	ENGINE GASKET	JY521006	GASKET CYLINDER BLOCK	1
			JY541225	GASKET CLUTCH COVER	1
			JF541209	GASKET MAGNETO COVER	1
			JF511046	HEAD COVER GASKET	1
			JF511049	GASKET CYLINDER HEAD	1
			CS101128	GASKET	1
			JG591070	GASKET EXHAUST	1
9	36JF0058	VALVE REPAIR	JF511236	VALVE SPRING	4
			JY511225	RETAINER VALVE SPRING	4
			JY511231	SHIM	4
			CB101022	COTTER VALVE	8
			CB101009	SEAL VALVE STEM	4
			JY511223	SEAT VALVE SPRING	4
10	36JF0059	BLOCK PISTON	JF521008	CYLINDER BLOCK	1
			JF521210	PISTON ASSEMBLY	1
11	36JF0060	PISTON RING SET	JF521215	RING PISTON TOP	1
			JF521212	RING PISTON SECOND	1
			JF521213	RING PISTON OIL	1
12	36JF0061	STEERING CONE	DG181005	BEARING CONE	1
			DG181045	BEARING CONE UPPER	1
			DG181046	BEARING RACE UPPER	1
			DG181047	BEARING RACE LOWER	1
13	36JF0064		JF131810	HOSE ABS TO FR MASTER CYL.	1
14	36JF0065		JF131811	HOSE ABS TO FR CALIPER	1
15	36JF0066		JF131812	HOSE ABS TO RR MASTER CYL.	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
16	36JF		JF131813	HOSE ABS TO RR CALIPER	1
17	36JF0062	CYLINDER COMPLETE FORK	JF121040	CAP OIL LOCK	1
			JF121041	SEAT PIPE	1
			DT121010	PISTON RING	1
			DT121009	BUSH SLIDE	1
			DT121011	SPRING REBOUND	1
18	36JF0063	FORK OIL SEALS	JP121018	FORK OIL SEAL SKF	1
			DT121018	OIL SEAL STOPPER	1
			JP121019	FORK DUST SEAL SKF	1
19	DT541203	MAGNETO COVER - ASSEMBLY CPL	DT541209	MAGNETO COVER WITH PLUG	1
			JG541232	CAP TDC FINDER	1
			30101195	O-RING(15.8X2.4)	1
			JL541223	LABEL B-BAJAJ	1
			JY541034	BUSH STARTER SHAFT	2
			JG541074	OIL NOZZLE	1
20	36DT0004	TIE BAND-W HARNESS	JD402212	BAND 200 MM	8
			JD402217	BAND 150 MM	2
			PA402204	BAND 110 MM	2
21	JF232611	LOCK SET 3 IN 1	DT401405	IGNITION SWITCH	1
			JL232600	LOCK -SIDE	1
			JF171612	FUEL TANK CAP - K10	1
			JL232601	KEY SET FOR K4	1
22	36JF0077	FRICTION PLATE A + B	JF551416	FRICTION PLATE A	4
			JF551417	FRICTION PLATE B	3
23	36JF0067	DCL F FENDER PLUM RED	JF233093	DECAL FENDER-FRONT-LH-ABS	1
			JF233094	DECAL FENDER-FRONT-RH-ABS	1
24	36JF0068	DCL S COWL PLUM RED	JF233095	DECAL COWL-SEAT-LH	1
			JF233096	DECAL COWL-SEAT-RH	1
25	36JF0069	DCL F FENDER T BLUE	JF233100	DECAL FRONT FENDER LH - ABS	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			JF233101	DECAL FRONT FENDER RH - ABS	1
26	36JF0070	DCL S COWL T BLUE	JF233102	DECAL COWL SEAT- LH	1
			JF233103	DECAL COWL SEAT - RH	1
27	36JF0071	DCL F FENDER P WHITE	JF233104	DECAL FRONT FENDER LH - ABS	1
			JF233105	DECAL FRONT FENDER RH - ABS	1
28	36JF0072	DCL S COWL P WHITE	JF233106	DECAL COWL SEAT- LH	1
			JF233107	DECAL COWL SEAT- RH	1
29	36JF0073	DCL TANK SIDE COVER	JF233097	DECAL TANK SIDE COVER - LH	1
			JF233098	DECAL TANK SIDE COVER-RH	1
30	36JF0074	DCL F FENDER PLUM RED NON ABS	JF233108	DECAL FENDER FRONT LH - NON ABS	1
			JF233109	DECAL FENDER FRONT RH - NON ABS	1
31	36JF0075	DCL F FENDER T BLUE-NON ABS	JF233110	DECAL FENDER FRONT LH - NON ABS	1
			JF233111	DECAL FENDER FRONT RH - NON ABS	1
32	36JF0076	DCL F FENDER P WHITE - NON ABS	JF233113	DECAL FENDER FRONT RH - NON ABS	1
			JF233112	DECAL FENDER FRONT LH - NON ABS	1
33	36JY0103	KIT FRICTION PLATE	JY551418	DISC FRICTION- A	4
			JY551420	DISC FRICTION - C	3
34	36JU0019	Kit Fork Oil seal	JG121013	SEAL OIL	1
			JG121011	INNER DUST SEAL	1

DOMINAR 400

[illegible]

DOMINAR 400

[illegible]

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
01 1009 05	10	22	36 JF00 55	13	12
30 1011 95	3	40	36 JF00 56	6	82
30 1410 31	10	64	36 JF00 57	12	24
30 1510 82	13	82	36 JF00 58	8	6
30 1910 38	14	80	36 JF00 59	1	14
31 1011 73	5	50	36 JF00 60	4	14
36 0010 52	4	122	36 JF00 62	12	88
36 0010 52	6	122	36 JF00 63	7	88
36 0010 55	8	122	36 JF00 64	2	78
36 0010 56	23	124	36 JF00 65	3	78
36 0010 58	2	122	36 JF00 66	4	78
36 0010 60	18	124	36 JF00 67	13	120
36 0010 61	1	122	36 JF00 68	14	120
36 0010 62	9	122	36 JF00 69	13	120
36 3140 04	10	122	36 JF00 70	14	120
36 DH19 02	4	74	36 JF00 71	13	120
36 DH40 29	11	122	36 JF00 74	13	120
36 DH40 61	3	122	36 JF00 75	13	120
36 DH40 71	12	122	36 JF00 76	13	120
36 DH40 72	13	124	36 JF00 78	5	78
36 DT00 04	3	110	36 JF00 79	3	80
36 DT00 34	14	74	36 JF00 80	12	74
36 DT00 36	9	74	36 JF00 81	16	74
36 DT00 40	18	80	36 JF00 82	17	74
36 DT00 52	23	80	36 JF00 83	9	76
36 DV00 08	2	60	36 JF00 84	10	76
36 JF00 50	1	4	36 JF00 85	17	80
36 JF00 51	1	26	36 JF00 85	24	80
36 JF00 52	1	24	36 JF00 86	20	80
36 JF00 54	13	16	36 JF00 87	6	80
36 JF00 54	2	42	36 JF00 88	9	76

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 JF00 89	40	8	36 JY00 40	28	6
36 JF00 90	42	8	36 JY00 41	30	8
36 JF00 91	44	8	36 JY00 42	32	8
36 JF00 92	46	8	36 JY00 43	34	8
36 JF00 93	48	8	36 JY00 44	36	8
36 JF00 94	50	8	36 JY00 45	38	8
36 JF00 95	52	8	36 JY00 46	39	8
36 JF00 96	54	8	36 JY00 47	41	8
36 JF00 97	56	8	36 JY00 48	43	8
36 JF00 98	58	10	36 JY00 49	45	8
36 JF00 99	59	10	36 JY00 50	47	8
36 JF01 00	60	10	36 JY00 51	49	8
36 JF01 01	61	10	36 JY00 52	51	8
36 JF01 02	62	10	36 JY00 53	53	8
36 JF01 03	63	10	36 JY00 54	55	8
36 JF01 04	64	10	36 JY00 55	57	8
36 JF01 05	65	10	36 JY00 56	21	6
36 JL00 39	3	30	36 JY00 57	23	6
36 JU00 15	21	112	36 JY00 58	25	6
36 JU00 19	31	90	36 JY00 59	27	6
36 JY00 29	13	6	36 JY00 60	29	6
36 JY00 30	14	6	36 JY00 61	31	8
36 JY00 31	15	6	36 JY00 62	33	8
36 JY00 32	16	6	36 JY00 63	35	8
36 JY00 33	17	6	36 JY00 64	37	8
36 JY00 34	18	6	36 JY01 02	24	18
36 JY00 35	19	6	36 JY01 03	7	42
36 JY00 36	20	6	36 PD00 38	15	74
36 JY00 37	22	6	37 0043 52	16	124
36 JY00 38	24	6	37 0043 53	17	124
36 JY00 39	26	6	37 2240 18	19	124

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
37 2540 39	24	124	39 2440 11	10	6
39 0198 11	15	48	39 2562 20	4	24
39 0198 11	18	48	39 2562 20	22	26
39 0198 11	15	80	39 2601 20	5	24
39 0219 11	16	46	39 2606 07	5	16
39 0255 11	20	104	39 2606 07	4	20
39 0326 15	13	66	39 2606 07	7	30
39 0422 15	6	68	39 2608 01	16	4
39 0808 08	16	80	39 2723 15	10	58
39 0849 14	16	52	52 JF00 62	12	22
39 0999 06	3	32	52 JF02 94	12	120
39 0999 06	10	40	52 JF02 95	10	118
39 1041 19	3	38	52 JF02 96	11	118
39 1043 19	6	26	52 JF02 97	8	118
39 1053 15	13	62	52 JF02 99	12	120
39 1283 21	18	4	52 JF03 00	10	118
39 1501 11	11	104	52 JF03 01	11	118
39 1537 21	7	38	52 JF03 02	9	118
39 1568 06	17	4	52 JF03 04	12	120
39 1665 11	9	30	52 JF03 05	10	118
39 1864 20	6	24	52 JF03 06	11	118
39 1907 01	9	96	52 JF03 20	12	120
39 1913 04	2	54	52 JF03 28	6	52
39 1990 20	2	38	52 JF03 48	6	22
39 1998 19	3	84	52 JY06 67	8	52
39 2005 11	20	24	56 JF14 1U	4	118
39 2016 19	12	38	56 JF14 1V	4	118
39 2038 04	15	82	56 JF14 W3	4	118
39 2181 06	2	14	56 JF15 1U	5	118
39 2181 06	25	28	56 JF15 1V	5	118
39 2185 20	3	24	56 JF15 W3	5	118

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 JF18 1Y	7	64	CB 1010 09	1	6
56 JF19 1Y	13	64	CB 1010 22	7	6
56 JF20 1U	6	118	CS 1011 28	9	12
56 JF20 1V	6	118	DD 1110 11	12	54
56 JF20 W3	6	118	DD 1110 12	6	54
56 JF21 1U	7	118	DE 1510 46	2	76
56 JF21 1V	7	118	DE 1510 46	10	80
56 JF21 W3	7	118	DE 1510 47	3	76
56 JF22 1U	2	118	DE 1510 47	9	80
56 JF22 1V	2	118	DE 1910 10	10	74
56 JF22 W3	2	118	DE 1910 10	8	80
56 JF24 6B	22	34	DE 1910 10	12	78
56 JF25 6B	23	34	DE 1910 28	7	74
56 JF3S 1Y	2	64	DE 1910 29	6	74
56 JF3T 1Y	12	64	DF 1611 02	5	68
56 JF3X 1Y	1	64	DG 1012 75	10	16
56 JF3Y 1Y	11	64	DG 1410 28	13	92
62 3050 84	22	124	DG 1510 05	4	72
75 6802 36	20	124	DG 1710 16	4	62
76 0109 36	14	124	DG 1710 18	5	62
76 0109 37	15	124	DG 1710 19	6	62
83 0201 73	7	122	DG 1810 03	5	60
83 0203 25	3	122	DG 1810 04	6	60
83 0203 34	1	122	DH 1012 95	9	6
83 0203 68	5	122	DH 1110 13	9	54
83 0204 11	1	122	DH 1110 16	11	54
83 0204 73	5	122	DH 1611 46	13	68
AA 1014 37	9	24	DH 1611 55	17	64
AA 1014 37	16	26	DH 1611 57	18	64
AA 1014 37	14	38	DH 1910 67	5	86
AN 1110 15	8	54	DH 1910 68	10	86

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DJ 1510 74	6	76	DP 1011 91	13	24
DJ 1510 75	7	76	DP 1611 45	17	108
DJ 1610 69	4	66	DP 2210 11	3	114
DJ 1610 91	8	66	DS 1011 54	12	30
DJ 1612 29	4	98	DS 1012 15	11	38
DJ 1810 65	33	36	DS 1611 25	3	66
DJ 1910 29	2	74	DS 1612 87	7	56
DJ 1910 30	3	74	DT 1111 34	1	60
DJ 1910 31	5	74	DT 1130 14	9	64
DJ 2011 73	16	108	DT 1130 15	14	64
DK 1012 25	10	4	DT 1132 05	2	68
DK 1012 84	3	52	DT 1138 25	14	110
DK 1013 40	11	4	DT 1138 27	11	58
DK 1110 28	4	54	DT 1138 48	14	62
DK 1510 26	2	70	DT 1138 49	15	94
DK 1510 45	19	80	DT 1138 50	6	78
DK 1510 63	7	80	DT 1138 51	14	110
DK 1510 69	11	74	DT 1138 56	15	46
DK 1510 69	4	80	DT 1210 01	2	88
DK 1510 69	13	78	DT 1210 02	3	88
DK 1510 74	18	80	DT 1210 13	9	88
DK 1510 81	19	82	DT 1210 15	8	88
DK 1510 82	18	82	DT 1210 16	6	88
DK 1510 85	13	80	DT 1210 20	14	88
DK 1510 86	23	80	DT 1210 21	15	88
DK 1810 07	5	88	DT 1220 17	1	62
DK 1810 25	21	88	DT 1310 17	10	72
DK 1810 50	3	60	DT 1312 10	8	82
DK 1810 51	4	60	DT 1312 13	7	82
DK 1810 75	27	90	DT 1318 67	8	72
DK 2110 07	6	56	DT 1318 75	10	78

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 1318 78	14	78	DT 5810 28	4	46
DT 1710 61	12	92	DT 5810 62	9	46
DT 1710 78	16	92	DT 5810 72	6	46
DT 1710 87	9	92	DT 5810 74	13	46
DT 1710 89	8	92	DT 5810 79	14	46
DT 1718 14	10	92	DT 5814 01	12	4
DT 1718 34	2	94	DT 6012 18	9	34
DT 1718 39	6	92	DT 6012 19	13	34
DT 1810 07	8	98	FD 2110 06	3	56
DT 1810 22	27	112	JA 5410 48	13	26
DT 1813 06	7	104	JB 4010 12	14	100
DT 1813 07	13	48	JC 1010 85	2	12
DT 1813 08	5	102	JC 1010 86	3	12
DT 1814 33	12	66	JC 1910 09	4	84
DT 2314 07	1	116	JD 1318 11	9	72
DT 2314 10	2	116	JD 1910 06	9	56
DT 2326 01	21	86	JD 3512 07	7	54
DT 2326 05	12	56	JF 1111 75	5	58
DT 3518 00	14	26	JF 1111 79	8	60
DT 3518 03	8	44	JF 1130 03	1	64
DT 4010 02	1	106	JF 1130 12	4	64
DT 4010 03	2	106	JF 1130 14	19	64
DT 4010 20	19	104	JF 1130 15	11	64
DT 4010 21	1	108	JF 1132 04	1	68
DT 4022 26	12A	110	JF 1134 14	1	58
DT 4024 04	11	72	JF 1134 15	2	58
DT 5312 00	1	30	JF 1138 16	28	112
DT 5412 02	7	40	JF 1138 17	15	56
DT 5412 03	1	40	JF 1138 18	9	98
DT 5412 04	1	38	JF 1138 21	11	60
DT 5612 05	14	22	JF 1138 28	10	60

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 1138 41	4	58	JF 1318 51	11	84
JF 1138 42	16	110	JF 1318 53	32	90
JF 1210 19	30	90	JF 1318 54	15	78
JF 1210 29	1	88	JF 1318 57	1	76
JF 1210 29	25	90	JF 1318 58	1	80
JF 1210 30	18	86	JF 1510 41	1	86
JF 1210 33	16	88	JF 1510 42	12	86
JF 1210 34	23	90	JF 1510 43	17	86
JF 1210 35	24	90	JF 1510 44	16	86
JF 1210 36	11	88	JF 1510 45	14	86
JF 1210 37	13	88	JF 1510 47	15	86
JF 1210 38	10	88	JF 1510 48	28	90
JF 1210 45	29	90	JF 1610 04	5	84
JF 1220 13	2	62	JF 1610 06	1	84
JF 1220 14	4	82	JF 1610 07	8	84
JF 1220 15	8	62	JF 1610 08	2	86
JF 1220 16	10	62	JF 1612 04	2	102
JF 1220 48	11	62	JF 1612 05	1	102
JF 1220 49	7	62	JF 1612 07	3	102
JF 1310 12	3	70	JF 1612 08	4	102
JF 1310 12	1	72	JF 1710 19	3	118
JF 1310 24	2	72	JF 1710 22	8	96
JF 1312 17	4	70	JF 1710 22	1	118
JF 1312 17	1	82	JF 1710 23	18	92
JF 1312 30	2	82	JF 1710 24	19	92
JF 1318 14	2	80	JF 1710 25	20	92
JF 1318 15	1	78	JF 1710 26	21	92
JF 1318 16	1	74	JF 1710 28	10	96
JF 1318 17	7	72	JF 1710 29	13	96
JF 1318 46	7	72	JF 1710 33	1	92
JF 1318 50	1	76	JF 1710 35	1	96

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 1710 36	2	96	JF 1813 07	12	108
JF 1710 37	16	96	JF 1813 08	23	112
JF 1710 43	6	96	JF 1813 09	11	48
JF 1710 47	14	96	JF 1813 14	10	48
JF 1710 48	12	96	JF 1813 16	6	102
JF 1710 55	15	92	JF 1813 20	25	92
JF 1710 56	24	92	JF 1813 23	20	48
JF 1710 57	17	96	JF 1813 24	21	48
JF 1710 58	18	96	JF 1814 20	2	108
JF 1716 03	14	94	JF 1814 21	4	108
JF 1716 04	11	94	JF 1814 22	7	108
JF 1716 05	6	94	JF 1814 24	10	108
JF 1716 06	8	94	JF 1814 29	7	66
JF 1716 07	12	94	JF 1814 32	14	66
JF 1716 13	16	94	JF 1814 33	6	66
JF 1718 02	4	92	JF 1814 34	5	66
JF 1812 57	19	34	JF 1910 09	1	56
JF 1812 62	27	36	JF 1910 12	8	56
JF 1812 65	5	100	JF 2312 08	4	116
JF 1812 66	13	104	JF 2312 11	8	116
JF 1812 67	10	104	JF 2312 16	11	116
JF 1812 68	9	104	JF 2312 17	12	116
JF 1812 69	6	100	JF 2326 11	23	86
JF 1812 70	9	100	JF 2326 11	22	92
JF 1812 71	4	104	JF 2326 11	2	92
JF 1812 73	22	112	JF 2330 36	9	40
JF 1812 75	17	104	JF 2330 99	15	120
JF 1812 76	18	104	JF 2331 18	16	120
JF 1812 83	19	88	JF 3510 11	2	52
JF 1812 84	18	88	JF 3510 13	1	52
JF 1812 85	17	88	JF 3512 06	13	54

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 3512 08	3	54	JF 5112 33	4	6
JF 3512 10	1	54	JF 5112 34	5	6
JF 3512 12	10	54	JF 5112 35	7	12
JF 3514 05	7	52	JF 5112 40	6	12
JF 3516 00	1	50	JF 5112 49	10	12
JF 4014 05	11	68	JF 5213 00	5	14
JF 4014 10	4	86	JF 5310 17	8	16
JF 4014 11	8	86	JF 5310 20	12	16
JF 4020 04	4	52	JF 5310 21	1	16
JF 4022 11	6	110	JF 5312 13	15	30
JF 4022 12	5	110	JF 5410 16	30	28
JF 4022 34	10	52	JF 5410 17	23	28
JF 4022 35	1	110	JF 5412 04	16	38
JF 4022 45	1	110	JF 5412 08	6	38
JF 4024 06	1	100	JF 5412 10	5	38
JF 4024 07	5	96	JF 5515 00	10	42
JF 4024 07	13	100	JF 5610 00	5	20
JF 4024 09	1	100	JF 5610 01	8	20
JF 4024 10	5	96	JF 5614 08	13	22
JF 4024 10	13	100	JF 5614 10	11	22
JF 4024 13	8A	72	JF 5810 20	1	46
JF 5010 11	2	24	JF 5810 22	3	46
JF 5110 41	1	2	JF 5810 26	7	46
JF 5110 42	6	6	JF 5910 33	7	48
JF 5110 46	2	2	JF 5910 65	4	48
JF 5110 49	7	4	JF 5911 16	1	48
JF 5110 52	14	4	JF 5911 20	5	48
JF 5112 04	2	6	JF 5911 34	3	48
JF 5112 08	3	6	JF 5911 35	2	48
JF 5112 22	1	12	JF 6012 02	12	34
JF 5112 23	12	12	JF 6012 03	7	34

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 6012 05	1	34	JG 4022 34	13B	110
JF 6112 01	3	44	JG 5110 20	9	4
JF 6112 01	7	92	JG 5110 21	5	2
JF 6112 03	1	44	JG 5110 46	2	4
JG 1310 01	6	72	JG 511010	6	48
JG 1310 38	1	70	JG 5112 69	8	12
JG 1312 20	17	82	JG 5310 40	4	16
JG 1312 28	22	82	JG 5312 15	4	30
JG 1312 45	5	70	JG 5412 30	8	38
JG 1318 21	5	80	JG 5412 32	4	40
JG 1510 22	9	86	JG 5610 08	6	20
JG 1610 08	3	86	JG 5610 09	21	24
JG 1610 10	8	74	JG 5610 10	3	20
JG 1710 29	26	36	JG 5612 04	23	24
JG 1710 86	7	94	JG 5612 05	22	24
JG 1716 01	3	94	JG 5612 15	9	20
JG 1812 39	22	80	JG 5612 15	2	22
JG 1812 59	32	36	JG 5612 16	5	22
JG 1812 59	15	96	JG 5612 17	3	22
JG 1910 08	2	56	JG 5612 18	4	22
JG 2310 01	1	114	JG 5612 22	1	20
JG 2310 02	2	114	JG 5612 26	19	24
JG 3510 19	18	52	JG 5710 14	14	24
JG 3514 00	8	4	JG 5710 16	15	24
JG 3518 05	6	44	JG 5814 23	9	44
JG 4010 06	8	108	JG 5814 24	4	44
JG 4010 36	13	108	JG 5814 37	7	44
JG 4020 02	4	110	JG 5910 70	3A	48
JG 4022 28	13A	110	JG 6010 05	5	30
JG 4022 29	12B	110	JG 6010 07	10	24
JG 4022 30	12C	110	JG 6010 12	6	30

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JG 6010 14	18	34	JL 1318 34	1	80
JG 6010 16	10	34	JL 1318 78	21	64
JG 6012 09	6	34	JL 1319 30	14	82
JG 6012 10	8	34	JL 1510 23	13	56
JG 6012 11	21	34	JL 1510 35	6	86
JG 6012 13	25	34	JL 1710 19	11	92
JG 6012 35	4	34	JL 1710 20	17	92
JG 6012 37	14	34	JL 1810 27	9	60
JG 6112 06	5	44	JL 1812 56	16	34
JH 1812 55	6	98	JL 1910 17	4	56
JH 5812 02	2	46	JL 1910 17	10	56
JK 1910 05	5	56	JL 2312 09	7	116
JL 1130 00	2	64	JL 2316 00	9	116
JL 1130 07	12	64	JL 2316 01	10	116
JL 1130 14	7	64	JL 2326 04	14	56
JL 1130 16	13	64	JL 3512 18	5	54
JL 1130 36	8	64	JL 4014 06	6	84
JL 1132 09	4	68	JL 4022 19	19	4
JL 1138 09	7	60	JL 4030 00	2	110
JL 1138 18	12	68	JL 4032 00	7	110
JL 1138 25	26	112	JL 5412 22	9	38
JL 1220 26	12	62	JL 5412 23	2	40
JL 1310 00	3	72	JL 5412 27	10	38
JL 1312 11	5	82	JL 5614 09	9	22
JL 1312 16	11	82	JL 5614 10	8	22
JL 1312 20	6	80	JL 5710 01	16	24
JL 1318 05	5	76	JL 6010 05	8	30
JL 1318 07	4	76	JL 6010 10	11	24
JL 1318 31	6	76	JL 6012 13	24	34
JL 1318 31	7	76	JL 6012 15	28	36
JL 1318 32	5	76	JL 6012 16	15	34

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JL 6012 35	20	34	JY 5410 82	19	26
JM 1910 14	7	84	JY 5412 08	14	52
JN 3516 04	11	110	JY 5412 20	13	38
JP 5810 18	11	46	JY 5412 22	13	52
JU 1312 22	9	82	JY 5412 25	15	38
JU 1318 02	16	82	JY 5412 76	5	40
JU 2328 00	1	104	JY 5510 05	15	18
JW 1710 15	17	34	JY 5510 06	10	18
JY 1138 42	10	94	JY 5510 08	12	18
JY 1210 11	19	86	JY 5510 10	3	18
JY 1710 69	4	94	JY 5510 18	23	18
JY 1710 70	9	94	JY 5510 21	6	18
JY 1710 77	1	94	JY 5510 22	1	18
JY 1710 90	5	94	JY 5510 27	17	18
JY 1718 25	13	94	JY 5510 29	25	18
JY 1812 55	19	48	JY 5510 30	26	18
JY 1812 84	30	36	JY 5512 05	20	18
JY 4010 24	6	106	JY 5512 12	6	16
JY 4010 25	7	106	JY 5512 14	4	18
JY 4014 04	24	86	JY 5512 15	9	18
JY 4022 35	23	92	JY 5512 17	22	18
JY 4036 04	15	110	JY 5512 18	18	18
JY 5210 06	3	14	JY 5512 25	3	50
JY 5310 08	9	16	JY 5512 26	4	50
JY 5410 09	14	12	JY 5512 28	8	18
JY 5410 31	9	26	JY 5512 29	5	18
JY 5410 40	7	50	JY 5512 30	2	18
JY 5410 47	8	24	JY 5512 31	7	18
JY 5410 58	7	26	JY 5512 32	21	18
JY 5410 80	18	26	JY 5512 33	11	18
JY 5410 81	17	26	JY 5512 34	16	18

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JY 5512 35	14	18	JY 6012 41	5	34
JY 5512 36	19	18	JY 6012 48	2	34
JY 5512 37	13	18	JY 6012 49	3	34
JY 5514 01	1	42	JY 6110 00	2	44
JY 5514 02	19	52	JY 6214 11	6	50
JY 5514 03	3	42	JZ 1318 75	9	84
JY 5514 04	14	42	JZ 1710 55	13	60
JY 5514 35	4	42	JZ 1812 71	5	98
JY 5514 36	8	42	JZ 1813 65	2	100
JY 5514 37	9	42	JZ 2328 05	15	108
JY 5514 38	13	42	JZ 2328 14	8	104
JY 5514 39	15	42	JZ 4036 01	3	68
JY 5514 41	6	42	KA AC08 25	9	66
JY 5514 42	5	42	KA CA06 35	14	48
JY 5514 43	16	42	KA CA08 18	6	116
JY 5610 02	11	20	KA CB06 22	5	116
JY 5610 04	7	20	KA CD05 16	3	92
JY 5610 08	10	20	KA CF06 12	17	46
JY 5612 05	1	22	KA CF06 12	17	48
JY 5710 08	3	26	KA CF06 12	17	110
JY 5710 09	5	26	KA CF10 30	4	88
JY 5710 12	6	32	KA CM10 35	22	88
JY 5710 15	1	32	KA DA05 10	3	96
JY 5710 23	7	32	KA DA06 10	18	108
JY 5710 24	5	32	KA DA08 14	10	110
JY 5710 29	28	28	KA DB05 16	10	68
JY 5710 30	11	26	KA DD06 14	21	80
JY 5810 28	8	46	KA DF06 25	11	56
JY 5810 28	10	46	KA DM06 16	20	64
JY 5810 28	12	46	KA DM06 22	7	22
JY 6012 15	11	34	KA DQ06 25	2	50

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KA DW08 20	14	92	KE BB42 17	4	12
KA DW10 B0	9	58	KH AA20 15	10	84
KA EA06 10	12	60	KH AA25 20	6	64
KA ED06 08	8	78	KH DA03 06	5	12
KA ED06 12	7	78	KJ AC18 24	15	4
KA ED06 22	24	112	KP AC62 05	21	82
KA ED06 25	25	112	KP BC62 02	5	72
KA ED06 30	5	52	KP BC62 02	10	82
KA EW06 16	17	24	KP BC63 02	12	82
KA EW06 20	11	12	KP BF63 04	7	24
KA EW06 35	26	28	KP BF63 04	2	30
KA EW06 35	17	38	LA C000 08	12	48
KA EW06 35	6	40	LA C000 08	18	110
KA EW06 50	8	40	LA C000 24	2	20
KA EW08 35	3	58	LA C000 54	7	102
KAE W06 25	11	78	LA C000 78	15	64
KB BA05 12	22	64	LA C000 79	16	64
KB BP05 30	5	104	LA C000 86	14	30
KB UA06 14	14	104	LA C000 91	13	86
KB UA06 30	5	46	LA C000 99	9	48
KB UB05 08	8	100	LA C001 05	3	62
KC AA05 04	4	100	LA C001 06	3	4
KC AM08 06	9	62	LA C001 07	4	4
KC GA06 06	9	52	LA C001 08	11	66
KC GC06 06	20	110	LA C001 09	15	116
KD AA05 10	6	104	LA C001 10	14	116
KD AA08 16	5	64	LA C001 11	11	86
KD AE05 10	2	66	LA C001 19	3	116
KD BA05 12	7	100	LA C001 22	17	52
KE AB10 10	9	32	LA C001 25	7	86
KE BA37 15	8	26	LA D000 37	13	74

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LA D000 63	15	26	LB C000 03	13	4
LA D000 77	22	86	LB R000 03	9	108
LA D001 02	10	100	LB R000 10	7	96
LA D001 24	12	52	LB U000 53	29	36
LA D001 41	3	2	LB U000 55	16	48
LA D001 42	4	2	LB U000 55	16	104
LA D001 54	5	92	LB U000 65	11	96
LA D001 63	12	6	LB U000 65	3	98
LA D001 66	17	42	LB U000 65	2	104
LA D001 84	8	68	LB U000 65	12	104
LA D001 93	20	88	LB U000 65	3	108
LA D001 96	6	108	LB U000 69	1	98
LA D001 98	8	76	LC A000 05	5	106
LA D002 00	9	68	LC A000 14	8	58
LA D002 02	7	98	LC G000 02	11	16
LA E000 01	18	24	LC G000 09	11	42
LA E000 02	27	28	LC G000 28	14	108
LA E000 16	15	52	LC G000 29	35	36
LA E000 17	27	18	LC G000 30	11	108
LA E000 18	4	32	LC H000 01	20	86
LA E000 21	9	78	LC H000 04	16	116
LA E000 42	8	50	LC J000 05	14	72
LA E000 48	10	30	LC J000 05	20	82
LA E000 49	36	36	LC L000 04	23	82
LA E000 54	26	92	LD A000 12	7	58
LA E000 55	31	36	LD A000 12	3	106
LA E000 55	12	72	LD A000 14	5	4
LA E000 56	11	30	LD A000 15	6	4
LB B000 07	10	26	LD A000 17	8	32
LB B000 07	24	28	LD B000 07	3	100
LB B000 15	1	66	LD B000 20	4	38

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LD B000 33	3	16	NA	21	124
LD B000 41	11	52	PA 4016 00	8	110
LD B000 51	13	30	PD 1510 06	26	90
LD B000 56	2	84	YJ F040 01	11	100
LD B000 57	13	72	YJ F040 02	12	100
LD B000 57	3	82	YJ F040 03	5	48
LD B000 68	8	48	YJ L040 05	11	80
LD B000 72	2	98	YJ L040 06	12	80
LD B000 72	15	104			
LD B000 72	5	108			
LD B000 72	19	110			
LD B000 73	9	110			
LD B000 74	4	96			
LD B000 74	3	104			
LD B000 75	34	36			
LD B000 76	13	116			
LD C000 01	6	58			
LD F000 02	4	106			
LD H000 02	2	16			
LF B000 01	7	16			
LH D000 01	2	32			
LH E000 03	3	64			
LJ A000 02	2	26			
LJ A000 02	29	28			
LJ A000 04	12	26			
LJ A000 09	11	6			
LJA00006	4	26			
LP A000 04	12	42			
LP B000 02	21	26			
LP B000 03	20	26			
NA	20	124			