

Pulsar 135LS UG, BS IV



Pulsar 135LS UG, BS IV

Bajaj Auto Limited

Akurdi, Pune - 411 035, India.

Tel : +91 20 27472851

Fax : +91 20 27407385

Toll Free : 1800 233 2453

Website : www.bajajauto.com

CIN L65993PN2007PLC130076

Spare Parts Catalogue



All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71112583

REV. 09 SEPT. 17

Copy rights : All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

Foreword

*pulsar***135LS** UG, BS IV

We have pleasure in presenting the Spare Parts Catalogue for '**Pulsar 135 LS (BS IV)**' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instructions

*pulsar***135LS** UG, BS IV

- 1. How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

- 2. How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

- 3. Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

- 4. Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

pulsar135LS UG, BS IV

[illegible]

pulsar135LS UG, BS IV

[illegible]

pulsar135LS UG, BS IV

[illegible]

pulsar135LS UG, BS IV

[illegible]

Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	SAI System	4
3	Cylinder Head	6
4	Valve	8
5	Camshaft & Tensioner	10
6	Cylinder and Piston	12
7	Crankshaft	14
8	Transmission	16
9	Change Drum & Shaft Fork	18
10	Gear Change Mechanism	20
11	Engine Assembly & Crankcase RH	22
12	Crankcase LH	24
13	Cover Clutch	26
14	Cover Magneto	28
15	Clutch Assembly	30
16	Oil Pump	32
17	Carburettor	34
18	Kick Starter Mechanism	36
19	Silencer Assembly	38
20	Air Cleaner Complete	40
21	EVAP Mechanism	42
22	Magneto, C.D.I. & H.T. Coil	44
23	Starter Assembly (For Self Start)	46
24	Frame and Frame Fitting	48
25	Engine Mountings	50
26	Swing Arm & Rear Shock Absorber	52
27	Pillion Foot Rest & Holder	54
28	Mudguard - Front & Rear	56
29	Center & Side Stand Assembly	58
30	Tube, Tyre & Rim	60

Plate No.	Description	Page No.
31	Front Wheel Assembly	62
32	Front Master Cylinder Assembly	64
33	Front Brake - Caliper & Disc	66
34	Rear Wheel Assembly	68, 70
35	Rear Brake Pedal	72
36	Handle Bar Assembly	74, 76
37	Front Fork	78, 80
38	Petrol Tank Spoiler	82
39	Petrol Tank, Cap Tank & Gauge Fuel	84
40	Fittings Petrol Tank, Side Cover & Cover Seat	86
41	Seat Assembly / Seat Lock	88
42	Speedometer Assembly	90
43	Control Cables	92
44	Leg Guards, Saree Guard & Grab Handle	94
45	Chain Case	96
46	Head Lamp & Fairing	98
47	Indicator Light Assembly	100
48	Tail Lamp Assembly & Front / Rear Number Plate	102
49	Electrical Equipments	104
50	Tool Kit	106
51	Painted Parts & Decals	108 - 114
52	Painted Parts & Decals - Cocktail wine red & saffire Blue	116 - 118
52	Consumable Parts	120 - 122
	Kits List	123 - 126
	Amendment Sheet (Parts Added)	127
	Amendment Sheet (Parts Deleted)	128
	Part Index	129 - 140

PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 1
--------------------------------------	---------------




PLATE NO. : 2 SAI SYSTEM	PAGE NO. 3
-----------------------------	---------------




PLATE NO. : 3 CYLINDER HEAD	PAGE NO. 5
--------------------------------	---------------




PLATE NO. : 4 VALVE	PAGE NO. 7
------------------------	---------------




PLATE NO. : 5 CAMSHAFT / TENSIONER	PAGE NO. 9
---------------------------------------	---------------




PLATE NO. : 6 CYLINDER & PISTON	PAGE NO. 11
------------------------------------	----------------




PLATE NO. : 7 CRANKSHAFT	PAGE NO. 13
-----------------------------	----------------




PLATE NO. : 8 TRANSMISSION	PAGE NO. 15
-------------------------------	----------------





PLATE NO. : 9 CHANGE DRUM / SHIFT FORK	PAGE NO. 17
	


PLATE NO. : 10 GEAR CHANGE MECHANISM	PAGE NO. 19
	


PLATE NO. : 11 ENGINE ASSEMBLY & CRANKCASE RH	PAGE NO. 21
	


PLATE NO. : 12 CRANKCASE LH	PAGE NO. 23
	


PLATE NO. : 13 COVER CLUTCH	PAGE NO. 25
	


PLATE NO. : 14 COVER MAGNETO	PAGE NO. 27
	


PLATE NO. : 15 CLUTCH ASSEMBLY	PAGE NO. 29
	


PLATE NO. : 16 OIL PUMP	PAGE NO. 31
	

PLATE NO. : 17
CARBURETOR

PAGE NO.
33




PLATE NO. : 18
KICK STARTER MECHANISM

PAGE NO.
35




PLATE NO. : 19
SILENCER ASSEMBLY

PAGE NO.
37




PLATE NO. : 20
AIR CLEANER COMPLETE

PAGE NO.
39




PLATE NO. : 21
EVAP MECHANISM

PAGE NO.
41




PLATE NO. : 22
MAGNETO, C.D.I. & H.T. COIL

PAGE NO.
43




PLATE NO. : 23
STARTER ASSEMBLY (FOR SELF START)

PAGE NO.
45




PLATE NO. : 24
FRAME AND FRAME FITTING

PAGE NO.
47




PLATE NO. : 25 ENGINE MOUNTINGS	PAGE NO. 49
------------------------------------	----------------




PLATE NO. : 26 SWING ARM & REAR SHOCK ABSORBER	PAGE NO. 51
---	----------------




PLATE NO. : 27 PILLION FOOT REST & HOLDER	PAGE NO. 53
--	----------------




PLATE NO. : 28 MUDGUARD - FRONT & REAR	PAGE NO. 55
---	----------------



PLATE NO. : 29 CENTER & SIDE STAND ASSEMBLY	PAGE NO. 57
--	----------------



PLATE NO. : 30 TUBE, TYRE & RIM	PAGE NO. 59
------------------------------------	----------------



PLATE NO. : 31 FRONT WHEEL ASSEMBLY	PAGE NO. 61
--	----------------




PLATE NO. : 32 FRONT MASTER CYLINDER ASSEMBLY	PAGE NO. 63
--	----------------




PLATE NO. : 33 FRONT BRAKE - CALIPER & DISC	PAGE NO. 65
--	----------------




PLATE NO. : 34 REAR WHEEL ASSEMBLY	PAGE NO. 67, 69
---------------------------------------	--------------------




PLATE NO. : 35 REAR BRAKE PEDAL	PAGE NO. 71
------------------------------------	----------------




PLATE NO. : 36 HANDLE BAR ASSEMBLY	PAGE NO. 73, 75
---------------------------------------	--------------------




PLATE NO. : 37 FRONT FORK	PAGE NO. 77, 79
------------------------------	--------------------




PLATE NO. : 38 PETROL TANK SPOILER	PAGE NO. 81
---------------------------------------	----------------




PLATE NO. : 39 PETROL TANK, CAP TANK & GAUGE FUEL	PAGE NO. 83
---	----------------




PLATE NO. : 40 FITTINGS PETROL TANK, SIDE COVER & COVER SEAT	PAGE NO. 85
--	----------------




PLATE NO. : 41 SEAT ASSEMBLY / SEAT LOCK	PAGE NO. 87
	


PLATE NO. : 42 SPEEDOMETER ASSEMBLY	PAGE NO. 89
	


PLATE NO. : 43 CONTROL CABLES	PAGE NO. 91
	


PLATE NO. : 44 LEG GUARDS, SAREE GUARD & GRAB HANDLE	PAGE NO. 93
	


PLATE NO. : 45 CHAIN CASE	PAGE NO. 95
	


PLATE NO. : 46 HEAD LAMP & FAIRING	PAGE NO. 97
	


PLATE NO. : 47 INDICATOR LIGHT ASSEMBLY	PAGE NO. 99
	





PLATE NO. : 48 TAIL LAMP ASSEMBLY & FRONT / REAR NUMBER PLATE	PAGE NO. 101
	


PLATE NO. : 49 ELECTRICAL EQUIPMENTS	PAGE NO. 103
	

PLATE NO. : 51 PAINTED PARTS & DECALS	PAGE NO. 107 - 113
       	      

PLATE NO. : 53 CONSUMABLE PARTS	PAGE NO. 119												
<table><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr></table>													
													
													
													
													


PLATE NO. : 53 CONSUMABLE PARTS	PAGE NO. 121												
<table><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td></tr></table>													
													
													
													
													

Cover Cylinder Head




No.	Part No.	Description	Qty.	Remarks
1	JZ 5110 21	Cover Cylinder Head	1	
2	59 0400 38	Bolt Flange	4	
3	JD 5110 10	Gasket Head Cover	1	
4	JA 5110 08	Bolt Head Mounting (Long)	4	
5	PA 5110 39	Plate Cylinder Head	1	
6	JA 5110 11	Hose Crankcase Breather	1	
7	59 0400 50	Bolt Head Mounting (Short)	1	For Head Mounting

SAI System




No.	Part No.	Description	Qty.	Remarks
1	PA 5810 38	Unit SAI	1	
2	JE 5810 39	Band Clip SAI Hose Outlet Tube	3	
3	JE 5810 38	Tube Outlet SAI	1	
4	JE 5110 67	Gasket Sai Flange	1	
5	KAEG0614	Bolt Flanged Small	2	
6	JE 5810 37	Hose Connector SAI	1	
7	JE 5810 41	Hose Intake Silencer Unit To SAI	1	
8	JY 5810 28	CLAMP	2	
9	24 1214 62	Silencer For SAI	1	
10	JE 5810 27	Hose Pipe A/F To Silencer Unit	1	
11	DG 1210 03	Clamp	2	
12	JE 5814 12	Hose Pipe Intake Manifold	1	
13	KA DF06 30	Bolt Flanged	2	
14	JD 1138 15	Sleeve SAI Unit	4	
15	JD 1138 14	Grommet SAI Unit	2	
16	KC GA06 06	Nut Hex Flanged	2	

Cylinder Head




No.	Part No.	Description	Qty.	Remarks
1	36 JD00 44	Head Cylinder Complete	1	or
2	JA 5110 28	Stud Silencer Mtg.	2	
	39 1666 05	Stud Silencer Mtg.	2	
3	JD 5110 08	Gasket Cylinder Head	1	
4	JE 5814 17	Intake Manifold	1	
5	JA 5814 06	Bolt Flange	2	
6	JE 5814 01	Sleeve (Carburettor - Duct Rubber)	1	
7	DP 1011 98	Clamp (39mm)	2	
8	39 1283 21	'O' Ring (Intake Pipe)	1	
9	JD 5110 04	Sleeve Spark Plug R.H	1	
10	39 2608 01	Grub Screw	1	
11	39 2629 21	'O' Ring Sleeve	1	
12	39 1283 21	'O' Ring Sleeve	1	




Valve

No.	Part No.	Description	Qty.	Remarks
1	JD 5112 09	Shaft Rocker Arm	2	Refer Kit List
2	JD 5112 07	Rocker Arm with Roller	2	
3	DG 1010 29	Cotter Valve (Collet)	8	
4	JD 5112 01	Valve Intake	2	
5	JD 5112 02	Valve Exhaust	2	
6	36 JE00 01	Valve Repair Kit	2	
7	39 2017 19	Seal Valve Stem	4	

Camshaft & Tensioner




No.	Part No.	Description	Qty.	Remarks
1	JD 5112 11	Camshaft Complete With Bearing	1	
2	JA 5112 16	Spacer Cam Sprocket	1	
3	DS 1012 76	Sprocket Cam Shaft	1	
4	59 0400 31	Socket Head Cap Bolt	1	
5	DH 1010 48	Special Washer ('O' Washer)	1	
6	36 PA01 15	Guide Chain Kit	1	Refer Kit List
7	DH 1013 92	Bolt Special	1	
8	JE 5210 16	Adjuster Assembly Chain	1	
9	CS 1011 28	Gasket Chain Tensioner	1	
10	DD 1010 62	Bolt	1	
11	39 1673 04	Flange Bolt	2	
12	39 0594 17	Internal Circlip for Camshaft	1	
13	39 2669 21	'O' Ring Tensioner	1	
14	JE 5112 30	Cam Chain 94 Links Straight	1	



Cylinder and Piston


No.	Part No.	Description	Qty.	Remarks
1	JD 5210 02	Gasket Cylinder Block	1	
2	39 1000 06	Dowel Pin	4	
3	36 JE00 02	Piston Ring Set	1	
4	DP 1011 65	Wire Circlip	2	
5	36 JE00 12	Cylinder Block & Piston Assembly	1	
6	JE 3514 03	Engine Temperature Sensor	1	

Crankshaft




No.	Part No.	Description	Qty.	Remarks
1	59 1500 14	Flange Nut	2	
2A	59 1200 03	Belleville Washer	2	
2B	59 1100 08	Plain Washer	1	
3	31 1011 73	Woodruff Key	1	
4	JE 5310 00	Crank Shaft Assembly	1	
5	JE 5310 01	Ball Bearing	1	
6	DS 1011 54	Parallel Key	1	
7	36 JE00 04	Set Primary Drive / Driven	1	
8	JA 5310 12	Spring	1	
9	JA 5310 15	Parallel Pin	1	
10	JB 5310 21	Plunger Oil	1	
11	JD 5310 04	Spacer Crankshaft Clutch Side	1	
12	JD 5410 00	Damper Crankshaft	1	

Transmission




No.	Part No.	Description	Qty.	Remarks
1	JZ 5510 10	Shaft Input	1	
2	JZ 5512 02	Gear 4th Drive	1	
3	39 0987 17	Ring Snap	2	
4	JA 5510 02	Spline Washer	4	
5	JE 5512 01	Gear 3rd Drive	1	
6	JZ 5512 13	Gear 5th Drive	1	
7	JZ 5512 00	Gear 2nd Drive	1	
8	JA 5510 04	Washer Thrust 2nd Drive	1	
9	JZ 5510 08	Shaft Output	1	
10	JZ 5512 10	Bush 2nd Driven	1	
11	JZ 5512 06	Gear 2nd Driven	1	
12	JZ 5512 11	Gear 5th Driven	1	
13	JE 5512 06	Gear 3rd Driven	1	
14	JZ 5512 08	Gear 4th Driven	1	
15	JZ 5512 05	Bush 1st Driven	1	
16	JZ 5512 04	Gear 1st Driven	1	
17	JA 5510 08	Washer Thrust 1st Driven	1	
18	JA 5510 09	Collar Sprocket Drive	1	
19	59 2100 24	'O' Ring Collar Sprocket	1	
20	JV 5510 00	Sprocket Drive (15 T)	1	
21	DU 1012 13	Plate Lock Sprocket	1	
22	39 1981 04	Socket Head Bolt	2	

Change Drum & Shaft Fork




No.	Part No.	Description	Qty.	Remarks
1	JE 5610 06	Drum Complete Gear Shift	1	
2	39 0992 06	Dowel (Pin Drum Change)	4	
3	JD 5610 11	Special Bolt	1	
4	JD 5610 06	Shaft Gear Shift Fork	2	
5	JD 5610 04	Fork Gear Shift Output	2	
6	JZ 5610 02	Fork Gear Shift Input	1	
7	JE 5610 05	Cam Drum Change	1	

Gear Change Mechanism




No.	Part No.	Description	Qty.	Remarks
1	52 JZ02 64	Lever Complete Gear Shift	1	
2	JW 5612 06	Extension Spring	1	
3	JW 5612 08	Spring Gear Shift Return	1	
4	PA 5612 09	Inhibitor Complete Gear Shift	1	
5	JD 5612 04	Spring Inhibitor	1	
6	LD B000 44	Step Washer (Collar)	1	
7	LD B000 44	Washer Plain	1	
8	BF 5612 19	Bolt Detent Lever	1	
9	JD 5614 23	Arm Lever Change Gear	1	
10	JD 5614 13	Tie Rod	1	
11	JD 5614 21	Lever Gear Change	1	
12	JD 5614 16	Washer - Nylon	2	
13	DH 1015 09	Damper	1	
14	JH 5614 04	Rubber Damper	1	
15	39 0808 08	Split Pin	2	
16	39 2453 04	Bolt Flange	1	

Engine Assembly & Crankcase RH



No.	Part No.	Description	Qty.	Remarks
1	JE 5010 49	Engine Assembly	1	
2	36 JZ00 09	Crankcase Clutch Side	1	
3	59 2000 36	Bearing Ball	1	For Input Shaft
4	JA 5410 11	Needle Roller Bearing	1	For Output Shaft
5	JA 5410 10	Stopper Plate	1	
6	39 0999 06	Dowel Pin	2	
7	PF 5410 18	Bushing Drum	1	
8	DH 1013 80	Screw	1	
9	JE 5010 49	Bolt	2	Crankcase Mtg.
10	59 0400 38	Bolt Flange	1	Crankcase Mtg.
11	52 JA00 29	Bolt Pre - Coated	1	
12	JA 5410 12	Guide Kick	1	
13	39 1964 04	Hexagon Bolt	2	


Crankcase LH




No.	Part No.	Description	Qty.	Remarks
1	36 JZ00 11	Crankcase Mag. Side	1	
2	39 2562 20	Needle Roller Bearing	1	
3	59 2000 36	Ball Bearing	1	
4	39 1715 19	Seal Oil	1	
5	31 2010 81	Neutral Switch	1	
6	DH 1017 84	Gasket Neutral Switch	1	
7	39 2190 19	Oil Seal	1	
8	JA 5410 05	Bush Starter Clutch	1	
9	39 0747 01	Pan Head Screw	2	
10	JA 5410 34	Stopper Gear Starter Clutch	1	
11	39 0999 06	Hollow Dowel Pin	2	
12	JA 5410 19	Mesh Filter Oil strainer	1	
13	59 2100 23	'O' Ring Cap Strainer	1	
14	JA 5410 21	Cap Strainer	1	
15	59 0400 38	Bolt Flange	6	
16	39 1759 04	Bolt	1	
17	LJ A000 04	'O' Ring Mesh Filter Oil Strainer	1	Changed with new MPL



Cover Clutch




No.	Part No.	Description	Qty.	Remarks
1	36 JD00 75	Kit Assembly Clutch Cover Slate Gray	1	Refer Kit List
2	JE 5412 11	Decal Clutch Cover	1	
3	39 1041 19	Oil Seal Clutch Lever	1	
4	30 1011 42	Oil Seal (Kick Shaft)	1	
5	JV 5412 08	Shaft Clutch Release	1	
6	JE 5514 01	Rod Push	1	
7	DG 1014 18	Gauge	1	
8	DS 1012 15	Wire Circilp	1	
9	39 2443 11	Plain Washer	1	
10	JE 5412 14	Spring Torsion Clutch Lever	1	
11	JA 5412 11	Cap Oil Filler	1	
12	JA 5412 25	'O' Ring Cap Oil Filler	1	
13	JA 5412 12	Gasket Clutch Cover	1	
14	59 0400 38	Bolt Flange	8	
15	JV 5412 09	Bracket Clutch Cable	1	
16	DD 1211 81	Oil Filter Element	1	
17	39 1671 21	'O' Ring	1	
18	JE 5412 18	Cap Filter	1	
19	39 1673 04	Bolt Flange	3	
20	14 1510 33	Bearing Wheel Clutch Lifter	1	
21	39 0999 06	Pin Hollow Dowel	2	



Cover Magneto


No.	Part No.	Description	Qty.	Remarks
1	52 JE55 06	Cover Magneto Assly -Matt Slate Gray	1	
2	39 1065 04	Bolt Flange	8	
3	JA 5412 05	Gasket Magneto Cover	1	
4	59 0400 38	Bolt	2	
5	JE 5412 19	Cover RR Moon Light Silver	1	
6	JA 5410 05	Bush	1	
7	JA 5412 33	Cap TDC Finder	1	
8	30 1011 95	'O' Ring	1	
9	JE 5412 12	Decal Magneto Cover	1	
10	DJ 1610 12	Gear Shift Label	1	
11	52 JD06 51	Cover RR Moon Slate Gray	1	




Clutch Assembly

No.	Part No.	Description	Qty.	Remarks
1	JD 5514 00	Spacer Clutch Assembly	1	Refer Kit List
2	JA 5514 06	Collar Clutch	1	
3	39 2600 11	Washer	1	
4	36 JZ01 21	Friction Plate Kit	1	
5	JE 5514 14	Wheel Clutch	1	
6	DP 1011 11	Plate Clutch	4	L.H. Threads
8	JE 5514 13	Hub Clutch	1	
9	JZ 5514 12	Spring Clutch	4	
10	JE 5514 15	Plate Clutch Lifter	1	
11	39 1553 04	Bolt Flange	4	
12	39 2200 11	Belleville Washer	1	Refer Page No. 105
13	39 0240 11	Plain Washer	1	
14	DH 1016 48	Nut Special	1	
15	14 1510 33	Bearing Clutch Lifter	1	Refer Page No. 105
16	36 JE00 04	Set Primary Drive & Driven	1	
17	JE 5514 11	Clutch Assembly	1	

Oil Pump Assembly




No.	Part No.	Description	Qty.	Remarks
1	JZ 5710 00	Oil Pump Assembly	1	Alt. Dx101068
2	JA 5410 16	Gasket Case Oil Pump	1	
3	FD 1010 78	Pan Head Screw	3	
4	39 0992 06	Dowel	2	
5	JZ 5710 01	Gear Oil Pump Driven	1	




Carburettor Assembly

No.	Part No.	Description	Qty.	Remarks
1	JE 5812 51	Carburettor Assembly	1	
2	36 JD00 02	Air screw Kit	1	Refer Kit List
3	36 JD00 01	Jet Kit	1	Refer Kit List
4	DK 1210 41	Idling screw kit	1	Refer Kit List
5	DH 1210 93	Valve complete float (Float pin)	1	
6	DH 1210 59	Float complete	1	
7	DP 1210 67	Screw Float chamber	3	
8	JE 5812 23	Tube Over Flow	1	
9	JE 5812 24	Tube Air Vent	1	N.I.
10	DH 1210 63	Float Pin	1	
11	36 JD00 04	Vacuum Piston Kit	1	Refer Kit List
12	36 JD00 05	Carburettor Gasket 'O' ring Kit	1	Refer Kit List
13	JE 5812 19	Screw for Diaphragm Cover	1	
14	JE 5812 18	Drain Screw	1	
15	DH 1210 64	Screw Needle Shaft	1	
16	36 JD00 06	Jet Holder Hardware Kit	1	Refer Kit List



Kick Starter Mechanism


No.	Part No.	Description	Qty.	Remarks
1	JE 6212 02	Lever Assembly Kick	1	Refer Kit List
2	JA 6212 06	Bolt Special	1	
3	36 DU10 07	Boss Kick Set	1	
4	22 1502 41	Plain Washer	1	
5	39 0993 11	Plain Washer Small	3	
6	39 0738 17	Circlip Shaft	2	
7	JD 6210 01	Shaft Kick	1	
8	DS 1011 17	Spring Kick Starter	1	
9	JA 6210 02	Ratchet	1	
10	JZ 6210 00	Assembly Kick Pinion Gear	1	
11	JA 6210 06	Washer Thrust	1	
12	39 2408 17	Circlip	1	
13	DD 1010 97	Kick Rubber	1	
14	JE 5410 08	Spring Kick Starter Return	1	



Silencer Assembly


No.	Part No.	Description	Qty.	Remarks
1	JD 5910 56	Silencer Assembly Without Shield	1	
2	JE 5910 02	Gasket Exhaust Mounting	1	
3	39 2295 15	Flange Nut	2	
4	JE 5911 95	Shield Muffler Black	1	
5	DH 1013 95	Truss Screw	3	
6	JW 5910 30	Grommet Shield	1	
7	39 2754 04	Bolt Hex with Flange M5	1	
8	39 2492 11	Plain Washer	1	
9	39 2754 04	Bolt M10 x 1.25	1	
10	DD 1610 71	U Nut M10X1.25	1	
11	DH 1013 01	Seal Shield Muffler	3	

Air Cleaner Assembly




No.	Part No.	Description	Qty.	Remarks
1	JE 5810 28	Air Filter Assembly	1	Intake
2	JD 5810 01	Air Filter Duct	1	
3	PF 5810 11	Assembly Cartridge Air filter	1	
4	PF 5810 12	Element Air Filter	1	
5	JA 5810 09	Flame Arrester	1	
6	JA 5810 12	Tube Drain	1	N.I.
7	DS 1211 26	Plug	1	
8	DP 1210 25	Clamp	3	
9	JA 5110 11	Hose Breather	1	
10	JY 5810 28	Clamp	1	
11	JD 1110 12	Bracket Side Cover Mtg.	1	N.I.
12	JE 5810 00	Connecting Tube	1	
13	JD 5810 07	Filter Air Cover	1	
14	JB 5810 35	Cover Assembly Cartridge	1	
15	JA 5810 11	'O' Ring Cartridge Cover	1	
16	39 0758 01	Flange Bolt M6	4	For Cartridge Cover
17	39 1673 04	Flange Bolt	2	
18	39 1677 04	Flange Bolt	1	

EVAP Mechanism




No.	Part No.	Description	Qty.	Remarks
1	JY 1710 77	Canister	1	
2	JY 1710 69	Spring Band Clamp 15 x 10	1	
3	JD 1716 05	Tube Canister To Purge Valve	1	
4	JY 1710 90	Spring Band Clamp 13 x 12	6	
5	JH 1710 48	Grommet Purge Valve	1	
6	PD 1716 16	Valve Purge	1	
7	JG 1710 29	Spring Band Clamp 11.5 X 8.4	1	
8	JD 1710 63	Tube Purge Valve To Carburetor	1	
9	JY 1710 70	Spring Band Clamp 9 x 8.4	3	
10	JD 1710 64	Tube Y Connector To Canister	1	
11	JY 1138 42	Connector Y Shape	1	
12	JH 1710 19	Tube Drain	1	
13	JY 1718 25	Plug Fuel Drain	1	
14	JD 1716 07	Tube Tank To Y Connector	1	
15	DU 1412 72	Tube Canister Drain	1	
16	JH 1716 02	Clamp - Canister Breather	1	
17	JH 1710 24	Tube Canister Breather	1	



FWD Front Wheel Direction

Magneto, CDI & H.T. Coil


No.	Part No.	Description	Qty.	Remarks
1	JE 3510 02	Rotor Assembly (ES)	1	
2	JP 3510 07	Stator Assembly Complete	1	
3	39 1675 04	Bolt Flange	2	
4	DH 1013 80	Pan Head Screw	3	
5	JE 3512 03	H. T. Coil With Cable & Cap - LH	1	
6	JE 3512 04	H. T. Coil With Cable & Cap - RH	1	
7	JE 3512 46	C.D.I. Assembly	1	
8	DD 1110 18	Spark Plug PRZ9 HC	2	or
	CF 1110 19	Spark Plug Bosch UR4AC	2	
9	DH 1110 15	Cap Spark Plug	1	
10A	DD 1110 11	Grommet Spark Plug Cap	1	
10B	JD 3512 06	Grommet Sleeve Spark Plug Cap	1	
11	DD 1110 12	Grommet for HT Cable LH	1	
11A	DH 1110 13	Grommet Spark Plug	1	
12	39 1943 04	Bolt Flange	2	
13	JW 4020 01	DC Regulator with Capacitor	1	
14	JA 5410 28	Lock plate	1	
15	59 0400 14	Bolt Flange	4	



Starter Assembly (For Self Start)


No.	Part No.	Description	Qty.	Remarks
1	JA 6214 14	Body Complete Starter Clutch	1	Refer Kit List
2	DH 1017 81	Plate Roller Clutch	1	
3	JZ 6214 05	Gear Starter Clutch	1	
4	JA 6214 02	Washer	2	
5	JA 6214 06	Starter Drive Assembly	1	
6	36 JW00 14	Starter Clutch Repair Kit	1	
7	JA 3516 00	Starter Motor Assembly	1	
8	LA D000 11	Flange Bolt	2	

Frame and Frame Fittings




No.	Part No.	Description	Qty.	Remarks
1	JD 1110 70	Frame Assembly	1	
2	30 1810 11	Nut Fork	1	
3	DH 1810 14	Cup - Steering	1	
4	36 DS18 02	Bearing Cone Kit or	1	Refer Kit List
	36 3140 01	Bearing Cone Kit	1	Refer Kit List
5	DJ 1811 15	Ball Steel Cage Bearing	2	
6	30 1810 09	Bearing Cone	1	

Engine Mountings




No.	Part No.	Description	Qty.	Remarks
1	JA 1134 03	Flange Bolt M10x10	2	
2	39 1970 15	Nut Flanged	7	
3	39 2312 04	Bolt Flanged	3	
4	39 2498 04	Bolt Flanged	1	
5	JA 1134 04	Bolt Flanged	3	
6	39 2723 15	Flanged Nut	2	
7	JA 1134 02	Engine Mounting Bracket Front	1	
8	JD 1134 00	Bracket Engine Hanger	2	
9	JA 1134 03	Engine Mounting Rear Bolt Top	2	

Swing Arm & Rear Shock Absorber




No.	Part No.	Description	Qty.	Remarks
1	JB 1220 16	Hex. Bolt Flange - M10	2	
2	JB 1220 10	Plain Washer	4	
3	JD 1220 03	Rear Shock Absorber	2	
4	JD 1220 09	Swing Arm Assembly	1	
5	39 2366 15	Domed Cap Nut	2	
6	39 2726 12	Spring Washer	2	
7	JD 1220 13	Chain Slider	1	
8	39 0553 02	Screw	2	
9	39 0454 11	Plain Washer	2	
10	JD 1220 02	Shaft Swing Arm	1	
11	59 1500 03	U Nut M-12	1	
12	DJ 1510 37	Adjuster Chain	1	
13	39 0292 15	Hexagon Nut	4	
14	DJ 1510 47	Plate Chain Adjuster	2	
15	DP 1710 06	Silent Bush	2	
16	36 JD00 07	Kit Adjuster RSA	2	

Pillion Foot Rest & Holder




No.	Part No.	Description	Qty.	Remarks
1	56 JD3Y 1Y	Holder LH Step	1	Refer Kit List
2	56 JD3X 1Y	Holder RH Step	1	
3	JD 1130 13	Pillion Footrest LH	1	
4	JD 1130 15	Pillion Footrest RH	1	
5	JD 1130 16	Rider Footrest LH	1	
6	JD 1130 17	Rider Footrest RH	1	
7	JD 1130 19	Pin Footrest	4	
8	JD 1130 14	Ball & Spring Assembly Footrest	4	
9	DH 1611 57	Tube Silencer Mounting	1	
10	36 DK00 13	Hardware Kit - Pillion Step	2	
11	DH 1611 55	Damper Silencer	1	

Mudguard - Front & Rear



No.	Part No.	Description	Qty.	Remarks
1	JD 1814 01	Brace Fender	1	
2	DJ 1610 91	Grommet Front Fender	4	
3	DG 1810 08	Socket Bolt	4	
4	DS 1611 25	Cable Guide	1	
5	DJ 1610 69	Nail for Cable Guide	1	
6	39 0326 15	Nyloc Nut	6	
7	39 0242 11	Washer	6	
8	39 2420 01	Screw	6	
9	JD 1814 02	Flap Front fender	1	
10	JD 1814 12	Fender Rear EVAP	1	
11	39 0211 11	Washer Plain	7	
12	39 1943 04	Flange Bolt	4	
13	DL 1610 15	Grommet	2	
14	JD 1318 09	Hose Clamp	1	
15	JD 1814 08	Cover Mud Rear	1	
16	JD 1814 09	Flap Mud Rear	1	
17	39 2060 04	Bolt M-6 Hugger Mounting	2	
18	JD 1810 00	Flap LH	1	
19	JD 1810 01	Flap RH	1	
20	JD 1810 02	Foam Strip	1	
21	JD 1810 06	Tube Hugger Mounting	1	



Center & Side Stand Assembly


No.	Part No.	Description	Qty.	Remarks
1	PF 1132 02	Center Stand	1	
2	JA 1132 01	Shaft Stand	1	
3	39 0797 08	Pin Cotter	1	
4	DH 1612 39	Spring Main Stand	1	
5	DH 1611 45	Cover Spring Main Stand	1	
6	JD 1132 00	Stand Side	1	
7	DH 1612 40	Spring Side Stand with Cover	1	
8	DF 1611 02	Bolt	1	
9	39 0422 15	Nut	1	
10	PA 1132 04	Damper Main Stand	1	
11	DH 1611 46	Cover Side Stand Spring	1	
12	JD 1132 01	Side Stand Mounting Bracket	1	
13	DH 1613 09	Plug Side Stand Mounting Bolt	2	
14	JA 1130 11	Flange Bolt M-8	4	

Tube, Tyre & Rim




No.	Part No.	Description	Qty.	Remarks
1	JZ 1310 12	Wheel Alloy 1.4 x 17 DISC	1	
2	DS 1510 48	Tyre Front	1	
3	DS 1510 49	Tube Front	1	
4	JZ 1312 06	Wheel (2.15x17-130 DR 5 SP) Black	1	
5	DS 1510 31	Tyre Rear	1	
6	DS 1510 29	Tube Rear	1	

Front Wheel Assembly




No.	Part No.	Description	Qty.	Remarks
1	30 1510 33	Seal Oil	1	
2	KP BB63 01	Bearing Ball	2	
3	DE 1510 06	Spacer Assembly	1	
4	DE 1510 12	Plate Drive	1	
5	DE 1510 08	Seal Oil	1	
6	DJ 1510 94	Rotor Speedo (Disc)	1	
7	JN 1316 03	Case Meter Assembly	1	
8	59 2100 19	'O' Ring	1	
9	39 0900 12	Washer Spring	1	
10	KB BM04 08	Screw - M4	1	
11	JD 1318 11	Hex. Soc. Head Bolt	5	
12	JD 1318 16	Disc (240 mm Dia)	1	
13	JZ 1310 12	Wheel Alloy 1.4 x 17 DISC	1	
14	JB 1310 18	Plain Washer	1	
15	DS 1510 58	Spacer	1	
16	JB 1310 17	Axle Front	1	
17	59 1500 03	'U' Nut M12	1	
18	30 1511 18	Stopper for Bushing	1	

Front Master Cylinder Assembly




No.	Part No.	Description	Qty.	Remarks
1	DJ 1910 23	Major Kit - Master Cylinder	1	Refer Kit List
2	JD 1318 08	Hose Brake Front	1	
3	DJ 1910 57	Lever Grip RH	1	
4	DK 1510 69	Banjo Bolt	2	
5	DE 1910 10	Washer Copper	4	
6	DJ 1910 27	Clamp Holder RH	1	
7	DJ 1910 28	Bolt	2	
8	DJ 1910 29	Bolt Front Brake Lever	1	
9	DJ 1910 30	Nut Flanged	1	
10	DJ 1910 31	Screw	2	
11	DJ 1910 56	Cylinder Master with Lever	1	
12	DJ 2011 09	Front Brake Switch	1	
13	DJ 1910 34	Reservoir Cap	1	
14	DJ 1910 35	Diaphragm	1	
15	36 DH19 02	'O' Ring Master Cylinder Kit	1	Refer Kit List

Front Brake - Caliper & Disc




No.	Part No.	Description	Qty.	Remarks
1	JD 1318 13	Caliper Assembly Front	1	
2	JA 6212 06	Bolt Flanged Caliper Mounting	2	
3	DJ 1510 68	Spring Pad	1	
4	DJ 1510 69	Bleeder Screw	1	
5	DJ 1510 70	Bleeder Cap	1	
6	JW 1318 07	Disc Pad Set	1	
7	DJ 1510 72	Protection Boot (8 mm Dia)	1	
8	DJ 1510 73	Protection Boot (9 mm Dia)	1	
9	DJ 1510 74	Minor Kit - Caliper	1	Refer Kit List
10	DJ 1510 75	Major Kit - Caliper	1	Refer Kit List
11	36 PD00 45	Kit Caliper Bracket	1	Refer Kit List

Rear Wheel Assembly




No.	Part No.	Description	Qty.	Remarks
1	DX 1510 81	Drive Chain Lock	1	Refer Kit List
	JD 1410 03	Drive Chain Lock	1	
2	36 JE00 07	Chain Sprocket kit	1	
	36 JE00 14	Chain Sprocket kit	1	
3	39 0801 15	Nut	1	
4	LD B000 01	Plain washer	1	
5	JD 1312 10	Collar Assembly	1	
6	39 2240 20	Bearing ball	1	
7	JN 1312 03	Coupling	1	
8	DS 1510 73	Stud M - 10	4	
9	LC B000 05	Nut Hex A/F 17 M10x1.25x6H	4	
10	PF 1312 20	Washer Lock For Nut	2	
11	DX 1510 22	Collar	1	
12	39 2686 20	Bearing Ball	1	
13	30 1510 75	Collar Bearing	1	
14	DJ 1510 88	Damper	1	
15	39 2687 20	Bearing Ball	1	
16	30 1510 69	Spring	2	
17	30 1510 68	Shoe Brake	2	
18	DJ 1510 92	Panel Rear Brake	1	
19	30 1510 11	Cam Brake	1	
19A	39 0722 11	Plain Washer	1	
20	30 1510 38	Ring 'O'	1	



Rear Wheel Assembly

No.	Part No.	Description	Qty.	Remarks
21	30 1510 05	Indicator	1	
22	JD 1316 01	Lever Brake	1	
23	39 2447 04	Bolt	1	
24	JN 1312 11	Axle	1	
25	JD 1312 12	Sleeve	1	
26	39 2567 11	Plain washer	1	
27	DJ 1710 33	'U' nut	1	




Front Wheel Direction


Rear Brake Pedal

No.	Part No.	Description	Qty.	Remarks
1	JD 1610 01	Brake Pedal	1	
2	JC 1910 09	Hex. Bolt	1	
3	LA A000 04	Bolt Brake Pedal Adjust	1	
4	39 1998 19	Oil Seal	2	
5	JD 1610 02	Brake Pedal Spring	1	
6	JD 1610 03	Rod Brake	1	
7	36 DK00 17	Brake Adjuster Kit	1	Refer Kit List
8	36 DK00 18	Torque Rod Hardware Kit	1	Refer Kit List
9	JD 1220 04	Rod Torque	1	
10	JA 1210 05	Step Bolt	1	
11	39 0789 12	Spring Washer	1	
12	39 0694 15	Nut Hex. Lock	1	
13	39 0807 08	Pin Snap	1	
14	30 1510 96	Hex. Bolt	1	

Handle Bar Assembly




No.	Part No.	Description	Qty.	Remarks
1	JD 1510 54	Upper Bracket	1	AHO Model
2	JD 1510 52	Holder Handle RH	1	
3	JD 1510 51	Holder Handle LH	1	
4	DG 1810 08	Socket Bolt	4	
5	JF 4014 00	Control Switch LH	1	
6	JF 4014 01	Control Switch RH	1	
6A	JD 4014 00	Control Switch RH	1	
7	DJ 1910 54	Holder LH	1	
8	DJ 1910 55	Lever LH	1	
9	DL 1910 14	Stud Lever Handle	1	
10	30 1910 17	Self Locking Nut	1	
11	36 DU19 01	Adjusting Screw	1	
12	DH 1910 07	Grip LH	1	
13	DH 1910 08	Grip Assembly RH	1	
14	DS 1910 52	Boot for lever LH	1	
15	DH 1810 22	Handle bar weight	2	
16	39 2427 04	Hex. Soc. Hd. Cap Screw	2	
17	DS 1910 52	Lever Boot for Clutch Switch	1	
18	JB 4014 02	Switch Assembly Ignition	1	
19	39 1943 04	Flange Bolt	2	
20	DK 1810 31	Bush Silent Handle Bar Tube	2	



Handle Bar Assembly


No.	Part No.	Description	Qty.	Remarks
21	DJ 2011 95	Clutch Switch	1	
22	JD 1510 45	Handle bar tube Assembly LH	1	
23	JD 1510 48	Handle bar tube Assembly RH	1	
24	DH 1910 17	Pipe throttle	1	N.I.
25	JW 2326 01	Lock set 4 in 1	1	
	52 JD06 43	Lock Set + Tank Cap BS IV	1	BS IV
26	DK 1810 79	Bolt Handle Bar Tube	2	
27	39 1180 11	Washer	2	
28	JD 1510 32	Rubber Plug	2	
29	JD 2316 00	Mirror Assembly LH	1	
30	JD 2316 01	Mirror Assembly RH	1	

Front Fork




No.	Part No.	Description	Qty.	Remarks
1	JD 1510 00	Fork Front	1	Refer Kit List
2	36 DZ00 20	Front Fork Seal Kit	1	
3	30 1810 26	Gasket	2	
4	30 1810 25	Bolt Socket Head	2	
5	JD 1510 26	Fork Inner Pipe	2	
6	DJ 1811 04	Spring Front Fork	2	Refer Kit List
7	59 0400 07	Bolt upper bkt.	2	
8	DS 1810 15	Cap Nut Fork	1	
9	DS 1810 16	Plain Washer	1	
10	36 DS18 02	Bearing Cone Kit	1	
11	JD 1510 29	Under Bracket Assembly	1	
12	39 1181 01	Bolt Hexagon Head	2	
13	DM 1810 10	Washer	2	
14	JD 1510 03	Outer Tube LH with Guide Bush	1	
15	JD 1510 04	Outer Tube RH	1	
16	JK 1210 07	Anti Friction Bush	2	
17	JD 1210 02	Cylinder Complete Fork	2	
18	JK 1210 09	Washer Anti Friction Bush	2	
19	JD 1510 28	Bolt Fork	2	
20	30 1810 29	'O' Ring	2	

Front Fork




No.	Part No.	Description	Qty.	Remarks
21	JD 1510 36	Cup Washer	2	
22	LA C000 09	Bolt Socket M10	2	
23	JD 1510 06	Lamp Shade Assembly	1	
24	DJ 1810 64	Grommet Head Lamp Mounting	1	
25	DJ 1810 29	Collar Head Lamp Mounting	4	
26	DJ 1810 52	Cover Trail 'B'	4	
27	DJ 1810 85	Cushion Rubber	4	
28	JD 1510 01	Leg Assembly LH	1	
29	JD 1510 02	Leg Assembly RH	1	



Petrol Tank Spoiler


No.	Part No.	Description	Qty.	Remarks
1	JW 1710 14	Grommet Central Spoiler	3	
2	JW 1710 15	Collar Central Spoiler	3	
3	JD 1710 16	Round Head Screw	1	
4	JW 1710 07	Dual lock Tape 15x20	4	
5	JD 1710 18	Dual Lock Tape 10x20	8	
6	JW 1710 16	Round Head Screw	2	For Fitting Central Spoiler
7	59 0200 01	Self Tap Screw	8	For Flap LH/RH Fitment on Central Spoiler
8	JC 1410 17	Grommet II Tank Cover	2	
9	JW 1710 06	Clip Nut on Tank Bracket	2	



Fittings Petrol Tank, Side Cover & Cover Seat


No.	Part No.	Description	Qty.	Remarks
1	36 JE00 09	Grommet Kit for Side Cover	1	Refer Kit List
2	DG 1611 21	Screw	1	
3	39 1943 04	Flanged Bolt	2	
4	JW 1710 17	Damper Rear	1	
5	39 1789 24	Washer Nylon	3	
6	39 1956 04	Bolt	1	
7	39 1054 11	Plain Washer	1	
8	DJ 1410 08	Damper Front	2	
9	JD 1110 12	Bracket Side Cover Lock	1	
10	DL 1610 15	Grommet Seat Cowl	2	
11	39 2754 04	Hex Head Bolt	2	

Seat Assembly & Seat Lock




No.	Part No.	Description	Qty.	Remarks
1	JD 1910 18	Seat Assembly Complete Front	1	
2	DK 2110 09	Damper For Seat	4	
3	DS 2110 04	Damper Seat I	2	
4	JD 1910 06	Damper Round	2	
5	DS 2110 07	Damper Seat Front	1	
6	DK 2110 08	Lock Assembly Seat	1	
7	39 1552 04	Bolt Flange	2	


Speedometer Assembly



No.	Part No.	Description	Qty.	Remarks
1	JD 4024 05	Speedometer Assembly	1	N.I.
2	JD 1812 11	Speedo Flap	1	
3	39 1778 02	Screw	4	
4	YJ D070 02	Top Cover With O Ring	1	




No.	Part No.	Description	Qty.	Remarks
1	JA 1612 00	Cable Accelerator	1	
2	JD 1612 01	Cable Clutch	1	
3	DH 2010 80	Speedometer Sensor Cable	1	



Leg Guards, Saree Guard & Grab Handle


No.	Part No.	Description	Qty.	Remarks
1	JD 2312 01	Leg Guard	1	Refer Kit List
2	JA 2312 01	Hook Leg Guard	1	
3	39 0798 15	Nut Hexagon With Flange - M6	2	
4	JA 2312 02	Leg Guard Spacer	1	
5	JD 2312 00	Leg Guard Kit	1	
6	JD 2312 04	Guard Sari	1	
7	39 1943 04	Bolt Flanged - M6	2	
8	JD 2314 13	Grab Handle	1	
9	KA DF08 22	Flange Bolt	4	
10	JD 2312 03	Ladies Foot Rest	1	
11	39 1849 04	Bolt Hex Head With Flange	1	

Chain Case




No.	Part No.	Description	Qty.	Remarks
1	JD 1812 33	Chain Cover Assembly	1	
2	JD 1812 32	Chain Case Inner	1	
3	JD 1812 34	Plastic Nail	3	
4	01 1605 08	Lock Washer	3	

Head Lamp & Fairing




No.	Part No.	Description	Qty.	Remarks
1	JD 4010 24	Head Lamp Assembly	1	
2	39 1778 02	Screw Tapping	6	For Head Lamp
3	CL 2010 23	Lamp 12V 35/35W-HS1	1	
4	DS 2010 36	Head Lamp Bulb Clip	1	
5	DJ 2010 72	Lamp 12V 5W	2	Pilot Lamp
6	JD 4010 25	Head Lamp Harness Branch	1	
7	JD 1812 21	Bracket Speedo Cover Mtg	1	
8	39 2208 04	Bolt Flange Bracket Speedo	2	
9	JD 1510 38	Bracket H/L Mtg Lower RH	1	
10	JD 1510 37	Bracket H/L Mtg Lower LH	1	
11	39 1553 04	Bolt Flange M-6	4	
12	39 1765 11	Washer	2	For Bracket Cowling Mounting
13	39 1844 01	Screw M-5	2	
14	JD 1812 28	Cover Harness LH	1	
15	JD 1812 29	Cover Harness RH	1	
16	39 1943 04	Bolt Flange	2	For Cover Harness Side
17	39 1778 02	Screw	4	For Cowling LH / RH
18	35 1610 60	Nut Clip	2	For Cowling LH / RH
19	01 1605 08	Lock Washer	2	For Wind Shield
20	JD 1812 40	Windshield	1	
21	JD 1812 41	Foam - Windshield	2	
22	JD 1812 49	Tape Windshield	2	

Indicator Light Assembly




No.	Part No.	Description	Qty.	Remarks
1	JD 4010 04	Indicator RR RH - CL Lens	2	
2	JD 4010 03	Indicator RR LH - CL Lens	2	
3	GH 2010 12	Lamp 12 V - 10W	4	
4	39 1225 15	Hex Nut with Flange	4	
5	39 1913 04	Bolt Flange	2	
6	JD 1510 23	Blinker Mounting Front LH	1	
7	JD 1510 24	Blinker Mounting Front RH	1	
8	39 1913 04	Bolt Flange	2	
9	JD 1138 01	Bracket Rear Blinker Mounting	1	
10	JD 2328 04	Rubber Bush RR Blnk. Mtg. Bkt. LH	1	
11	JD 2328 05	Rubber Bush RR Blnk. Mtg. Bkt. RH	1	

Tail Lamp Assembly & Front / Rear Number Plate



No.	Part No.	Description	Qty.	Remarks
1	JD 4010 08	LED Tail Lamp	1	
2	DD 2010 11	Damper	2	
3	DJ 1810 83	Collar	2	
4	39 2124 15	Flange Nut	1	
5	JD 1138 00	Bracket Rear No. Plate	1	
6	39 1553 04	Bolt Flange	2	
7	JD 2328 03	Number Plate Rear	1	
8	39 1943 04	Hex Flanged Bolt	2	
9	JD 2328 00	Number Plate Front	1	
10	52 JD01 75	Front No. Plate Mounting Bracket	1	
11	39 1783 01	Truss Screw Front No. Plate	2	
12	JD 4010 07	Rear Number Plate Lamp	1	
13	DJ 2010 72	Bulb 12V/ 5W	1	
14	39 2179 24	Washer (Non Metallic)	4	
15	39 1523 01	Screw For LED Tail Lamp	4	
16	JD 1138 01	Bracket Rear Blinker Mounting	1	
17	JD 1138 02	Bracket Reflector Mounting	1	
18	DD 2010 02	Reflector Reflex	1	
19	39 1972 15	Nut for Reflex	1	
20	JW 4010 10	Cap Tail Lamp	1	N.I.
21	DJ 1612 29	Clip Nut Tail Lamp	4	
22	JD 2328 01	Bracket Number Plate Mounting	1	
23	39 1943 04	Bolt	2	

Electrical Equipments




No.	Part No.	Description	Qty.	Remarks
1	DK 2010 37	Horn LH with Stay	1	
	DK 2010 38	Horn RH with Stay	1	
2	39 1507 11	Plain Washer	1	
3	39 1956 04	Flange Bolt	1	
4	JD 4022 14	Wiring Harness Front	1	
4A	JD 4022 34	Wiring Harness Front	1	AHO Model
5	JD 4022 33	Wiring Harness Rear	1	
5A	JD 4022 32	Wiring Harness Rear	1	AHO Model
6	DH 1910 12	Spring Brake Switch	1	
7	DS 2010 82	Battery 5 AH	1	
8	JA 4018 00	Base Battery (ES)	1	
9	JV 4018 02	Band Battery	1	
10	JA 4018 05	Pad II	1	
11	DS 2010 25	Assembly DC Flasher	1	
11A	JL 4020 04	Light Control Module	1	AHO Model
12	DS 1612 24	Bolt Flange	2	
13	JN 3516 04	Starter Relay With Grommet	1	
14	30 2011 04	Fuse Box Assembly	2	
15	30 2010 85	Fuse	2	
16	JA 4022 02	Cable Assembly (Battery to Earth)	1	
17	JW 4022 02	Cable Assembly (Relay to Starter Motor)	1	
18	30 1910 48	Band (Harness) (123 mm)	5	
19	31 2010 79	Rear Brake Switch	1	
20	JD 4018 03	Adapter with 530 mm Vent Tube	1	
21	JG 4018 08	Foam Battery Bracket 35x15x33	3	

Tool Kit




No.	Part No.	Description	Qty.	Remarks
1	DJ 2210 19	Tool Kit	1	For Reference Only

Painted Parts & Decals



No.	Part No.	Description	Qty.	Remarks
1	56 JD05 X3	Painted Front Fender	1	
	56 JD05 7Q	Painted Front Fender	1	
	52 JD03 67	Painted Font Fender Flame Red	1	
	52 JD08 12	Front Fender Passion Red WH Decal	1	
2	52 JD06 09	Spoiler Assembly Ebony Black Wh Decal	1	
	52 JD06 10	Spoiler Assembly Royal Blue Wh Decal	1	
	52 JD06 62	Spoiler Assembly FI Red Wh Decal	1	
	52 JD07 80	Spoiler Assembly Ebony Black Chrome Dcl	1	
	52 JD07 81	Spoiler Assembly Royal Blue Chrome Decal	1	
	52 JD08 65	Spoiler Assembly Passion Red WH Decal	1	
3	52 JD06 03	Cowling LH Ebony Black	1	
	52 JD06 04	Cowling LH Royal Blue	1	
	52 JD06 56	Cowling LH FI Red	1	
	52 JD07 62	Cowl LH Ebony Black WH Chrome Decal	1	
	52 JD07 65	Cowl LH Royal Blue WH Chrome Decal	1	
	52 JD08 21	Cowling LH Passion Red With Decal	1	
4	52 JD06 38	Cowling RH Ebony Black	1	
	52 JD06 39	Cowling RH Royal Blue	1	
	52 JD06 57	Cowling RH FI Red	1	
	52 JD07 63	Cowl RH Ebony Black WH Chrome Decal	1	
	52 JD07 66	Cowling RH Royal Blue WH Chrome Decal	1	
	52 JD08 22	Cowling RH Passion Red With Decal	1	
5	52 JD05 93	Side Cover LH Assembly Ebony Black	1	
	52 JD05 94	Side Cover LH Assembly Royal Blue	1	
	52 JD06 53	Side Cover LH Assembly FI Red	1	
	52 JD07 74	Side Cover LH Asly Ebony Blk. Chrome Dcl	1	
	52 JD07 75	Side Cover LH Asly Royal Blue Chrome Dcl	1	
	52 JD08 60	Side Cover LH Assembly Passion Red	1	


Painted Parts & Decals



No.	Part No.	Description	Qty.	Remarks
6	52 JD05 97	Side Cover RH Assembly Ebony Black	1	
	52 JD05 98	Side Cover RH Assembly Royal Blue	1	
	52 JD06 55	Side Cover RH Assembly FI Red	1	
	52 JD07 78	Side Cover RH Asly Eb. Blk. Chrome Dcl	1	
	52 JD07 79	Side Cover RH Asly Royal Blue Chrome Dcl	1	
	52 JD08 61	Side Cover RH Assembly Passion Red	1	
7	52 JD05 99	Seat Cowl Assembly Wh Decal Ebony Black	1	
	52 JD06 00	Seat Cowl Assembly Wh Decal Royal Blue	1	
	52 JD06 59	Seat Cowl Assembly Wh Decal FI Red	1	
	52 JD07 68	Seat Cowl Ebony Black WH Chrome Decal	1	
	52 JD07 70	Seat Cowl Royal Blue WH Chrome Decal	1	
	52 JD08 62	Seat Cowl Passion Red With Decal	1	
8	52 JD06 07	Tank Ebony Black With Decal	1	
9	52 JD06 08	Tank Royal Blue With Decal	1	
	52 JD06 61	Tank Flame Red With Decal	1	
	52 JD07 82	Tank Ebony Black Chrome Decal	1	
	52 JD07 83	Tank Royal Blue Chrome Decal	1	
	52 JD08 66	Tank Passion Red With Decal	1	
10	JD 2331 62	Decal Wheel LH Ebony Black	4	
	JD 2331 82	Decal Wheel LH Royal Blue	4	
	DH 0101 67	Decal Wheel LH Flame Red	4	
	DH 0102 09	Decal Wheel LH Silver	4	
11	JD 2331 63	Decal Wheel RH Ebony Black	4	
	JD 2331 83	Decal Wheel RH Royal Blue	4	
	DH 0101 68	Decal Wheel RH Flame Red	4	
	DH 0102 10	Decal Wheel RH Silver	4	




Painted Parts & Decals



No.	Part No.	Description	Qty.	Remarks
12	36 JD00 48	Kit Seat Cowl Decal Black Red	1	Refer Kit List
	36 JD00 52	Kit Seat Cowl Decal Royal Blue	1	Refer Kit List
	36 JD00 61	Kit Seat Cowl Decal FI Red	1	Refer Kit List
	36 JD00 70	Kit Seat Cowl Decal Eb. Blk. Chrome	1	
	36 JD00 74	Kit Seat Cowl Decal Ryl. Blue Crome	1	
	36 JD00 79	Kit Seat Cowl Decal Passion Red	1	
13	JD 2331 68	Decal Side Cover LH Ebony Black	1	
	JD 2331 88	Decal Side Cover LH Royal Blue	1	
	JD 2332 46	Decal Cover Side LH Black Chrome	1	
	JD 2332 62	Decal Side Cover LH Blue Chrome	1	
	JD 2332 78	Decal Side Cover LH Passion Red	1	
14	JD 2331 69	Decal Side Cover RH Ebony Black	1	
	JD 2331 89	Decal Side Cover RH Royal Blue	1	
	JD 2332 47	Decal Side Cover RH Black Chrome	1	
	JD 2332 63	Decal Side Cover RH Blue Chrome	1	
	JD 2332 79	Decal Side Cover RH Passion Red	1	
15	36 JD00 46	Kit Fairing Decal Black Red	1	Refer Kit List
	36 JD00 50	Kit Fairing Decal Royal Blue	1	Refer Kit List
	36 JD00 57	Kit Fairing Decal FI Red	1	Refer Kit List
	36 JD00 68	Kit Fairing Decal Ebony Black Crome	1	
	36 JD00 72	Kit Fairing Decal Royal Blue Chrome	1	
	36 JD00 77	Kit Decal Fairing Passion Red	1	
16	36 JD00 47	Kit Spoiler Decal Black Red	1	Refer Kit List
	36 JD00 51	Kit Spoiler Decal Royal Blue	1	Refer Kit List
	36 JD00 58	Kit Spoiler Decal FI Red	1	Refer Kit List
	36 JD00 69	Kit Spoiler Decal Ebony Black Crome	1	
	36 JD00 73	Kit Spoiler Decal Royal Blue Chrome	1	
	36 JD00 78	Kit Decal Spoiler Passion Red	1	




Painted Parts & Decals




No.	Part No.	Description	Qty.	Remarks
17	36 JD00 45	Kit Tank Decal Black Red	1	Refer Kit List
	36 JD00 49	Kit Tank Decal Royal Blue	1	Refer Kit List
	36 JD00 60	Kit Tank Decal FI Red	1	Refer Kit List
	36 JD00 67	Kit Tank Decal Ebony Black Chrome	1	
	36 JD00 71	Kit Tank Decal Royal Blue Chrome	1	
	36 JD00 76	Kit Decal Tank Passion Red	1	
18	JD 2331 50	Decal Tank 3D Ebony Black	2	
19	36 JD00 59	Kit Decal Side Cover FI Red	1	

Painted Parts & Decals - Cocktail Wine Red & Saffire Blue



No.	Part No.	Description	Qty.	Remarks
1	56 JD05 2V	Front Fender P135 (Jd181400) C. Wine Red	1	
	56 JD05 5N	Front Fender P135 (Jd181400) Saffire Blue	1	
2	52 JD09 58	Spoiler Asly Cw Red WH Decal	1	
	52 JD09 59	Spoiler Asly Saffire Blue WH Decal	1	
3	52 JD09 40	Cowl LH C. Wine Red WH Decal	1	
	52 JD09 41	Cowl LH Saffire Blue WH Decal	1	
4	52 JD09 42	Cowl RH C. Wine Red WH Decal	1	
	52 JD09 43	Cowl RH Saffire Blue WH Decal	1	
5	52 JD09 52	Sd Cvr LH Asly C. Wine Red	1	
	52 JD09 53	Sd Cvr LH Asly Saffire Blue	1	
6	52 JD09 56	Sd Cvr RH Asly C. Wine Red	1	
	52 JD09 57	Sd Cvr RH Asly Saffire Blue	1	
7	52 JD09 46	Seat Cowl C. Wine Red WH Decal	1	
	52 JD09 47	Seat Cowl Saffire Blue WH Decal	1	
8	52 JD09 60	Tank C. Wine Red WH Decal	1	
	52 JD09 61	Tank Saffire Blue WH Decal	1	
9	JD 2333 23	Decal Cover Side LH Cw Red	1	
	JD 2333 39	Decal Cover Side LH Saffire Blue	1	
10	JD 2333 24	Decal Cover Side RH Cw Red	1	
	JD 2333 40	Decal Cover Side RH Saffire Blue	1	

Painted Parts & Decals - Cocktail Wine Red & Saffire Blue



No.	Part No.	Description	Qty.	Remarks
11	36 JD00 87	Kit Fairing Decal Cw Red	1	
	36 JD00 83	Kit Fairing Decal Saffire Blue	1	
12	36 JD00 88	Kit Spoiler Decal Cw Red	1	
	36 JD00 84	Kit Spoiler Decal Saffire Blue	1	
13	36 JD00 86	Kit Tank Decal Cw Red	1	
	36 JD00 82	Kit Tank Decal Saffire Blue	1	
14	36 JD00 89	Kit Seat Cowl Decal Cw Red	1	
	36 JD00 85	Kit Seat Cowl Decal Saffire Blue	1	

Consumable Parts

1		2		3	
4		5		6	
7		8		9	
10		11		12	

No.	Part No.	Description	Supply Unit	Application
1	36 0010 61 83 0204 11 83 0203 34	Bajaj Genuine Oil 10W50 Bajaj Genuine Oil 10W30 Bajaj Genuine Oil 20W50 (BGO to be ordered to HPCL)	1.5 Ltr. 1 Ltr. 1 Ltr.	Dominar 400 100cc Models 125cc and above models
2	36 0010 58	Bajaj Coolant Koolex	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61 83 0203 25	Brake Fluid DOT4 Brake Fluid DOT3	100 ml 100 ml	Disc Brake Top-up/Replace Disc Brake Top-up/Replace
4	36 0010 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 83 0203 68	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 0010 52	HP Lithon RR Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04	Fork oil	160 ml	Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

Consumable Parts

13		14		15	
16		17		18	
19		20		21	
22		23		24	

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray		For Cleaning Carburetor
24	37 2540 39	Corrosion Protection Spray Proto quick LTP902 (To be ordered on Vendor)	--	For Preventing vehicle parts from rusting

Kit List

*pulsar***135LS** UG, BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JE0001	Valve Repair Kit	39201719	Seat Valve Stem	2
			DG101029	Cotter Valve	2
			JD511205	Retainer Valve Spring	2
			JD511203	Seat Valve Spring	2
			JA511202	Spring Valve	2
2	36JE0003	Kit Guide Camchain	JW541012	Guide Camchain (Slack Side)	1
			JA521002	Guide Camchain (Tight Side)	1
3	36JE0002	Piston Ring Set	JE521202	Ring Piston Top	1
			JE521203	Ring Piston Second	1
			JE521204	Ring Piston Oil	1
4	36DU1007	Boss Kick Set	30101233	Boss Kit	1
			30101234	Spring	1
			30101236	Ball Steel	1
			30101235	Pin	1
			39085517	E - Type Clip	1
5	36JE0007	Chain Sprocket Kit	DJ151086	Sprocket Hub (42T)	1
			JV551000	Sprocket Drive (14T)	1
			JD141000	Chain 118 Link - 420 Series	1
6	36JW0014	Starter Clutch Repair Kit	JA621411	Bush Spring Starter Clutch	5
			DH101163	Roller Clutch	5
			JA621412	Spring	5
			DJ101109	Bush For Spring Starter Clutch	5
7	36JE0004	Set Primary Drive & Driven	JE551402	Housing Compl Clutch	1
			JA531010	Gear Primary Drive	1
8	36DS1802	Bearing Cone Kit	DH181025	Bearing cone	1
			DH181026	Bearing race	1
			DH181024	Upper bearing race	1
9	36JE0009	Grommet Kit - Side Cover	DS141012	Grommet Side Cover Front	2
			DS161082	Grommet Side Cover Rear	2

Kit List

*pulsar***135LS** UG, BS IV

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
10	52JD0025	Case Chain Kit	JD181213	Case Chain Upper Assembly	1
			JD181216	Case Chain Lower Assembly	1
			15161069	Cap Rubber	1
11	36JD0006	Jet Needle Hardware Kit	DP121056	Holder for Jet Needle	1
			JE581217	E - Type Clip	1
			PP121052	Washer - Jet Needle	1
			JE581216	Spring Jet Needle	1
12	36JD0005	Carb. Gasket- 'O' Ring Kit	DP121059	Gasket Float Chamber	1
			DH121018	Top Gasket	1
			JE581209	'O' - Ring	3
			JE581207	'O' - Ring 24x26 (eng Side)	1
			JE581215	'O' Ring Auto Chock	1
13	DK121041	Idling Screw Kit	JE581210	Screw Idling Adjuster	1
			JE581211	Spring	1
14	36JD0004	Vaccum Piston Kit	JE581212	Vaccum Piston Complete	1
			JE581213	Diaphram	1
			JE581214	Spring	1
15	36JD0001	Jet Kit	JE581201	Jet Needle	1
			JE581202	Needle Jet	1
			JE581203	Holder Needle Jet	1
			JE581204	Jet Main	1
			JE581201	Jet Pilot	1
16	36JD0002	VC Screw Kit	JE581206	Screw Adjuster VC	1
			JE581207	'O' - Ring Head	1
			JE581206	Spring Screw VC	1
			24121063	Plain Washer	1
			JE581209	'O' - Ring (at tip)	1
17	36JD0044	Kit Cyl. Head BS IV	JE511062	Cylinder Head P135 SAI	1
			31101064	Plug	1
			JA511028	Stud M8 x 1.25 x 45L	2

pulsar135LS UG, BS IV

125

pulsar135LS UG, BS IV

126

[illegible][illegible]

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
01 1605 08	4	96	36 0010 60	18	122
01 1605 08	19	98	36 0010 61	1	120
14 1510 33	20	26	36 0010 62	9	120
14 1510 33	15	30	36 3140 01	4	48
22 1502 41	4	36	36 3140 04	10	120
24 1214 62	9	4	36 DH19 02	15	64
30 1011 42	4	26	36 DH40 29	11	120
30 1011 95	8	28	36 DH40 61	3	120
30 1410 39	5	84	36 DH40 71	12	120
30 1510 05	21	70	36 DH40 72	13	122
30 1510 11	19	68	36 DK00 13	10	54
30 1510 33	1	62	36 DK00 17	7	72
30 1510 38	20	68	36 DK00 18	8	72
30 1510 68	17	68	36 DS18 02	4	48
30 1510 69	16	68	36 DS18 02	10	78
30 1510 75	13	68	36 DU10 07	3	36
30 1510 96	14	72	36 DU19 01	11	74
30 1511 18	18	62	36 DZ00 20	2	78
30 1810 09	6	48	36 JD00 01	3	34
30 1810 11	2	48	36 JD00 02	2	34
30 1810 25	4	78	36 JD00 04	11	34
30 1810 26	3	78	36 JD00 05	12	34
30 1810 29	20	78	36 JD00 06	16	34
30 1910 17	10	74	36 JD00 07	16	52
30 1910 48	18	104	36 JD00 09	1	28
30 2010 85	15	104	36 JD00 10	1	26
30 2011 04	14	104	36 JD00 44	1	6
31 1011 73	3	14	36 JD00 45	17	114
31 2010 79	19	104	36 JD00 46	15	112
31 2010 81	5	24	36 JD00 47	16	112
33 1410 08	12	84	36 JD00 48	12	112
35 1610 60	18	98	36 JD00 49	17	114
36 0010 52	4	120	36 JD00 50	15	112
36 0010 52	6	120	36 JD00 51	16	112
36 0010 55	8	120	36 JD00 52	12	112
36 0010 56	23	122	36 JD00 57	15	112
36 0010 58	2	120	36 JD00 58	16	112

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 JD00 59	19	114	37 0043 52	16	122
36 JD00 60	17	114	37 0043 53	17	122
36 JD00 61	12	112	37 2240 18	19	122
36 JD00 67	17	114	37 2540 39	24	122
36 JD00 68	15	112	39 0211 11	11	56
36 JD00 69	16	112	39 0240 11	13	30
36 JD00 70	12	112	39 0242 11	7	56
36 JD00 71	17	114	39 0292 15	13	52
36 JD00 72	15	112	39 0326 15	6	56
36 JD00 73	16	112	39 0422 15	9	58
36 JD00 74	12	112	39 0454 11	9	52
36 JD00 76	17	114	39 0553 02	8	52
36 JD00 77	15	112	39 0594 17	12	10
36 JD00 78	16	112	39 0694 15	12	72
36 JD00 79	12	112	39 0722 11	19A	68
36 JD00 82	13	118	39 0738 17	6	36
36 JD00 83	11	118	39 0740 11	7	84
36 JD00 84	12	118	39 0747 01	9	24
36 JD00 85	14	118	39 0758 01	16	40
36 JD00 86	13	118	39 0789 12	11	72
36 JD00 87	11	118	39 0797 08	3	58
36 JD00 88	12	118	39 0798 15	3	94
36 JD00 89	14	118	39 0801 15	3	68
36 JE00 01	6	8	39 0807 08	13	72
36 JE00 02	3	12	39 0808 08	15	20
36 JE00 04	7	14	39 0900 12	9	62
36 JE00 04	16	30	39 0987 17	3	16
36 JE00 07	2	68	39 0992 06	2	18
36 JE00 09	1	86	39 0992 06	4	32
36 JE00 12	5	12	39 0993 11	5	36
36 JE00 14	2	68	39 0999 06	6	22
36 JW00 14	6	46	39 0999 06	11	24
36 JZ00 09	2	22	39 0999 06	21	26
36 JZ00 11	1	24	39 1000 06	2	12
36 JZ01 21	4	30	39 1041 19	3	26
36 PA01 15	6	10	39 1054 11	7	86
36 PD00 45	11	66	39 1065 04	2	28

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 1180 11	27	76	39 1943 04	23	102
39 1181 01	12	78	39 1956 04	6	86
39 1225 15	4	100	39 1956 04	3	104
39 1283 21	8	6	39 1964 04	13	22
39 1283 21	12	6	39 1970 15	2	50
39 1507 11	2	104	39 1972 15	19	102
39 1523 01	15	102	39 1981 04	22	16
39 1552 04	7	88	39 1998 19	4	72
39 1553 04	11	30	39 2017 19	7	8
39 1553 04	11	98	39 2060 04	17	56
39 1553 04	6	102	39 2124 15	4	102
39 1666 05	2	6	39 2179 24	14	102
39 1671 21	17	26	39 2190 19	7	24
39 1673 04	11	10	39 2200 11	12	30
39 1673 04	19	26	39 2208 04	8	98
39 1673 04	17	40	39 2240 20	6	68
39 1675 04	3	44	39 2295 15	3	38
39 1677 04	18	40	39 2312 04	3	50
39 1715 19	4	24	39 2366 15	5	52
39 1759 04	16	24	39 2381 04	2	84
39 1765 11	12	98	39 2408 17	12	36
39 1778 02	3	90	39 2420 01	8	56
39 1778 02	2	98	39 2427 04	16	74
39 1778 02	17	98	39 2443 11	9	26
39 1783 01	11	102	39 2447 04	23	70
39 1789 24	5	86	39 2453 04	16	20
39 1844 01	13	98	39 2484 15	10	84
39 1849 04	11	94	39 2492 11	8	38
39 1913 04	5	100	39 2498 04	4	50
39 1913 04	8	100	39 2562 20	2	24
39 1943 04	12	44	39 2567 11	26	70
39 1943 04	12	56	39 2600 11	3	30
39 1943 04	19	74	39 2608 01	10	6
39 1943 04	3	86	39 2629 21	11	6
39 1943 04	7	94	39 2669 21	13	10
39 1943 04	16	98	39 2686 20	12	68
39 1943 04	8	102	39 2687 20	15	68

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 2723 15	6	50	52 JD07 68	7	110
39 2726 12	6	52	52 JD07 70	7	110
39 2754 04	7	38	52 JD07 74	5	108
39 2754 04	9	38	52 JD07 75	5	108
39 2754 04	11	86	52 JD07 78	6	110
39 2758 21	8A	84	52 JD07 79	6	110
52 JA00 29	11	22	52 JD07 80	2	108
52 JD01 75	10	102	52 JD07 81	2	108
52 JD03 67	1	108	52 JD07 82	9	110
52 JD05 93	5	108	52 JD07 83	9	110
52 JD05 94	5	108	52 JD08 12	1	108
52 JD05 97	6	110	52 JD08 21	3	108
52 JD05 98	6	110	52 JD08 22	4	108
52 JD05 99	7	110	52 JD08 60	5	108
52 JD06 00	7	110	52 JD08 61	6	110
52 JD06 03	3	108	52 JD08 62	7	110
52 JD06 04	3	108	52 JD08 65	2	108
52 JD06 07	8	110	52 JD08 66	9	110
52 JD06 08	9	110	52 JD09 40	3	116
52 JD06 09	2	108	52 JD09 41	3	116
52 JD06 10	2	108	52 JD09 42	4	116
52 JD06 38	4	108	52 JD09 43	4	116
52 JD06 39	4	108	52 JD09 46	7	116
52 JD06 43	25	76	52 JD09 47	7	116
52 JD06 43	1	84	52 JD09 52	5	116
52 JD06 43	1	84	52 JD09 53	5	116
52 JD06 53	5	108	52 JD09 56	6	116
52 JD06 55	6	110	52 JD09 57	6	116
52 JD06 56	3	108	52 JD09 58	2	116
52 JD06 57	4	108	52 JD09 59	2	116
52 JD06 59	7	110	52 JD09 60	8	116
52 JD06 61	9	110	52 JD09 61	8	116
52 JD06 62	2	108	52 JE55 06	1	28
52 JD07 62	3	108	52 JZ02 64	1	20
52 JD07 63	4	108	56 JD05 2V	1	116
52 JD07 65	3	108	56 JD05 5N	1	116
52 JD07 66	4	108	56 JD05 7Q	1	108

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 JD05 X3	1	108	DD 1010 62	10	10
56 JD3X 1Y	2	54	DD 1010 97	13	36
56 JD3Y 1Y	1	54	DD 1110 11	10A	44
59 0200 01	7	82	DD 1110 12	11	44
59 0400 07	7	78	DD 1110 18	8	44
59 0400 14	15	44	DD 1211 81	16	26
59 0400 31	4	10	DD 1412 27	6	84
59 0400 38	2	2	DD 1610 71	10	38
59 0400 38	10	22	DD 2010 02	18	102
59 0400 38	15	24	DD 2010 11	2	102
59 0400 38	4	28	DE 1510 06	3	62
59 0400 38	14	26	DE 1510 08	5	62
59 0400 50	7	2	DE 1510 12	4	62
59 1100 08	2B	14	DE 1910 10	5	64
59 1200 03	2A	14	DF 1611 02	8	58
59 1500 03	11	52	DG 1010 29	3	8
59 1500 03	17	62	DG 1014 18	7	26
59 1500 14	1	14	DG 1210 03	11	4
59 2000 36	3	22	DG 1611 21	2	86
59 2000 36	3	24	DG 1810 08	3	56
59 2100 19	8	62	DG 1810 08	4	74
59 2100 23	13	24	DH 0101 67	10	110
59 2100 24	19	16	DH 0101 68	11	110
62 3050 84	22	122	DH 0102 09	10	110
75 6802 36	20	122	DH 0102 10	11	110
76 0109 36	14	122	DH 1010 48	5	10
76 0109 37	15	122	DH 1013 01	11	38
83 0201 73	7	120	DH 1013 80	8	22
83 0203 25	3	120	DH 1013 80	4	44
83 0203 34	1	120	DH 1013 92	7	10
83 0203 68	5	120	DH 1013 95	5	38
83 0204 11	1	120	DH 1015 09	13	20
83 0204 73	5	120	DH 1016 48	14	30
BF 5612 19	8	20	DH 1017 81	2	46
CF 1110 19	8	44	DH 1017 84	6	24
CL 2010 23	3	98	DH 1110 13	11A	44
CS 1011 28	9	10	DH 1110 15	9	44

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DH 1210 59	6	34	DJ 1810 52	26	80
DH 1210 63	10	34	DJ 1810 64	24	80
DH 1210 64	15	34	DJ 1810 83	3	102
DH 1210 93	5	34	DJ 1810 85	27	80
DH 1611 45	5	58	DJ 1811 04	6	78
DH 1611 46	11	58	DJ 1811 15	5	48
DH 1611 55	11	54	DJ 1910 23	1	64
DH 1611 57	9	54	DJ 1910 27	6	64
DH 1612 39	4	58	DJ 1910 28	7	64
DH 1612 40	7	58	DJ 1910 29	8	64
DH 1613 09	13	58	DJ 1910 30	9	64
DH 1810 14	3	48	DJ 1910 31	10	64
DH 1810 22	15	74	DJ 1910 34	13	64
DH 1910 07	12	74	DJ 1910 35	14	64
DH 1910 08	13	74	DJ 1910 54	7	74
DH 1910 12	6	104	DJ 1910 55	8	74
DH 1910 17	24	76	DJ 1910 56	11	64
DH 2010 80	3	92	DJ 1910 57	3	64
DJ 1410 08	8	86	DJ 2010 72	5	98
DJ 1510 37	12	52	DJ 2010 72	13	102
DJ 1510 47	14	52	DJ 2011 09	12	64
DJ 1510 68	3	66	DJ 2011 95	21	76
DJ 1510 69	4	66	DJ 2210 19	1	106
DJ 1510 70	5	66	DK 1210 41	4	34
DJ 1510 72	7	66	DK 1410 15	13	84
DJ 1510 73	8	66	DK 1510 69	4	64
DJ 1510 74	9	66	DK 1810 31	20	74
DJ 1510 75	10	66	DK 1810 79	26	76
DJ 1510 88	14	68	DK 2010 37	1	104
DJ 1510 92	18	68	DK 2010 38	1	104
DJ 1510 94	6	62	DK 2110 08	6	88
DJ 1610 12	10	28	DK 2110 09	2	88
DJ 1610 69	5	56	DL 1610 15	13	56
DJ 1610 91	2	56	DL 1610 15	10	86
DJ 1612 29	21	102	DL 1910 14	9	74
DJ 1710 33	27	70	DM 1810 10	13	78
DJ 1810 29	25	80	DP 1011 11	6	30

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DP 1011 65	4	12	JA 1134 03	9	50
DP 1011 98	7	6	JA 1134 04	5	50
DP 1210 25	8	40	JA 1210 05	10	72
DP 1210 67	7	34	JA 1612 00	1	92
DP 1710 06	15	52	JA 2312 01	2	94
DS 1011 17	8	36	JA 2312 02	4	94
DS 1011 54	6	14	JA 3516 00	7	46
DS 1012 15	8	26	JA 4018 00	8	104
DS 1012 76	3	10	JA 4018 05	10	104
DS 1211 26	7	40	JA 4022 02	16	104
DS 1510 29	6	60	JA 5110 08	4	2
DS 1510 31	5	60	JA 5110 11	6	2
DS 1510 48	2	60	JA 5110 11	9	40
DS 1510 49	3	60	JA 5110 28	2	6
DS 1510 58	15	62	JA 5112 16	2	10
DS 1510 73	8	68	JA 5310 12	8	14
DS 1611 25	4	56	JA 5310 15	9	14
DS 1612 24	12	104	JA 5410 05	8	24
DS 1810 15	8	78	JA 5410 05	6	28
DS 1810 16	9	78	JA 5410 10	5	22
DS 1910 52	14	74	JA 5410 11	4	22
DS 1910 52	17	74	JA 5410 12	12	22
DS 2010 25	11	104	JA 5410 16	2	32
DS 2010 36	4	98	JA 5410 19	12	24
DS 2010 82	7	104	JA 5410 21	14	24
DS 2110 04	3	88	JA 5410 28	14	44
DS 2110 07	5	88	JA 5410 34	10	24
DU 1012 13	21	16	JA 5412 05	3	28
DU 1412 72	15	42	JA 5412 11	11	26
DX 1510 22	11	68	JA 5412 12	13	26
DX 1510 81	1	68	JA 5412 25	12	26
FD 1010 78	3	32	JA 5412 33	7	28
GH 2010 12	3	100	JA 5510 02	4	16
JA 1130 11	14	58	JA 5510 04	8	16
JA 1132 01	2	58	JA 5510 08	17	16
JA 1134 02	7	50	JA 5510 09	18	16
JA 1134 03	1	50	JA 5514 06	2	30

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JA 5810 09	5	40	JD 1138 15	14	4
JA 5810 11	15	40	JD 1210 02	17	78
JA 5810 12	6	40	JD 1220 02	10	52
JA 5814 06	5	6	JD 1220 03	3	52
JA 6210 02	9	36	JD 1220 04	9	72
JA 6210 06	11	36	JD 1220 09	4	52
JA 6212 06	2	36	JD 1220 13	7	52
JA 6212 06	2	66	JD 1312 10	5	68
JA 6214 02	4	46	JD 1312 12	25	70
JA 6214 06	5	46	JD 1316 01	22	70
JA 6214 14	1	46	JD 1318 08	2	64
JB 1220 10	2	52	JD 1318 09	14	56
JB 1220 16	1	52	JD 1318 11	11	62
JB 1310 17	16	62	JD 1318 13	1	66
JB 1310 18	14	62	JD 1318 16	12	62
JB 4014 02	18	74	JD 1410 03	1	68
JB 5310 21	10	14	JD 1510 00	1	78
JB 5810 35	14	40	JD 1510 01	28	80
JC 1410 17	8	82	JD 1510 02	29	80
JC 1910 09	2	72	JD 1510 03	14	78
JD 1110 12	11	40	JD 1510 04	15	78
JD 1110 12	9	86	JD 1510 06	23	80
JD 1110 70	1	48	JD 1510 15	1	74
JD 1130 13	3	54	JD 1510 16	3	74
JD 1130 14	8	54	JD 1510 17	2	74
JD 1130 15	4	54	JD 1510 23	6	100
JD 1130 16	5	54	JD 1510 24	7	100
JD 1130 17	6	54	JD 1510 26	5	78
JD 1130 19	7	54	JD 1510 28	19	78
JD 1132 00	6	58	JD 1510 29	11	78
JD 1132 01	12	58	JD 1510 32	28	76
JD 1134 00	8	50	JD 1510 36	21	80
JD 1138 00	5	102	JD 1510 37	10	98
JD 1138 01	9	100	JD 1510 38	9	98
JD 1138 01	16	102	JD 1510 45	22	76
JD 1138 02	17	102	JD 1510 48	23	76
JD 1138 14	15	4	JD 1610 01	1	72

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JD 1610 02	5	72	JD 2314 13	8	94
JD 1610 03	6	72	JD 2316 00	29	76
JD 1612 01	2	92	JD 2316 01	30	76
JD 1710 16	3	82	JD 2328 00	9	102
JD 1710 18	5	82	JD 2328 01	22	102
JD 1710 38	9	84	JD 2328 03	7	102
JD 1710 63	8	42	JD 2328 04	10	100
JD 1710 64	10	42	JD 2328 05	11	100
JD 1716 02	3	84	JD 2331 50	18	114
JD 1716 05	3	42	JD 2331 62	10	110
JD 1716 07	14	42	JD 2331 63	11	110
JD 1718 00	11	84	JD 2331 68	13	112
JD 1810 00	18	56	JD 2331 69	14	112
JD 1810 01	19	56	JD 2331 82	10	110
JD 1810 02	20	56	JD 2331 83	11	110
JD 1810 06	21	56	JD 2331 88	13	112
JD 1812 11	2	90	JD 2331 89	14	112
JD 1812 21	7	98	JD 2332 46	13	112
JD 1812 28	14	98	JD 2332 47	14	112
JD 1812 29	15	98	JD 2332 62	13	112
JD 1812 32	2	96	JD 2332 63	14	112
JD 1812 33	1	96	JD 2332 78	13	112
JD 1812 34	3	96	JD 2332 79	14	112
JD 1812 40	20	98	JD 2333 23	9	116
JD 1812 41	21	98	JD 2333 24	10	116
JD 1812 49	22	98	JD 2333 39	9	116
JD 1814 01	1	56	JD 2333 40	10	116
JD 1814 02	9	56	JD 3512 06	10B	44
JD 1814 08	15	56	JD 4010 03	2	100
JD 1814 09	16	56	JD 4010 04	1	100
JD 1814 12	10	56	JD 4010 07	12	102
JD 1910 06	4	88	JD 4010 08	1	102
JD 1910 18	1	88	JD 4010 24	1	98
JD 2312 00	5	94	JD 4010 25	6	98
JD 2312 01	1	94	JD 4014 00	6A	74
JD 2312 03	10	94	JD 4018 03	20	104
JD 2312 04	6	94	JD 4022 14	4	104

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JD 4022 32	5A	104	JE 5110 67	4	4
JD 4022 33	5	104	JE 5112 30	14	10
JD 4022 34	4A	104	JE 5210 16	8	10
JD 4024 05	1	90	JE 5310 00	4	14
JD 4026 01	8	84	JE 5310 01	5	14
JD 5110 04	9	6	JE 5410 08	14	36
JD 5110 08	3	6	JE 5412 11	2	26
JD 5110 10	3	2	JE 5412 12	9	28
JD 5112 01	4	8	JE 5412 14	10	26
JD 5112 02	5	8	JE 5412 18	18	26
JD 5112 07	2	8	JE 5412 19	5	28
JD 5112 09	1	8	JE 5412 21	11	28
JD 5112 11	1	10	JE 5512 01	5	16
JD 5210 02	1	12	JE 5512 06	13	16
JD 5310 04	11	14	JE 5514 01	6	26
JD 5410 00	12	14	JE 5514 11	17	30
JD 5514 00	1	30	JE 5514 13	8	30
JD 5610 04	5	18	JE 5514 14	5	30
JD 5610 06	4	18	JE 5514 15	10	30
JD 5610 11	3	18	JE 5610 05	7	18
JD 5612 04	5	20	JE 5610 06	1	18
JD 5614 13	10	20	JE 5810 00	12	40
JD 5614 16	12	20	JE 5810 27	10	4
JD 5614 21	11	20	JE 5810 28	1	40
JD 5614 23	9	20	JE 5810 37	6	4
JD 5810 01	2	40	JE 5810 38	3	4
JD 5810 07	13	40	JE 5810 39	2	4
JD 5910 26	4	38	JE 5810 41	7	4
JD 5910 56	1	38	JE 5812 18	14	34
JD 6210 01	7	36	JE 5812 19	13	34
JE 3510 02	1	44	JE 5812 23	8	34
JE 3512 03	5	44	JE 5812 24	9	34
JE 3512 04	6	44	JE 5812 51	1	34
JE 3512 46	7	44	JE 5814 01	6	6
JE 3514 03	6	12	JE 5814 12	12	4
JE 5010 49	1	22	JE 5814 17	4	6
JE 5010 49	9	22	JE 5910 02	2	38

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JE 6212 02	1	36	JY 1138 42	11	42
JF 4014 00	5	74	JY 1710 69	2	42
JF 4014 01	6	74	JY 1710 70	9	42
JG 1710 29	7	42	JY 1710 77	1	42
JG 4018 08	21	104	JY 1710 90	4	42
JH 1710 19	12	42	JY 1718 25	13	42
JH 1710 24	17	42	JY 5810 28	8	4
JH 1710 48	5	42	JY 5810 28	10	40
JH 1716 02	16	42	JZ 1310 12	1	60
JH 5614 04	14	20	JZ 1310 12	13	62
JK 1210 07	16	78	JZ 1312 06	4	60
JK 1210 09	18	78	JZ 5110 21	1	2
JL 4020 04	11A	104	JZ 5510 08	9	16
JN 1312 03	7	68	JZ 5510 10	1	16
JN 1312 11	24	70	JZ 5512 00	7	16
JN 1316 03	7	62	JZ 5512 02	2	16
JN 3516 04	13	104	JZ 5512 04	16	16
JP 3510 07	2	44	JZ 5512 05	15	16
JV 4018 02	9	104	JZ 5512 06	11	16
JV 5412 08	5	26	JZ 5512 08	14	16
JV 5412 09	15	26	JZ 5512 10	10	16
JV 5510 00	20	16	JZ 5512 11	12	16
JW 1318 07	6	66	JZ 5512 13	6	16
JW 1710 06	9	82	JZ 5514 12	9	30
JW 1710 07	4	82	JZ 5610 02	6	18
JW 1710 14	1	82	JZ 5710 00	1	32
JW 1710 15	2	82	JZ 5710 01	5	32
JW 1710 16	6	82	JZ 6210 00	10	36
JW 1710 17	4	86	JZ 6214 05	3	46
JW 2326 01	25	76	KA DF06 30	13	4
JW 2326 01	4	84	KA DF08 22	9	94
JW 4010 10	20	102	KAEG0614	5	4
JW 4020 01	13	44	KB BM04 08	10	62
JW 4022 02	17	104	KC GA06 06	16	4
JW 5612 06	2	20	KP BB63 01	2	62
JW 5612 08	3	20	LA A000 04	3	72
JW 5910 30	6	38	LA C000 09	22	80

Parts Index

*pulsar***135LS** UG, BS IV

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LA D000 11	8	46			
LC B000 05	9	68			
LD B000 01	4	68			
LD B000 44	6	20			
LD B000 44	7	20			
LJ A000 04	17	24			
NA	20	122			
NA	21	122			
PA 1132 04	10	58			
PA 5110 39	5	2			
PA 5612 09	4	20			
PA 5810 38	1	4			
PD 1716 16	6	42			
PF 1132 02	1	58			
PF 1312 20	10	68			
PF 5410 18	7	22			
PF 5810 11	3	40			
PF 5810 12	4	40			
YJ D070 02	4	90			