



Bajaj Auto Limited
Akurdi Pune 411 035 India
Tel +91 20 27472851
Fax +91 20 27407385
Toll Free 1800 233 2453
www.bajajauto.com
CIN : L65993PN2007PLC130076

Spare Parts Catalogue

(V15 BSIV & V12)





Notice

All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71112414

REV. 07 SEPT. 17

Copy rights : All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

Foreword



We have pleasure in presenting the Spare Parts Catalogue for 'V15 BSIV & V12' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instructions



1. **How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

2. **How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

3. **Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

4. **Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

[illegible][illegible]

THE INVINCIBLE

[illegible][illegible]

Index



Plate No.	Description	Page No.
1	Cylinder Head & Cylinder Cover	2 - 4
2	SAI System	6
3	Valve	8
4	Camshaft & Tensioner	10
5	Cylinder and Piston	12
6	Crankshaft	14
7	Transmission	16
8	Change Drum & Shift Fork	18
9	Gear Change Mechanism	20
10	Engine Assembly & Crankcase RH	22
11	Crankcase LH	24
12	Cover Clutch	26
13	Cover Magneto	28
14	Clutch Assembly	30
15	Oil Pump Assembly	32
16	Carburetor Assembly - V15	34
17	Carburetor Assembly - V12	36
18	Kick Starter Mechanism	38
19	Silencer Assembly	40
20	Air Cleaner Assembly	42
21	EVAP Mechanism	44
22	Magneto, CDI, Spark Plug & H.T. Coil	46
23	Starter Motor & Starter Gear	48
24	Frame and Frame Fittings	50
25	Engine Mountings	52
26	Swing Arm & Rear Shock Absorber	54
27	Main Step & Pillion Step Assembly	56
28	Mudguard - Front & Rear	58
29	Center & Side Stand Assembly	60
30	Wheel Rim & Tyres	62
31	Front Wheel Assembly	64

Index



Plate No.	Description	Page No.
32	Front Hub - V12 Drum	66
33	Rear Wheel Assembly	68 - 70
34	Rear Brake Pedal	72
35	Front Master Cylinder Assembly	74
36	Front Brake - Caliper & Disc	76
37	Handle Bar Assembly	78
38	Front Fork	80 - 82
39	Fuel Tank	84
40	Seat Assembly & Seat Lock	86
41	Speedometer	88
42	Cables	90
43	Side Covers & Seat Cowl Fittings	92
44	Leg Guards, Saree Guard & Grab Handle	94
45	Head Light	96 - 98
46	Indicator Light	100
47	Electrical Equipment	102
48	Chain Case Kit & Tool Kit	104
49	Front & Rear Number Plate	106
50	Painted Parts and Decals - V15	108 - 110
51	Painted Parts and Decals - V12	112 - 114
52	Consumable Parts	115 - 118
	Kits List	119 - 124
	Part Index	125 - 144

Pictorial Index



PLATE NO. : 1 CYLINDER HEAD & CYLINDER COVER	PAGE NO. 1 - 3	PLATE NO. : 2 SAI System	PAGE NO. 5

PLATE NO. : 3 VALVE	PAGE NO. 7	PLATE NO. : 4 CAMSHAFT & TENSIONER	PAGE NO. 9

Pictorial Index



PLATE NO. : 5 CYLINDER & PISTON	PAGE NO. 11	PLATE NO. : 6 CRANKSHAFT	PAGE NO. 13

PLATE NO. : 7 TRANSMISSION	PAGE NO. 15	PLATE NO. : 8 CHANGE DRUM & SHIFT FORK	PAGE NO. 17

Pictorial Index



PLATE NO. : 9 GEAR CHANGE MECHANISM	PAGE NO. 19	PLATE NO. : 10 ENGINE ASSEMBLY & CRANKCASE RH	PAGE NO. 21

PLATE NO. : 11 CRANKCASE LH	PAGE NO. 23	PLATE NO. : 12 COVER CLUTCH	PAGE NO. 25

Pictorial Index



PLATE NO. : 13 COVER MAGNETO	PAGE NO. 27	PLATE NO. : 14 CLUTCH ASSEMBLY	PAGE NO. 29

PLATE NO. : 15 OIL PUMP ASSEMBLY	PAGE NO. 32	PLATE NO. : 16 CARBURETOR ASSEMBLY - V15	PAGE NO. 33

Pictorial Index



PLATE NO. : 17 CARBURETOR ASSEMBLY - V12	PAGE NO. 35
---	----------------

PLATE NO. : 18 KICK STARTER MECHANISM	PAGE NO. 37
--	----------------

PLATE NO. : 19 SILENCER ASSEMBLY	PAGE NO. 39
-------------------------------------	----------------

PLATE NO. : 19 AIR CLEANER ASSEMBLY	PAGE NO. 37
--	----------------

Pictorial Index



PLATE NO. : 21 AIR CLEANER ASSEMBLY	PAGE NO. 43
--	----------------

PLATE NO. : 22 MAGNETO, CDI, SPARK PLUG & H.T. COIL	PAGE NO. 45
--	----------------

PLATE NO. : 23 STARTER MOTOR & STARTER GEAR	PAGE NO. 47
--	----------------

PLATE NO. : 24 FRAME AND FRAME FITTINGS	PAGE NO. 49
--	----------------

Pictorial Index



PLATE NO. : 25 ENGINE MOUNTINGS	PAGE NO. 52	PLATE NO. : 26 SWING ARM & REAR SHOCK ABSORBER	PAGE NO. 53

PLATE NO. : 27 MAIN STEP & PILLION STEP ASSEMBLY	PAGE NO. 55	PLATE NO. : 28 MUDGUARD - FRONT & REAR	PAGE NO. 57

Pictorial Index



PLATE NO. : 29 CENTER & SIDE STAND ASSEMBLY	PAGE NO. 59	PLATE NO. : 30 WHEEL RIM & TYRE	PAGE NO. 61
PLATE NO. : 31 FRONT WHEEL ASSEMBLY	PAGE NO. 63	PLATE NO. : 32 FRONT HUB - V12 Drum	PAGE NO. 65

Pictorial Index



PLATE NO. : 33 REAR WHEEL ASSEMBLY	PAGE NO. 67 - 69	PLATE NO. : 34 REAR BRAKE PEDAL	PAGE NO. 71

PLATE NO. : 35 FRONT MASTER CYLINDER ASSEMBLY	PAGE NO. 73	PLATE NO. : 36 FRONT BRAKE - CALIPER & DISC	PAGE NO. 75

Pictorial Index



PLATE NO. : 37 HANDLE BAR ASSEMBLY	PAGE NO. 77	PLATE NO. : 38 FRONT FORK	PAGE NO. 79 - 81

PLATE NO. : 39 FUEL TANK	PAGE NO. 83	PLATE NO. : 40 SEAT ASSEMBLY & SEAT LOCK	PAGE NO. 85

Pictorial Index



PLATE NO. : 41 SPEEDOMETER	PAGE NO. 87	PLATE NO. : 42 CABLES	PAGE NO. 89

PLATE NO. : 43 SIDE COVERS & SEAT COWL FITTINGS	PAGE NO. 91	PLATE NO. : 44 LEG GUARDS, SAREE GUARD & GRAB HANDLE	PAGE NO. 93

Pictorial Index



PLATE NO. : 45 HEAD LIGHT	PAGE NO. 95 - 97	PLATE NO. : 46 INDICATOR LIGHT	PAGE NO. 99

PLATE NO. : 47 ELECTRICAL EQUIPMENT	PAGE NO. 102	PLATE NO. : 48 CHAIN CASE KIT & TOOL KIT	PAGE NO. 104

Pictorial Index




PLATE NO. : 49 FRONT & REAR NUMBER PLATE	PAGE NO. 107
---	-----------------

PLATE NO. : 51 PAINTED PARTS AND DECALS - V12	PAGE NO. 111 - 113
--	-----------------------

Pictorial Index




PLATE NO. : 50 PAINTED PARTS AND DECALS - V15	PAGE NO. 107 - 109
--	-----------------------



Cylinder Head & Cylinder Cover

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	36 JH00 23	Kit Cyl Head & Cover	1	--	Refer Kit Details
1A	36 JH00 27	Kit Cyl Head & Cover	--	1	Refer Kit Details
2	JH 5814 01	Manifold Intake	1	-	
2A	JH 5814 10	Manifold Intake	-	1	
3	LA C000 75	Bolt Socket	2	-	
4	LD A000 23	Washer	2	-	
5	LA D001 38	Flanged Bolt	4	-	
	LA D001 67	Bolt Flanged	-	4	
6	39 1612 11	Washer	4	4	
7	39 1020 21	O Ring Tappet Cover	2	-	
	JH 5110 50	O Ring Tappet Cover	-	2	
8	31 1010 06	Tappet Cap	2	-	
	52 JH55 05	Tappet Cover	-	2	
9	39 1673 04	Flanged Bolt	4	-	
	KA ED06 20	Bolt Flanged Small	-	4	
10	CB 1010 09	Seal Valve Stem	2	2	
11	39 2608 01	Grub Screw	1	1	
12	39 2629 21	O Ring	1	-	
	KJ AC18 24	O Ring	-	1	
13	39 1283 21	O Ring	1	1	
14	JB 5110 18	Sleeve Spark Plug	1	-	
	JF 5110 52	Sleeve Spark Plug	--	1	
15	39 2539 21	O Ring	1	-	
	LJ A000 11	O Ring	-	1	



Cylinder Head & Cylinder Cover


No.	Part No.	Description	Qty.		Remarks
			V15	V12	
16	DG 1210 40	Clamp Breather Pipe	2	2	
17	39 1674 04	Bolt Silver Colour	2	–	
	LA D000 11	Bolt Flanged	–	2	
18	JH 5810 07	Breather Pipe	1	--	
	JH 5810 30	Tube Breather	–	1	
19	JH 5110 16	Gasket Cylinder Head	1	–	
	JH 5110 44	Gasket Head	–	1	
20	39 0999 06	Dowel	2	–	
	39 1000 06	Hollow Dowel Pin	–	2	
21	39 1660 05	Stud	2	2	
22	52 JH55 06	Assembly OHC Cover	–	1	
23	JH 5110 45	O Ring OHC Cover	–	1	
24	KA ED06 20	Bolt Flanged Small	–	3	



5


SAI System

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5824 02	Tube SAI To Cylinder Head	1	1	
2	JE 5110 67	Gasket SAI Flange	1	1	
3	KA EG06 14	Bolt - Flanged - Small	2	2	
4	JE 5810 35	Hose Connector D106C SAI	1	1	
5	JE 5810 39	Band Clip SAI Hose Outlet Tube	3	2	
6	JH 5822 00	SAI Unit	1	1	
7	DG 1210 03	Clamp	2	2	
8	JH 5824 05	Hose SAI Intake Manifold	1	1	
9	JH 5824 00	Hose Intake SAI C101	1	1	
10	JY 5810 28	Clamp	1	1	
11	JD 1138 15	Sleeve SAI Unit	4	4	
12	JD 1138 14	Grommet SAI Unit	2	2	
13	KA DF06 30	Bolt Flanged	2	2	
14	KC GA06 06	Nut Hex Flanged	2	2	




Valve

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	36 JH00 19	Kit Valve	1	--	Refer Kit Details
	36 JH00 28	Kit Valve	--	1	Refer Kit Details
2	DK 1017 51	Rocker Arm Shaft	2	2	
3	JH 5112 07	Rocker Arm Assembly	2	–	
	JH 5112 10	Assembly Rocker Arm	–	2	
4	DG 1010 29	Cotter valve	4	–	
	CB 1010 22	Cotter Valve	–	4	
5	CB 1010 09	Seal Valve Stem	2	2	
6	36 JH00 08	Kit Valve Repair	1	–	Refer Kit Details
	36 JH00 29	Kit Valve Repair	--	1	Refer Kit Details
7	DH 1012 95	Wave washer	2	–	
8	39 2440 11	Plain washer	4	–	
9	JH 5110 28	Taper Plug 1/4	2	–	




Camshaft & Tensioner

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5112 08	Camshaft Assembly	1	–	1D - 4UP Model
	DY 5112 04	Assembly Camshaft	–	1	
2	JH 5110 17	Cap Shaft	1	–	
3	39 0594 17	Internal Circlip	1	1	
4	JA 5112 16	Spacer Cam Sprocket	1	1	
5	JE 5112 37	Sprocket	1	–	
	DS 1012 76	Sprocket Camshaft	–	1	
6	DH 1010 48	Special Washer	1	1	
7	DK 1013 86	Hexagon Socket Head Cap Bolt	1	1	
	DH 1021 25	Bolt Special Camshaft	–	1	
8	JE 5112 36	Chain Cam	1	–	Refer Kit Details
	DS 1099 05	Cam Chain	–	1	
9	36 JZ01 22	Kit Guide Chain	1	--	
	36 PA01 15	Kit Guide Chain	--	1	
10	DH 1013 92	Bolt	1	1	
11	CS 1011 28	Gasket	1	1	
12	JH 5210 05	Chain Tensioner	1	1	
13	39 2669 21	O Ring	1	1	
14	DD 1010 62	Bolt	1	1	
15	39 1673 04	Bolt Silver Colour	2	–	
	KA ED06 20	Bolt Flanged Small	–	2	




Cylinder and Piston

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5210 01	Gasket Cylinder	1	--	For BS IV Model
	JH 5210 07	Gasket Cylinder Block	1	1	
2	39 1000 06	Hollow Dowel Pin	2	2	
3	JE 3514 03	Engine Temperature Sensor	1	1	
4	36 JH00 01	Kit Piston Ring	1	--	Refer Kit Details
	36 JH00 32	Kit Piston Ring	--	1	Refer Kit Details
5	36 JH00 03	Kit Cylinder Block & Piston	1	--	Refer Kit Details
	36 JH00 30	Kit Cylinder Block & Piston	--	1	Refer Kit Detail




Crankshaft

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5310 00	Crankshaft Assembly	1	–	
	JH 5310 07	Crankshaft Assembly	–	1	
2	59 1500 14	Nut Flange	2	2	
3	LD A000 25	Plain washer	2	2	
4	31 1011 73	Key woodruff	1	1	
5	DS 1011 54	Parallel key	1	1	
6	JE 5310 01	Bearing 22 x 56 x 16	2	2	
7	JE 5410 38	Damper Crankshaft	1	1	
8	36 JZ00 03	Kit Gear Primary Drive & Driven	1	--	Refer Kit Details
	36 JZ00 23	Kit Gear Primary Drive & Driven	--	1	Refer Kit Details
	36 PF00 88	Kit Primary Drive & Driven	–	1	1D - 4UP Model
9	JD 5310 04	Spacer Crankshaft	1	1	
10	JB 5310 21	Plunger	1	1	
11	JA 5310 15	Pin	1	1	
12	JA 5310 12	Spring	1	1	




Transmission

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JE 5510 01	Shaft Input	1	--	
	JZ 5510 10	Shaft Input	--	1	
2	JA 5510 04	Washer Thrust 2nd Drive	1	1	
3	JE 5512 02	Gear 4th Drive	1	--	
	JZ 5512 02	Gear 4th Drive	--	1	
4	JA 5510 02	Spline Washer	3	3	
5	JE 5512 01	Gear 3rd Drive	1	1	
6	39 0987 17	Ring Snap	3	3	
7	JE 5512 03	Gear 5th drive	1	--	
	JZ 5512 13	Gear 5th drive	--	1	
8	JE 5512 00	Gear 2nd drive	1	1	
9	JH 5510 01	Shaft Output	1	1	
10	DH 1012 35	Circlip External	1	1	
11	39 2166 11	Special Washer	1	1	
12	JH 5512 04	Gear 2nd Driven	1	1	
13	JH 5512 05	Bush Gear 2nd Driven	1	1	
14	JH 5512 06	Gear 5th Driven	1	--	
	JH 5512 10	Gear 5th Driven	--	1	
15	JH 5512 03	Washer Gear 3rd Driven	1	1	
16	JE 5512 06	Gear 3rd Driven	1	1	
17	JE 5512 16	Gear 4th Driven	1	--	
	JH 5512 11	Gear 4th Driven	--	1	
18	JE 5512 12	Bush 1st Gear Driven	1	1	
19	JE 5512 15	Gear 1st Driven	1	1	
20	JE 5512 11	Washer 1MM	1	1	
21	30 1010 61	O - Ring 13.8 x 1.9	1	1	
22	JH 5510 02	Collar Sprocket Drive	1	1	
23	JH 5512 01	Sprocket Output 14T	1	1	
24	JH 5512 02	Plate Lock - Sprocket Output	1	1	
25	DS 1013 55	Bolt - Flanged - Small	2	2	




Change Drum & Shift Fork

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	PA 5610 02	Assembly Drum Gear Shift	1	1	1D - 4UP Model
	JE 5610 06	Drum Comp Gear Shift	1	1	
2	JE 5610 05	Cam Drum Change	1	1	
3	JD 5610 11	Special Bolt Drum Change M6 x 1	1	1	
4	39 0992 06	Dowel	4	4	
5	JD 5610 06	Shaft Gear Fork Shift	2	2	
6	JD 5610 04	Fork Gear Shift Output	1	1	
7	JZ 5610 02	Fork Input Disco - H	1	1	
8	JH 5610 00	Fork Gear Shift 5th Driven	1	1	




Gear Change Mechanism

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	52 JZ02 64	Lever Complete Gear Shifter	1	1	
2	JW 5612 06	Extension Spring	1	1	
3	JW 5612 08	Spring Gear Shift Return	1	1	
	JE 5612 00	Spring Gear Shift Return	1	–	1D - 4UP Model
4	PA 5612 09	Inhibitor Complete Gear Shift	1	1	
5	LD B000 44	Plain Washer	1	1	
6	BF 5612 19	Bolt M6 x 1	1	1	
7	JD 5612 04	Spring Inhibitor	1	1	
8	JH 5614 02	Assembly Gear Shift Lever C101	1	1	
8A	JH 5612 12	Lever Assembly Gear Change	1	1	1D - 4UP Model
9	JH 5614 04	Rubber Damper GSL C101	1	1	
10	DH 1015 09	Damper	1	1	
11	KA ED06 22	Bolt - Flanged - Small	1	1	
12	JH 5614 09	Rod Tie	1	1	1D - 4UP Model
13	JH 5612 13	Arm Lever Change	1	1	1D - 4UP Model
14	JD 5614 16	Washer - Nylon	1	1	1D - 4UP Model
15	KH AA20 15	Pin Snap	2	2	1D - 4UP Model




Engine Assembly & Crankcase RH

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5010 01	Engine Assembly	1	–	N.I.For BS IV Model
	JH 5010 30	Engine Assembly	1	–	1D - 4UP Model
	JH 5010 03	Assembly Engine	–	1	
	JH 5010 31	Engine Assembly	–	1	1D - 4UP Model
2	36 JH00 22	Kit Assembly Crankcase RH	1	--	Refer Page No.98
	JH 5410 08	Assly Crankcase RH	--	1	
3	52 JA00 29	Bolt Shift Change	1	1	
4	JE 5410 28	Pin	1	1	
5	59 2000 36	Ball Bearing 6203	1	1	
6	JA 5410 10	Stopper Plate Input Bearing	1	1	
7	DH 1013 80	Screw Pan Head (M6 x 12)	1	1	
8	KP BF62 01	Ball Bearing C3 Clearances	1	1	
9	JA 5410 12	Guide Kick	1	1	
10	39 1964 04	Bolt Flanged Small	2	–	
	DH 1016 39	Lock Screw Earthing	–	1	
11	39 1740 04	Bolt Silver Colour M6 x 85L	2	2	
12	59 0400 38	Bolt Silver Colour M6 x 35L	1	1	
13	KA EF06 50	Bolt M6 x 50	2	2	
14	KA ER06 C0	Bolt Flange Small	–	2	




Crankcase LH

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	36 JH00 21	Kit Assly Crankcase LH	1	1	Refer Kit Details
2	36 JH00 25	Kit Engine Gasket	1	--	Refer Kit Details
	36 JH00 46	Kit Engine Gasket	--	1	Refer Kit Details
3	DH 1017 84	Gasket Neutral Switch	1	1	
4	31 2010 81	Switch Complete	1	1	
5	39 2189 19	Oil Seal	1	1	
6	39 2190 19	Oil Seal	1	1	
7	39 2583 20	Ball Bearing 6004 HN3 D8	1	1	
8	39 2562 20	Needle Roller Bearing	1	1	
9	JZ 5410 05	Oil Jet	1	1	
10	39 1000 06	Dowel	2	2	
11	JH 5410 15	Gasket	1	1	
12	59 0400 38	Bolt Silver Colour M6 X 35L	7	7	
13	PF 6214 02	Stopper Gear Starter	1	--	
	JH 5410 21	Bracket Gear Stopper	1	1	For BS IV Model
14	DH 1013 80	Screw Pan Head (M6 x 12)	1	1	
15	JG 5710 24	Mesh Oil Filter Assembly	1	1	
16	59 2100 23	O Ring	1	1	
17	JV 5410 06	Cap Strainer	1	1	




Cover Clutch

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	36 JH00 53	Kit Assly Clutch Cover	1	--	Refer Kit Details
	36 JH00 52	Kit Assly Clutch Cover	--	1	
2	JA 5412 12	Gasket Clutch Cover	1	1	
3	JE 5514 08	Rod Push	1	--	
	PF 5514 07	Rod Push	--	1	
4	JA 5412 25	'O' Ring Cap Oil Filler	1	1	
5	JA 5412 11	Cap Oil Filler	1	1	
6	31 1010 64	Plug	1	1	
7	30 1011 42	Oil Seal	1	1	
8	JL 5412 27	Window Oil Gauge	1	1	
9	DS 1012 15	Wire Clip	1	1	
10	DD 1211 81	Element Oil Filter	1	1	
11	39 1671 21	O Ring ID 59.6 x 2.4	1	1	
12	JH 5412 17	Oil Filter Cap With Decal	1	1	
13	39 1673 04	Bolt M6 x 1 x 20	3	--	For BS IV Model
	LA E000 05	Bolt Flanged - M6 x 1 x L20	3	3	
14	39 1041 19	Oil Seal	1	1	
15	39 2443 11	Washer	1	1	
16	JH 5412 10	Spring Torsion Clutch Lever	1	1	
17	JH 5412 12	Assembly Shaft Clutch Release	1	1	
18	39 0999 06	Pin Dowel	2	2	
19	59 0400 38	Bolt Flanged (M6 x 1 x 35L)	8	8	
20	JH 5412 09	Bracket Clutch Cable	1	1	
21	JH 5412 15	Decal	1	1	




Cover Magneto

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5412 02	Magneto Cover With Bush, Cap TDC	1	1	Without Decal
2	39 0999 06	Dowel Pin	2	2	
3	PF 5412 40	Gasket Magneto Cover	1	1	
4	59 0400 38	Flange Bolt	7	7	
5	30 1011 95	O Ring	1	1	
6	JA 5412 33	Cap TDC Finder	1	1	
7	JA 5410 05	Bush (Starter Clutch)	1	1	
8	JH 5412 07	Bracket Harness	1	1	
9	KB AB06 08	Screw - Pan	1	1	
	KB BC06 08	Screw Pan Cross	-	1	1D - 4UP Model
10	JH 5412 05	Assembly Cover LH RR With Label	1	1	
	JH 5412 41	Cover Assembly Rear LH	1	1	1D - 4UP Model
11	KA ED06 45	Flange Bolt M6 x 45L	2	2	
12	JH 5412 11	Label Gear Shift	1	1	
13	JH 5412 16	Label Magneto Cover	1	1	




Clutch Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5514 00	Assembly Clutch Complete	1	—	1D - 4UP Model
	JH 5514 11	Assembly Clutch Complete	—	1	
	JH 5514 16	Clutch Assembly	—	1	
2	JA 5514 14	Wheel Clutch	1	—	Refer Kit Details Refer Kit Details
	JB 5514 08	Wheel Clutch	—	1	
	PF 5514 28	Plate Pressure B104D	—	1	
3	JA 5514 19	Plate Clutch	4	—	Model BS IV
	30 1010 96	Plate Clutch	—	4	
	JH 5514 19	Plate Clutch	—	3	
4	36 JZ00 03	Primary Drive & Driven Gear	1	—	1D - 4UP Model
	36 JZ00 23	Primary Drive & Driven Gear	—	1	
5	JH 5514 04	Hub Clutch	1	—	1D - 4UP Model
	JH 5514 13	Hub Clutch	—	1	
	PF 5514 26	Hub Clutch B104D	—	1	
6	JH 5514 05	Spring Compression	4	—	1D - 4UP Model
	JH 5514 10	Spring Compression	4	—	
	JZ 5514 15	Spring Clutch Disco	—	6	
7	JH 5514 18	Spring Compression Clutch	—	4	1D - 4UP Model
	39 1553 04	Bolt - Flange M6	4	—	
	39 0980 04	Flange Bolt	—	6	
8	PF 5514 22	Bolt Flange Special	—	4	1D - 4UP Model
	PF 5514 06	Holder Clutch	1	—	
	JB 5514 06	Clutch Holder	—	1	
9	PF 5514 27	Clutch Lifter B104D	—	1	1D - 4UP Model
	JD 5514 00	Spacer Clutch Assembly	1	1	
10	JA 5514 06	Collar Clutch	1	1	
11	39 2600 11	Washer	1	1	
12	39 0240 11	Washer Plain	1	—	
13	JA 5514 20	Washer Plain	—	1	LH Thread
	39 2200 11	Washer Primary Drive Gear	1	—	
14	JE 5514 09	Washer Belleville	—	1	Refer Kit Details Refer Kit Details Refer Kit Details
	DH 1016 48	Nut Clutch Center Lock	1	—	
15	52 JA00 28	Nut Round	—	1	1D - 4UP Model
	14 1510 33	Bearing 10 x 30 x 9 Clutch Lifter	1	—	
16	39 1001 20	Bearing Ball	—	1	Refer Kit Details Refer Kit Details Refer Kit Details
	36 JH00 04	Kit Friction Plate	1	—	
	36 JH00 33	Kit Friction Plate-BSIV	1	—	
17	36 JE00 24	Kit Friction Plate	—	1	1D - 4UP Model
	36 JH00 57	Friction Plate	—	1	
	JH 5514 01	Assembly Clutch Plate	1	—	
	JH 5514 12	Assembly Clutch Plate	—	1	




Oil Pump Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JZ 5710 00	Assembly Oil Pump	1	1	
2	FD 1010 78	Screw Pan Cross	3	3	
3	JA 5410 16	Gasket Case Oil Pump	1	1	
4	39 0999 06	Pin Dowel	2	2	
5	JZ 5710 01	Gear Oil Pump Driven	1	1	




Front Wheel Direction

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5812 00	Assembly Carburator	1	—	Model BS IV
	JH 5812 06	Assembly Carburetor EVAP	1	—	
2	36 JH00 12	Kit Carb “O” Rings & Gasket	1	--	
3	36 JH00 13	Kit Carb Jets	1	--	Model BS IV
4	36 JH00 14	Kit Carb Throttle Valve	1	--	Model BS IV
5	36 JH00 15	Kit Carb Float Chamber Body	1	--	
6	36 JF00 24	Kit Carb Idling Screw	1	--	
7	36 JH00 17	Kit Carb Top Cap	1	--	
8	36 JH00 18	Kit Carb Plunger Assly	1	--	
9	36 JF00 22	Kit Carb Vacuum Adjuster	1	--	
10	DH 1210 59	Float Assly.	1	--	
11	DH 1210 63	Float Pin	1	--	
12	DP 1210 59	“O” Ring	1	--	
13	DH 1211 76	Screw	2	--	
14	JE 5812 23	Hose Drain	1	--	
15	JE 5812 18	Drain Screw	1	--	
16	DH 1210 93	Needle Assembly	1	--	
17	DH 1210 64	Screw Needle Shaft	1	--	
18	JH 5812 01	Sleeve Carburetor C101	1	--	
19	JH 5812 02	Clamp	2	--	
20	JH 1812 31	Cover Carburetor LH	1	--	
21	JH 1812 80	Cover Carburetor RH	1	--	
22	LB U000 46	Screw Truss	4	—	




Carburettor Assembly - V12

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5812 07	Assembly Carburetor	—	1	Includes all O-Rings & Gasket
2	JB 5812 30	Float Assly.	—	1	
3	JB 5812 29	Float Valve	—	1	
4	JB 5812 56	Pin Float Arm	—	1	
5	P No. Req'd	Float Chamber "O" Ring	—	1	
6	PA 5812 21	Screw Float Chamber	—	1	
7	P No. Req'd	Hose Drain	—	1	
8	JB 5812 60	Drain Screw	—	1	
9	36 JH00 12	Kit Carb "O" Rings & Gasket	—	1	
10	36 JH00 39	Kit Carb Jets	—	1	
11	36 JH00 43	Kit Carb Throttle Valve	—	1	
12	36 JH00 44	Kit Carb Float Chamber Body	—	1	
13	36 JH00 45	Kit Carb Idling Screw	—	1	
14	36 JH00 42	Kit Carb Top Comp	—	1	
15	JL 1812 88	Screw Stepped	—	2	
16	36 JH00 40	Kit Carb Air Screw	—	1	
17	JH 5812 01	Sleeve Carburetor C101	—	1	
18	JH 5812 02	Clamp	—	1	
19	JH 1812 65	Assembly Carburetor Cover LH	—	1	
20	JH 1812 80	Cover Carburetor RH	—	1	
21	LB U000 46	Screw Truss	—	2	
22	LJ A000 11	O Ring	—	1	
23	PA 5812 05	Insulator	—	1	
24	JA 5814 06	Bolt Flange	—	2	
25	LB U000 33	Screw Truss	—	2	




Kick Starter Mechanism

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	PA 6210 07	Kick Shaft	1	1	1D - 4UP Model
2	JA 6210 06	Washer Thrust	1	1	
3	39 0738 17	Circlip	2	1	
4	DS 1011 17	Spring Kick Starter Ratchet	1	1	
5	JA 6210 02	Ratchet	1	1	
6	39 0993 11	Washer Plain	3	3	
	JA 6210 06	Washer Thrust (16.2 x 25 x 0.5)	–	1	
7	PA 6210 08	Gear Kick Pinion	1	1	
8	39 2408 17	External Circlip	1	1	
9	JE 6210 03	Spring Kick Return	1	1	
10	PA 6212 03	Assembly Kick Lever	1	1	Refer Kit Details
11	36 JH00 09	Kit Boss Kick Lever	1	1	
12	DD 1010 97	Damper	1	1	
13	JA 6212 06	Bolt Flange	1	1	
14	22 1502 41	Plain Washer	1	1	
15	JE 6210 04	Sleeve	1	1	



Silencer Assembly


No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	YJ H010 10	Silencer without Shields	1	–	
	YJ H050 03	Silencer without Shields	--	1	
2	JH 5910 34	Shield Muffler	1	1	
3	JW 5910 30	Grommet Shield	1	–	
	JB 5910 59	Damper Shield Muffler Disco - M	–	1	
4	JB 5910 68	Washer Nylon Shield Silencer	2	2	
5	JW 5910 28	Truss Screw M5 x 0.8	2	2	
6	39 2492 11	Plain Washer	1	1	
7	DK 1016 10	Bolt (M5)	1	1	
8	DJ 1010 64	Gasket Exhaust	1	1	
9	39 2295 15	Nut Flanged - Ex. Tube Cyl Head	2	2	
10	DD 1610 71	'U' Nut M10 x 1.25	1	1	
11	39 2425 11	Plain Washer	2	2	
12	KA DD10 55	Bolt	1	1	
13	JH 5911 11	Wire Shield	1	1	
14	JL 5911 49	Truss Screw (Head Black)	2	2	




Air Cleaner Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 5810 00	Air Filter Assly.	1	–	
	JH 5810 18	Assembly Air Filter	–	1	
2	JH 5810 07	Tube Breather	1	–	
	JH 5810 30	Tube Breather	–	1	
3	PA 5810 53	Top Cover Mounting Screw M6 x 18	6	6	
4	DS 1211 26	Plug	1	1	
5	JH 5810 11	Arrester Flame	1	1	
6	DP 1210 25	Clamp	2	2	
7	JH 5810 15	Tube Drain	1	1	
8	JH 5810 12	Assembly Cover Air Filter	1	1	
9	PF 5810 49	Ring Seal Air Filter	2	2	
10	JH 5826 02	Foam Element SAI	1	1	
11	JH 5810 08	Case Air Filter & Connecting Tube	1	–	
	JH 5810 29	Assembly Case Air Filter	–	1	
12	JH 5826 01	Plate Supporting SAI	1	1	
13	DG 1210 40	Clamp	1	1	
14	JH 5810 03	Air Filter Element	1	1	
15	JG 5814 42	Clamp Intake Pipe	1	–	
	DH 1021 18	Clamp Insulator IM	–	1	
16	KB RA42 32	Screw Tapping Pan Cross	1	1	
17	KB RA35 10	Screw Tapping Pan Cross	2	2	
18	DJ 1013 05	Bolt Flange	–	1	
19	DP 1610 94	Bolt Stepped - M6	2	2	
20	KA DD06 14	Bolt Flanged	1	1	

EVAP Mechanism




No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JY 1710 77	Canister	1	1	
2	DJ 1410 70	Tube Canister To Connector	1	–	
	JH 1710 20	Tube Connector To Canister	–	1	
3	PD 1716 16	Valve Purge	1	1	
4	JY 1710 69	Spring Band Clamp 15 x 10	1	1	
5	JY 1710 90	Spring Band Clamp 13 x 12	6	1	
6	JH 1710 21	Tube Connector to Purge Valve	1	1	
7	JG 1710 86	Connector Tube EVAP	2	1	
8	JH 1710 22	Tube Purge Valve To Carburetor	1	–	
	JH 1710 72	Tube Purge Port To Carburetor	–	1	
9	JY 1710 70	Spring Band Clamp 9 x 8.4	6	6	
10	JY 1138 42	Connector Y Shape	1	1	
11	JH 1710 20	Tube Y Connector To Canister	1	1	
12	JH 1716 01	Tube Canister Drain	1	1	
13	JY 1718 25	Plug Fuel Drain	1	1	
14	JH 1710 23	Tube Inline connector To Y Connector	1	1	
15	JH 1710 24	Tube Canister Breather	1	1	
16	JH 1710 48	Grommet Purge Valve	1	1	
17	JH 1710 19	Tube Drain	1	1	
18	JG 1710 29	Spring Band Clip 10 MM	2	1	
19	JH 1710 18	Tube Tank To Inline Connector	1	1	
20	JH 1716 02	Clamp Canister Breather	1	1	




Magneto, CDI, Spark Plug & H.T. Coil

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	PA 3510 25	Assly Rotor With One Way Clutch	1	1	
2	JH 3510 05	Assembly Stator	1	–	
	JH 3510 07	Assembly Stator	–	1	
3	LA C000 52	Bolt Socket - M6x1xL 28 (TL 24)	2	2	
4	JH 3512 00	CDI Assembly	1	–	
	JH 3512 07	CDI Assembly	–	1	
5	DH 1110 15	Cap Spark Plug	1	1	
6	JH 3512 03	H. T. Coil 1 With Cable	1	1	
7	DD 1110 12	Grommet H.T. Cable	2	2	
8	DH 1110 13	Grommet Spark Plug	2	2	
9	JH 3512 05	H.T. Coil 2 With Cable	1	1	
10	JD 3512 06	Grommet Sleeve Spark Plug Cap	2	1	
11	JZ 4020 00	DC Regulator With Capacitor	1	1	
12	KA ED06 14	Bolt Flanged Small	2	1	
12A	KA ED06 20	Bolt Flanged Small	–	1	
13	DD 1110 18	Spark Plug	2	2	
	CF 1110 19	Spark Plug Bosch UR4AC	2	2	
14	59 0400 14	Bolt Flanged M6 x 1	–	4	




Starter Motor & Starter Gear

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 3516 00	Assembly Starter Motor	1	--	With 3 resting pad
	JH 3516 01	Assembly Starter Motor	1	1	
2	39 1674 04	Bolt M6 X 25 Silver Colour	2	2	1D - 4UP Model
3	PF 6214 00	Starter Drive Assembly	1	1	
4	JH 6214 01	Assembly Starter Gear With Bearing	1	1	
	JH 6214 03	Gear Starter Clutch Assembly	--	1	
5	JE 6214 03	Needle Roller Bearing (20 x 26 x 16)	1	1	
6	GL 6214 14	One Way Clutch	1	1	




Frame & Frame Fittings

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1110 00	Frame Assly Without Bearing Race	1	1	Refer Kit Details
2	JH 1510 18	Cap Steering Stem	1	1	
3	KA DF06 10	Bolt	2	2	
4	36 PA01 44	Steering Cone Kit	1	1	
5	JZ 1510 84	Nut	1	1	
6	DJ 1811 15	Cage with Ball Steel	2	2	
7	JH 1710 14	Cover Fuel Tank Front	1	1	
8	DS 1810 15	Nut Cap Fork	1	1	
9	DS 1810 16	Washer	1	1	
10	JH 1138 10	Tape Frame	3	3	
11	JH 1710 16	Damper Tank Mounting Front	2	2	
12	JH 1138 05	Strap For Harness	1	1	
13	JZ 1112 92	Tape Frame Head Pipe	3	3	
14	JH 1138 13	Cap For Pipe Rear	2	2	
15	JH 1110 18	Hook Clutch Cable	-	1	
16	KA DD06 12	Bolt Flanged	-	1	





Engine Mountings

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1134 01	Bracket Engine Mounting Front RH	1	1	Model BS IV
2	JH 1134 00	Bracket Engine Mounting Front LH	1	1	
3	39 1970 15	Nut	5	5	
4	KA DD08 65	Bolt Flanged	4	4	
5	KA DD08 A0	Bolt	2	2	
6	JH 1134 02	Bracket Engine Mounting Top	1	–	
6A	JH 1134 15	Assly. Bracket Engine Mounting Top	1	–	
6B	JH 1134 16	Assembly Engine Mounting Top	–	1	
7	JH 1134 10	Bkt. Engine Mounting Top With Hook	1	–	
8	KA DF08 50	Bolt Flanged	3	3	
9	JH 1134 03	Bracket Engine Mounting Rear	1	1	
10	KA DD10 B5	Bolt Flanged	2	2	
11	39 1225 15	Nut	2	2	




Swing Arm & Rear Shock Absorber

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1220 11	Swing Arm Assly	1	1	
2	JH 1220 13	Bearing Needle	2	2	
3	JH 1220 09	Dust Seal	4	4	
4	DJ 1510 36	Chain Adjuster LH	1	1	
5	DJ 1510 37	Chain Adjuster RH	1	1	
6	DJ 1510 47	Plate Chain Adjuster	2	2	
7	39 0292 15	Hex Nut	4	4	
8	JH 1220 14	Chain Slider	1	1	
9	39 0454 11	Plain Washer	2	2	
10	39 0553 02	Self Tapping Screw	2	2	
11	JH 1220 04	Shaft Swing Arm	1	1	
12	39 1053 15	Nut	1	1	
13	JH 1138 00	Cap Swing Arm Shaft	2	2	
14	JH 1220 03	Rear Shock Absorber	2	—	
	JH 1220 15	Shockabsorber Rear	—	2	
15	39 2366 15	Nut	2	2	
16	39 2726 12	Washer Spring	2	2	
17	JB 1220 10	Plain Washer	4	4	
18	39 0714 11	Washer Plain	2	2	
19	JB 1220 16	Flange Bolt	2	2	
20	JH 1220 12	Sleeve	2	2	





Main Step and Pillion Step Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	52 JH00 18	Assembly Stay Main Step LH	1	1	
2	JH 1130 06	Rubber Main Step	2	2	
3	52 JH00 19	Assembly Stay Main Step RH	1	1	
4	LA D001 26	Bolt Flanged	2	2	
5	JH 1132 03	Damper Kick Stopper	1	1	
6	KA DD08 20	Bolt Flanged	2	2	
7	KD CB08 16	Washer Spring	2	2	
8	JH 1130 04	Pillion Step Holder LH	1	—	
	JH 1130 19	Holder Pillion Step LH	—	1	
9	JH 1130 09	Assembly Pillion Step LH	1	—	
	JH 1130 22	Assembly Pillion Step LH	—	1	
10	DH 1611 00	Washer Nylon	2	2	
11	DH 1610 61	Pin Pillion Step	2	—	
	DD 1613 81	Pin Pillion Step	—	2	
12	30 1410 31	O-Ring	2	2	
13	KD BA08 18	Washer	2	2	
14	KH AA25 20	Pin Cotter	2	2	
15	LA C000 23	Bolt Socket Head	4	—	
	LA C001 21	Bolt Socket - M8x1.25xL35xPrecoat	—	4	
16	JH 1130 05	Pillion Step Holder RH	1	—	
	JH 1130 20	Holder Pillion Step RH	—	1	
17	JH 1130 11	Assembly Pillion Step RH	1	—	
	JH 1130 23	Assembly Pillion Step RH	—	1	
18	DJ 1612 78	Tube Silencer With Washer	1	1	
19	JZ 1130 42	Damper	1	1	
20	JH 1130 10	Damper Pillion Step	2	—	
	JH 1130 21	Rubber Pillion Step	—	2	
21	PA 1130 61	Damper	2	2	
22	JH 1130 12	Washer Nyloc	2	2	




Mudguard - Front & Rear

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1814 08	Brace Fender	1	1	
2	39 1075 04	Bolt Flanged	4	4	
3	DS 1611 25	Cable Guide	1	1	
4	DJ 1610 69	Nail Cable Guide	1	1	
5	JH 1814 03	Fender Rear	1	1	
6	JH 1814 05	Cap Tool Kit	1	1	
7	JH 1814 04	Reinforcement Bracket	1	1	
8	JH 1814 11	Reinforcement Blinker Bracket	1	1	
9	DJ 1013 05	Bolt	2	2	
10	LA E000 22	Flanged Bolt	6	6	
11	DD 2010 02	Reflex Reflector	1	1	
12	LC A000 08	Nut	1	1	
13	PA 1112 50	Collar Special	–	4	
14	LB U000 43	Screw Truss	–	4	
15	DJ 2011 73	Grommet For Cables Rear Fender	--	2	




Center & Side Stand Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1132 01	Center Stand	1	1	
2	30 1611 57	Shaft Center Stand	1	1	
3	KH AA32 35	Pin Cotter	1	1	
4	JZ 1132 09	Spring Center Stand With Cover	1	1	
5	JZ 1132 12	Spring Cover Center Stand	1	1	
6	PA 1132 04	Damper	1	1	
7	JH 1132 00	Side Stand	1	–	
	JH 1132 05	Stand Side	–	1	
8	DH 1612 40	Spring Side Stand With Cover	1	1	
9	DH 1611 46	Spring Cover	1	1	
10	DF 1611 02	Bolt	1	1	
11	39 0422 15	Nut	1	1	




Wheel Rim & Tyres

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1310 01	Wheel Rim Front Disc 1.85 x 18	1	–	
1A	JH 1310 31	Wheel Front Drum 1.4 x 18	–	1	
1B	JH 1310 25	Wheel Front Disc 1.4x18	–	1	
2	DK 1510 26	Valve Tubeless Tyre	2	–	
3	JH 1310 06	Tyre Front 90 / 90 - 18 Tubeless	1	–	Not Supplied in Spare
	JH 1310 23	Tyre Front 2.75 x 18	–	1	
4	JH 1312 01	Wheel Rim Rear	1	–	
4A	JH 1312 18	Wheel Rear 2.15 x 16	–	1	
5	JH 1312 02	Tyre Rear 120 / 80 -16 Tubeless	1	–	Not Supplied in Spare
	JH 1312 22	Tyre Rear 100 / 90 - 16	–	1	
6	JH 1310 30	Tube Front 2.75 x 18	–	1	N. I.
7	JH 1312 23	Tube Rear 100 / 90 - 16	–	1	N. I.




Front Wheel Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JD 1318 10	Disc Front 240mm	1	--	Model BS IV
1A	JD 1318 10	Brake Disc	1	--	
	JH 1318 87	Disc Brake 200 DIA	--	1	
2	JH 1310 11	Axle, Front	1	1	
3	JH 1316 00	Case Meter Housing without Cable	1	1	
4	59 1500 03	Nut	1	1	
5	DE 1510 06	Spacer Assembly	1	1	
6	KP BB63 01	Ball Bearing	2	2	
7	30 1510 33	Seal oil	1	1	
8	DS 1510 58	Spacer Front Axle	1	1	
9	39 0781 11	Washer	1	1	
10	DK 1510 26	Valve Tubeless Tyre	2	--	
11	JD 1318 11	Bolt	5	5	
12	JH 1812 99	Cover Disc	1	--	
	JH 1813 05	Cover Disc	--	1	
13	KA DD06 18	Bolt	1	1	
14	KA DD06 14	Bolt	1	1	
15	JH 1813 00	Bracket Cover Disc	1	--	
	JH 1813 06	Bracket Cover Disc Mounting	--	1	
16	JN 1812 11	Clip Nut	1	1	
17	JH 1210 79	Hook - Brake Hose Routing	1	1	




Front Hub - V12 Drum

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1310 11	Axle Front	-	1	
2	JH 1318 20	Assembly Brake Panel Fr 130 Dr	-	1	
3	DS 1510 89	Cam Brake Assembly Front	-	1	
4	30 1510 38	O Ring	-	1	
5	DS 1510 91	Wear Indicator	-	1	
6	JH 1318 80	Lever Brake Front	-	1	
7	KA EF06 30	Bolt Flange	-	1	
8	DS 1510 94	Flanged Nut	-	1	
9	30 1511 05	Shoe Brake	-	2	
10	30 1510 69	Spring	-	2	
11	39 0242 11	Washer A	-	2	
12	36 3015 09	Kit Gear Speddo Meter	-	1	
13	39 1013 21	O Ring	-	1	
14	JA 1316 06	Bushing	-	1	
15	30 1511 18	Stopper For Bushing	-	1	
16	KD DB04 08	Washer Spring Thin	-	1	
17	KB BM04 08	Screw Pan Cross	-	1	
18	KP BB63 01	Bearing Ball C3 Clearance	-	2	
19	30 1510 32	Collar Bearing	-	1	
20	30 1510 33	Seal - Oil	-	1	
21	59 1500 03	Nut	-	1	
22	JB 1310 22	Spacer Assembly	-	1	




Rear Wheel Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JC 1510 16	Coupling	1	1	Refer Kit Details
2	JH 1318 02	Assly Panel Brake Rear	1	1	
3	30 1511 05	Shoe Brake Rear	2	2	
4	JC 1510 04	Cam Brake	1	1	
5	JH 1318 03	Lever Brake Cam	1	1	
6	DT 1312 07	Axle Rear	1	1	
7	JC 1510 06	Indicator Brake Shoe	1	1	
8	DK 1510 94	Coupling Rubber	1	1	
9	DS 1510 73	Stud	4	4	
10	36 JH00 06	Chain Sprocket Kit	1	1	
11	LC B000 05	Nut	4	4	
12	DK 1510 12	Seal Oil	1	1	
13	KP BB63 02	Bearing Ball	1	1	
14	JD 1410 03	Chain Link Lock	1	1	
15	39 0801 15	Nut	1	1	
16	30 1510 69	Spring Brake Shoe	2	2	
17	DH 1710 19	Nut	1	1	
18	30 1510 75	Collar Rear Brake Drum	1	1	
19	DJ 1510 34	Collar Rear Axle	1	1	
20	39 2566 11	Washer	1	1	
21	KA EF06 30	Bolt	1	1	




Rear Wheel Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
22	KP AC60 05	Bearing Ball	1	1	
23	01 1701 22	'O' RING	1	1	
24	DS 1510 94	Flanged Nut	1	1	
25	JC 1510 12	Special Washer Panel RR	1	1	
26	KP BB62 02	Bearing Ball	1	1	
27	JH 1312 03	Sleeve	1	1	
28	PF 1312 20	Washer Lock for Nut	2	2	
29	39 2567 11	Washer	1	1	
30	JH 1312 08	Collar	1	—	
	JH 1312 04	Collar	—	1	




Rear Brake Pedal

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	52 JH00 22	Rear Brake Pedal	1	1	
2	JH 1610 02	Pad Brake Pedal	1	1	
3	DD 1610 78	Damper	1	1	
4	39 1680 04	Bolt Flange	1	1	
5	DG 1910 45	Washer Plain	1	1	
6	JD 1610 02	Spring Brake Pedal	1	1	
7	JD 1610 06	Sleeve Spring Brake Pedal	1	1	
8	JH 1610 04	Brake Rod	1	1	
9	JZ 1318 75	Pin Brake Rod	1	1	
10	KH AA20 15	Pin Snap	1	1	
11	30 1910 35	Spring	1	1	
12	15 1910 26	Pin	1	1	
13	30 1910 36	Brake Adjusting Nut	1	1	
14	39 0198 11	Washer Plain	1	1	
15	JD 1220 04	Torque Rod	1	1	
16	JA 1210 05	Step Bolt	1	1	
17	39 1540 11	Washer Plain	1	1	
18	39 0789 12	Washer Spring	1	1	
19	39 0694 15	Hex Lock Nut	1	1	
20	39 0807 08	Pin Snap	1	1	
21	KD DB10 18	Washer Plain	1	1	
22	30 1510 95	Hex Bolt	1	1	
23	KC AA10 08	Nut Master	1	1	
24	KH BA08 28	Pin Snap	1	1	




Front Master Cylinder Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	DJ 1910 57	Lever Front Brake	1	1	Drum Brake
	DD 1911 42	Lever Grip Right	–	1	
2	DJ 1910 29	Bolt Front Brake Lever	1	1	
3	DJ 1910 30	Nut	1	1	
4	36 DH19 02	Oil Window Kit	1	1	
5	DJ 1910 31	Screw	2	2	
6	DE 1910 29	Cover - Reservoir	1	1	
7	DE 1910 28	Diaphragm	1	1	
8	DJ 1910 56	Master Cylinder with lever	1	1	
9	DJ 2011 09	Brake Switch	1	1	
10	DE 1910 10	Washer - Copper	4	–	
	DJ 1910 26	Washer - Copper	–	1	
11	36 PD00 36	Kit Bolt - Banjo With Washer	2	–	
	DJ 1910 25	Banjo Bolt	–	2	
12	JH 1318 01	Hose Assembly	1	–	
	JH 1318 33	Hose Assembly	–	1	
13	LA D000 37	Bolt Flanged M8 x 1 x 50	2	2	
14	DJ 1910 23	Major Kit M-11	1	1	
15	DE 1910 33	Clamp - Holder : RH	1	1	
16	JH 1210 79	Hook -brake Hose Routing	1	1	
17	KA DD06 18	Bolt	1	1	



Front Brake - Caliper & Disc


No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JD 1318 10	Disc, Front	1	-	
	JH 1318 87	Disc Brake 200 Dia	-	1	
2	DG 1510 89	Caliper Assly. Front	1	-	
	JH 1318 35	Assembly Calliper	-	1	
3	JD 1318 11	Bolt, Disc Plate	5	5	
4	DG 1510 88	Bolt Flanged	2	-	
5	36 PD00 43	Kit Caliper Assembly Pad Spring	1	-	
6	DE 1510 46	Bleeder Screw	1	-	
7	DE 1510 47	Bleeder Cap	1	-	
8	JW 1318 07	Disc Pad Set	1	1	
9	DE 1510 43	Insulator	1	-	
10	DE 1510 45	Dust cover	1	-	
11	36 DK00 65	Minor Kit - Caliper	1	-	
	36 DJ40 32	Minor Kit - Caliper	-	1	
12	36 DK00 66	Major Kit - Caliper	1	-	
	36 DJ40 33	Major Kit - Caliper	-	1	
13	36 PD00 44	Kit Caliper Assembly Pad Pin	1	-	
14	36 PD00 45	Kit Caliper Bracket	1	-	




Handle Bar Assembly

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1510 06	Holder Fork Upper	1	1	
2	JH 1510 07	Holder Handle Lower	1	—	
	JH 1510 21	Handle Holder Lower	—	2	
3	DS 1810 07	Washer Handle Upper	2	2	
4	JZ 1510 78	Damper Handle Upper	2	2	
5	JZ 1510 79	Damper Handle Lower	2	2	
6	DS 1810 10	Washer Handle Lower	2	2	
7	39 0422 15	Nut Nylock	2	2	
8	LA E000 21	Bolt Flanged	2	2	
9	JH 1510 09	Holder Handle Upper	1	1	
10	39 2582 04	Flanged Bolt	4	4	
11	JH 2326 02	Lock Set	1	—	
	52 JH04 33	Lock Set With Cap BSIV	1	—	
	JH 2326 12	Set Lock	1	—	1D - 4UP Model
	JH 2326 16	Set Lock	—	1	1D - 4UP Model
	JH 2326 06	Lock Set with Fuel Tank Cap	—	1	
	52 JH04 31	Lock Set with Fuel Tank Cap	1	—	
11A	JH 2326 16	Set Lock	—	1	
12	JH 1510 01	Handle Bar	1	1	
13	PF 1610 09	Lever & Holder Assly	1	1	
14	PF 1610 15	Lever Clutch	1	1	
15	JZ 4014 03	Clutch Switch	1	1	
16	DS 1910 52	Boot Clutch Lever	1	1	
17	JH 1510 02	Grip Handle LH	1	1	
18	JH 1510 03	Assembly Grip RH	1	1	
19	PA 1510 23	Pipe Throttle	1	1	
20	JH 1510 11	Handle Bar Weight	2	—	
	JH 1510 41	Weight Handle Bar End	2	—	Model BS IV
	DH 1810 22	Handle Bar Weight	—	2	
21	KA CF06 55	Bolt Socket	2	2	
22	JH 4014 00	Switch Control LH	1	1	
23	JH 4014 01	Switch Control RH	1	1	
23A	JH 4014 02	Switch Control RH	1	1	AHO Model
24	JH 2316 00	Mirror Assembly LH	1	1	
25	JH 2316 01	Mirror Assembly RH	1	1	
26	PF 1610 11	Assembly Lever Holder RH	—	1	
27	59 0400 06	S. S. Hex Head Bolt (With Washer)	—	2	

Front Fork




No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1210 09	Fork Assembly Front	1	—	For Disc Type
	JH 1210 50	Fork Assembly Drum	—	1	
	JH 1210 38	Assembly Front Fork Disc	—	1	
2	JH 1210 12	Tube Outer LH	1	—	For Disc Type
	JH 1210 53	Tube Outer LH	—	1	
	JH 1210 39	Tube Outer LH	—	1	
3	JH 1210 13	Tube Outer RH	1	—	For Disc Type
	JH 1210 54	Tube Outer RH	—	1	
	JH 1210 40	Tube Outer RH	—	1	
4	KA CF08 30	Socket Head Bolt	2	2	
5	30 1810 26	Copper Washer	2	2	
6	DG 1810 23	Toughened Oil Seal	2	—	
	DU 1811 08	Oil Seal	—	2	
7	DG 1810 22	Ring Snap	2	—	
	31 1811 08	Ring Snap - Oil Seal Stopper	—	2	
8	DG 1810 21	Inner Dust Seal	2	—	
	DD 1810 32	Inner Dust Seal	—	2	
9	DG 1810 13	Bushing Pipe Outer	2	—	
	JK 1210 07	Guide Bush	—	2	
	JK 1210 09	Washer Guide Bush	—	2	
10	DG 1810 24	Washer	2	—	
	JK 1210 09	Washer Guide Bush	—	2	
11	DG 1810 15	Washer	2	—	
	DM 1810 10	Washer	—	2	
12	JH 1210 33	Spacer Tube	2	—	
	JK 1210 08	Spacer Tube	—	2	
13	JH 1210 05	Fork Pipe Inner	2	—	
	JH 1210 41	Fork Pipe Spinning	—	2	
14	36 JH00 11	Cylinder Complete Fork	2	—	Refer Kit Details
	36 JH00 31	Cylinder Complete Fork	—	2	Refer Kit Details




Front Fork

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
15	JH 1210 32	Main Spring	2	—	
	JH 1210 56	Spring Main	—	2	
16	JH 1210 16	Fork Bolt	2	—	
	DS 1810 12	Bolt Fork	—	2	
17	DG 1810 26	'O' Ring	2	—	
	30 1810 29	'O' Ring	—	2	
18	36 PA01 44	Kit Steering Cone	1	—	Refer Kit Details
19	JH 1210 06	Under Bracket Assembly	1	—	
20	JH 1210 43	Assembly Under Bracket Complete	—	1	
	39 0789 12	Spring Washer	2	2	
21	39 1181 01	Bolt	2	2	
22	JH 1210 11	Leg Assembly RH	1	—	
	JH 1210 52	Fork Leg Assembly RH	—	1	For Disc Type
	JH 1210 48	Leg Assembly RH	—	1	
	JH 1210 10	Leg Assembly LH	1	—	For Disc Type
23	JH 1210 51	Fork Leg Assembly LH	—	1	
	JH 1210 47	Leg Assembly LH	—	1	
24	JH 1210 14	Cover Dust Fork LH	1	—	
25	JH 1210 19	Cover Dust Fork RH	1	—	
26	JH 1210 42	Bellow	—	2	
27	PF 1210 54	Clamp For Bellow	—	2	




Fuel Tank

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JD 1110 52	Grommet Tank Mtg	1	1	
2	DS 1410 12	Grommet Side Cover FR	2	2	
3	JH 1710 08	Seat Tape	1	1	
4	JH 4026 00	Gauge Fuel Tank	1	1	
5	JH 1710 17	O Ring Fuel Gauge	1	1	
6	39 2484 15	Nut	4	—	
	KC GA05 05	Nut Hex Flanged	—	4	
7	JH 1710 33	Cap Fuel Tank	1	—	
	JH 2326 02	Lock Set	1	—	
	52 JH04 33	Lock Set With Cap BSIV	1	—	
	JH 2326 06	Lock Set with Fuel Tank Cap	—	1	
	52 JH04 31	Lock Set with Fuel Tank Cap	1	—	
8	AP 1012 55	Screw Pan M5 x 10 (Pre-Coated)	2	2	
9	39 2179 24	Washer	2	2	
10	39 0740 11	Washer (Non Metalic)	2	2	
11	JD 1718 01	Socket Head Bolt	2	2	
12	JH 1718 00	Assembly Fuel Cock	1	1	
13	DK 1410 41	Pipe Clip	1	1	
14	JH 1718 01	Tube Fuel	1	1	
15	JH 1710 45	Beading Tank	2	2	
16	39 19 5604	Bolt Flanged Small	1	1	
17	39 2424 11	Plain Washer	1	1	
18	DZ 1410 75	4 Hole Washer	1	1	N.I.




Seat Assembly & Seat Lock

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1910 00	Seat Assembly	1	1	1D - 4UP Model
1A	JH 1910 14	Seat Assembly	1	1	
2	PA 1910 10	Damper Seat Front	2	2	
3	JZ 1910 11	Damper Seat Rear	3	3	
4	JZ 1910 10	Damper Seat	6	6	
5	JH 1612 03	Seat Lock Assembly Complete	1	1	
6	JH 1612 04	Cable Seat Lock	1	1	
7	DH 1612 33	Reinforcement Seat Lock	1	1	
8	KA DD06 22	Bolt Flanged	2	2	
9	LB U000 38	Screw Button HD	2	2	
10	JH 1812 55	Washer Retaining	2	2	
11	JH 1812 43	Pad Pillion Seat Cover	1	1	
12	JH 1910 03	Reinforcement Pillion Seat Cover	1	1	
13	LB U000 38	Screw Cr Pan Head Tap	2	2	
14	LD A000 07	Washer Plain Small	2	2	




Speedometer

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 4024 00	Speedometer	1	–	
	JH 4024 04	Speedometer	–	1	
2	JH 1812 53	Beading Rubber	4	4	
3	JH 1812 07	Fairing Mounting Structure	1	1	
4	39 0258 11	Washer	3	3	
5	KC GA05 05	Nut Flanged	3	3	
6	JZ 1813 65	Grommet	3	3	
7	JL 5911 48	Bolt Hex Flanged	2	2	
8	YJ H010 05	Speedo. Top Cover with Sealing Ring	1	1	
9	YJ H010 04	Housing With Wrig Harn. & Indication	1	–	
9A	YJ H050 04	Housing with Panel	–	1	
10	YJ H010 06	Speedometer With Dial	1	1	
11	YJ H010 03	Back Cover	1	1	
12	CM 2010 54	Bulb T10 12V1.7 W	7	7	
13	JH 1812 59	Plug Fairing Structure	2	2	
14	YJ H050 05	Wiring Harness	–	1	
15	YJ H050 06	Fuel Gauge	–	1	




Cables

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JZ 1612 10	Cable Speedometer	1	–	
	PA 1612 17	Cable Speedometer	–	1	
2	JZ 1612 24	Cable Clutch	1	1	
3	JH 1612 00	Cable Accelerator	1	–	
	JH 1612 09	Cable Accelerator	–	1	
4	JH 1612 02	Cable Choke	1	–	
	JH 1612 10	Cable Choke	–	1	




Side Covers & Seat Cowl Fittings

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JZ 1813 22	Grommet Side Cover	2	2	
2	JL 1812 19	Grommet Seat Cowl	2	2	
3	DJ 1612 29	Clip Nut M5	4	4	
4	JH 1812 34	Grommet Tail Lamp Mounting	4	4	
5	JH 1812 28	Bracket Seat Cowl Mounting Rear	1	1	
6	KC GC05 05	Nut Hex Flanged	4	4	
7	LD A000 18	Washer	2	2	
8	KA DF06 12	Bolt Flanged M6	2	2	
9	DG 1611 21	Screw	2	2	
10	KA DF06 14	Bolt Flanged M6	2	2	
11	DS 1410 12	Grommet Side Cover FR	2	2	
12	DU 1611 02	Damper	1	1	
13	JH 2326 02	Lock Set	1	--	
	JH 2326 06	Lock Set with Fuel Tank Cap	1	1	
14	DS 1610 35	Clip Nut	1	1	
15	39 1789 24	Washer Nylon	1	1	
16	DG 1611 21	Screw	1	1	
17	LB R000 03	Screw	8	8	
18	LA D000 07	Washer	8	—	
19	LD A000 07	Washer Plain Small	—	8	




Leg Guards, Saree Guard & Grab Handle

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 2312 10	Assembly Leg Guard LH	1	1	
2	JH 2312 11	Assembly Leg Guard RH	1	1	
3	JH 2312 04	Cap Leg Guard	4	4	
4	KA DD08 12	Bolt Flanged	4	4	
5	JH 2312 02	Saree Guard	1	1	
6	KA DD08 50	Bolt Flanged	1	1	
7	KA CF10 50	Bolt Socket	1	1	
8	39 0296 15	Hex Nut M10	1	--	
9	JH 2314 09	Primary Grab Handle Black	1	--	
	56 JH70 6S	Primary Grab Handle Red	1	--	
	56 JH70 1W	Primary Grab Handle White	1	--	
	56 JH70 43	Primary Grab Handle Orange	--	1	
	56 JH70 6E	Primary Grab Handle Silver	--	1	
9A	56 JH5W 36	Grab With Backrest Mat Slik Blk	2	2	1D - 4UP Model
10	KA CA08 20	Bolt Master KAC	4	4	
11	JH 2314 09	Kit Grab Handle Secondary + Bolts	1	1	
12	LA C000 24	Bolt Socket Head M6 x 1	4	4	
13	JH 2314 22	Cap Backrest	1	1	1D - 4UP Model
14	JH 2314 19	Foam Backrest	2	2	1D - 4UP Model
15	LB U000 76	Screw Truss	1	1	1D - 4UP Model
16	JH 2330 20	Decal - Pillion Seat Cover	1	1	1D - 4UP Model



Head Light


No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 1812 23	Head Lamp Bezel	1	1	
2	KD BA05 12	Washer	6	6	
3	KB RA42 16	Screw Tapping Pan Cross	2	2	
4	DJ 1612 29	Clip Nut M5	2	4	
5	YJ H010 07	Head Assembly Without Bulb & Cap	1	–	
	YJ H050 01	Head Assembly Without Bulb & Cap	--	1	
6	JH 1812 33	Head Lamp Mounting Bracket Lower	1	1	
7	DJ 1810 65	Clip Nut - M6	2	2	
8	JH 1812 41	Grommet Fairing Mounting	4	4	
9	JH 1812 42	Collar Fairing Mounting	2	4	
10	KA DC06 25	Bolt Flanged	2	2	
11	DJ 1612 29	Clip Nut - M5	4	4	
12	LB U000 23	Screw Truss	4	4	
13	39 2141 24	Washer Non Metallic	4	4	
14	LB U000 44	Screw Truss	2	2	
15	JH 1812 15	Windshield	1	1	
16	JG 1812 36	Well Nut M5	2	2	
17	JZ 1812 06	Screw M5	2	2	
18	LA E000 40	Bolt Flange Small	2	2	
19	JH 1812 38	Cover Back Fairing LH	1	1	
20	JH 1812 39	Cover Back Fairing RH	1	1	




Head Light

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
21	LA D001 65	Bolt Flange	4	4	
22	YJ H010 01	Wiring Harness & Cap Headlight	1	–	
	YJ H050 02	Wiring Harness & Cap Headlight	–	1	
23	EC 4010 30	Bulb 60/55W	1	–	
24	JH 1812 71	Foam Fairing 20X20X6	3	3	
25	DH 1910 37	Bulb 3W	2	–	
26	LB U000 02	Screw Truss	–	2	
27	PA 1812 49	Foam Speedo Flap	–	4	
28	JL 1812 59	Foam Strip	–	2	
29	JH 1812 62	Sleeve For Fairing Mounting	–	2	
30	KA DC06 20	Bolt Flanged	–	2	

Indicator Light




No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 4010 06	Indicator Front LH	1	–	
	JH 4010 17	Indicator Front LH	–	1	
2	JH 4010 07	Indicator Front RH	1	–	
	JH 4010 18	Indicator Front RH	–	1	
3	31 2010 01	Collar	2	2	
4	KA DD06 20	Bolt Flanged	2	2	
5	JH 4010 00	Rear Indicator LH	1	1	
6	JH 4010 01	Rear Indicator RH	1	1	
7	KC GD10 10	Nut Hex Flange	2	2	
8	GH 2010 12	Bulb	4	4	




Electrical Equipment

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	PA 4016 00	Horn	1	1	
2	KA DD08 12	Bolt Flange	1	1	
3	JN 3516 04	Starter Relay with Grommet	1	1	
4	JF 4018 03	Battery 4AH VRLA Wet (K11)	1	1	Not Supplied in Spare
5	JH 4018 00	Band Battery	1	1	
	JV 4018 02	Band Battery	1	1	For BS IV Model
6	JZ 4018 09	Foam For Battery Base	1	1	
7	JH 4022 00	Wiring Harness	1	--	
	JH 4022 07	Wiring Harness	--	1	AHO Model
	JH 4022 11	Wiring Harness	1	--	AHO Model
	JH 4022 27	Wiring Harness	--	1	AHO Model
8	JZ 4022 18	Tie Band	4	4	
9	60 1114 15	Clip	4	--	
10	DJ 2012 19	Fuse Box Assembly	1	1	
11	60 1115 34	Fuse 15A	2	2	
12	JD 4022 17	Tie Band	9	9	
13	DS 2010 25	Flasher	1	1	
13A	DT 4020 06	Light Control Module	1	--	AHO Model
13B	JL 4020 04	Light Control Module	--	1	AHO Model
14	DS 1910 07	Spring Brake Switch	1	1	
15	JL 4014 06	Rear Brake Switch	1	1	
16	JH 4022 01	Cable Assembly (Battery to Earth)	1	1	
17	JH 4022 02	Cable Assly. (Motor to Starter Relay)	1	1	
18	DL 1910 20	Bulb Number Plate Lamp	1	1	
19A	YJ H010 08	Tail Lamp without Bezel - V15	1	1	
19B	YJ H010 09	Bezel Tail Lamp - V15	1	1	
20	KA DF06 10	Bolt Flanged	1	2	
21	JH 1710 47	Cable Tie Fixed Length	1	1	For BS IV Model
22	JH 1138 02	Clamp For Pipe	1	1	For BS IV Model
23	KA DF06 08	Bolt Flanged	1	1	For BS IV Model
24	GF 1611 31	Foam Strip	7	7	
25	60 1114 20	Cable Tie Lock	4	4	





Chain Case Kit & Tool Kit

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	36 JH00 02	Chain Case Upper + lower	1	1	Refer Kit Details
2	LA D000 53	Bolt	6	6	
3	15 1610 69	Rubber Cap	1	1	
4	DJ 2210 19	Tool Kit	1	1	
5	JZ 1813 38	Beading Chain Case	1	1	
6	DK 2210 24	Band Tool Kit	2	2	



Front & Rear Number Plate

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	JH 2328 00	Bracket Front Number Plate	1	--	
	JH 2328 09	Bkt. Number Plate Mounting Front	1	1	For BS IV Model
2	36 DT00 53	Kit Front Number Plate	1	1	Refer Kit Details
3	36 JL00 89	Kit Rear Number Plate	1	1	Refer Kit Details
4	JZ 2328 14	Pad	2	2	
5	DJ 1610 72	Bracket Rear Number Plate	1	1	
6	JZ 2328 05	Foam Rear Number Plate	1	1	
7	LC G000 08	Nut	2	2	
8	KB UC05 25	Screw Truss	2	2	For Front No. Plate
9	39 1501 11	Washer Plain	2	2	For Front No. Plate
10	JH 1812 63	Collar For Windshield Mtg	2	2	



10/11



12



13



14



15



Front Wheel Direction


Plate No.: 50

Brand ID: 001MC680 (V15)

Brand ID: 001MC706 (V12)

Painted Parts and Decals - V15

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	52 JH00 73	Fuel Tank Ebony Black With Decal	1	--	
	52 JH00 75	Fuel Tank Cocktail Wine Red	1	--	
	52 JH03 66	Fuel Tank Dark Montego Blue WH Decal	1	--	
	52 JH02 86	Fuel Tank Pearl White With Decal	1	--	BS IV
	52 JH02 85	Fuel Tank Ebony Black With Decal	1	--	BS IV
	52 JH02 87	Fuel Tank Cocktail Wine Red	1	--	BS IV
	52 JH04 46	Fuel Tank Dark Montego Blue WH Decal	1	--	BS IV
2	52 JH00 67	Side Cover LH Ebony Black With Decal	1	--	
	52 JH00 82	Side Cover LH Pearl White With Decal	1	--	
	52 JH00 69	Side Cover LH Cocktail Wine Red	1	--	
	52 JH03 59	Side Cover LH Dark Montego Blue Decal	1	--	
3	52 JH00 64	Side Cover RH Ebony Black With Decal	1	--	
	52 JH00 81	Side Cover RH Pearl White With Decal	1	--	
	52 JH00 60	Side Cover RH Cocktail Wine Red	1	--	
	52 JH03 61	Side Cover RH Dark Montego Blue	1	--	
4	56 JH05 7A	Painted Part Front Fender Pearl White	1	--	
	56 JH05 X3	Painted Part Front Fender Ebony Black	1	--	
	56 JH05 2V	Painted Part Front Fender Wine Red	1	--	
	56 JH05 7M	Painted Front Fender Dark Montego Blue	1	--	
5	56 JH04 7A	Painted Part Fairing Pearl White	1	--	
	56 JH04 X3	Painted Part Fairing Ebony Black	1	--	
	56 JH04 2V	Painted Part Fairing Assembly C W Red	1	--	
	56 JH04 7M	Painted Fairing Assly. Dark Montego Blue	1	--	
6	JH 2314 09	Primary Grab Handle Black	1	--	
	56 JH70 6S	Primary Grab Handle Red	1	--	
	56 JH70 1W	Primary Grab Handle White	1	--	
	56 JH5W 36	Grab With Backrest Mat Slik Blk	1	--	1D - 4UP Model



10/11



12



13



14



15



Front Wheel Direction


Plate No.: 50

Brand ID: 001MC680 (V15)

Brand ID: 001MC706 (V12)


Painted Parts and Decals - V15

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
7	52 JH00 86	Cover Seat Pillion Pearl White	1	--	
	52 JH00 32	Cover Seat Pillion Ebony Black	1	--	
	52 JH00 59	Cover Seat Pillion Cocktail Wine Red	1	--	
	52 JH03 64	Cover Seat Pillion Dark Montego Blue	1	--	
8	56 JH45 X3	Painted Part Seat Cowl Ebony Black	1	--	1D - 4UP Model
	56 JH45 7M	Assly Seat Cowl Dark Mont Blue	1	--	
	56 JH45 2V	Painted Seatcowl C W Red	1	--	
9	JH 1812 20	Painted Part Cover Seat Cowl LH	1	--	1D - 4UP Model
	JH 1812 21	Painted Part Cover Seat Cowl RH	1	--	
	56 JH11 4X	Cover Seat Cowl LH Satin Black	1	--	
	56 JH10 4X	Cover Seat Cowl LH Satin Black	1	--	
10	JH 2330 25	Decal Side Cover LH - White	1	--	
	JH 2330 26	Decal Side Cover RH - White	1	--	
	JH 2330 33	Decal Side Cover RH	1	--	
	JH 2330 57	Decal Side RH	1	--	
11	JH 2330 15	Decal Side Cover LH - Black	1	--	
	JH 2330 16	Decal Side Cover RH - Black	1	--	
	JH 2330 32	Decal Side Cover LH	1	--	
	JH 2330 56	Decal Side LH	1	--	
12	JH 2330 21	Decal Kit Tank - White	1	--	
	JH 2330 14	Decal Kit Tank - Black	1	--	
	JH 2330 28	Decal Tank Kit Cocktail Wine Red	1	--	
	JH 2330 52	Decal Kit Tank Montego Blue	1	--	
13	JH 2330 18	Decal 3D - Tank	2	--	
14	JH 2330 19	Decal 3D - Side Cover	2	--	
	JH 2330 58	Decal Side Cover 3D	2	--	
15	JH 2330 20	Decal - Pillion Seat Cover	1	--	



Painted Parts and Decals - V12

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
1	52 JH04 25	Fuel Tank Flame Red Wh Decal	--	1	
	52 JH04 27	Fuel Tank Saffire Blue With Decal	--	1	
	52 JH04 26	Fuel Tank Ebony Black With Decal	--	1	
2	52 JH04 10	Side Cover LH Flame Red With Decal	--	1	
	52 JH04 12	Side Cover LH Saffire Blue Th Decal	--	1	
	52 JH04 11	Side Cover LH Ebony Black Wh Decal	--	1	
3	52 JH04 13	Side Cover RH Flame Red With Decal	--	1	
	52 JH04 14	Side Cover RH Ebony Black Wh Decal	--	1	
	52 JH04 15	Side Cover RH Saffire Blu Wh Decal	--	1	
4	56 JH05 X3	Painted Part Front Fender Ebony Black	--	1	
5	56 JH04 3F	Fairing Asly Flm Red	--	1	
	56 JH04 5N	Fairing Asly Saff Blue	--	1	
	56 JH04 X3	Fairing Asly Eb Black	--	1	
6	56 JH70 43	Primary Grab Handle Orange	--	1	1D - 4UP Model
	56 JH70 6E	Primary Grab Handle Silver	--	1	
	56 JH5W 36	Grab With Backrest Mat Slik Blk	--	1	
7	52 JH04 48	Cover Seat Pillion Flame Red	--	1	
	52 JH04 49	Cover Seat Pillion Saffire Blue	--	1	
	52 JH00 32	Cover Seat Pillion Ebony Black	--	1	
8	JH 2330 60	Kit Decal Tank Flame Red	--	1	
	JH 2330 67	Kit Decal Tank Ebony Black	--	1	
	JH 2330 74	Kit Decal Tank Saf Blue	--	1	
9	JH 1812 20	Painted Part Cover Seat Cowl LH	--	1	1D - 4UP Model
	JH 1812 21	Painted Part Cover Seat Cowl RH	--	1	
	56 JH11 4X	Cover Seat Cowl LH Satin Black	1	--	
	56 JH10 4X	Cover Seat Cowl LH Satin Black	1	--	



Painted Parts and Decals - V12

No.	Part No.	Description	Qty.		Remarks
			V15	V12	
10	56 JH45 X3	Painted Part Seat Cowl Ebony Black	--	1	1D - 4UP Model
	56 JH45 7M	Assly Seat Cowl Dark Mont Blue	--	1	
	56 JH45 3F	Painted Seatcowl Flm Red	--	1	
	56 JH45 5N	Painted Seat Cowl Saffire Blue	--	1	
11	JH 2330 64	Decal Cover Side LH Flame Red	--	1	
	JH 2330 71	Decal Cover Side LH Eb Black	--	1	
	JH 2330 78	Decal Cover Side LH Saf Blue	--	1	
12	JH 2330 65	Decal Cover Side RH Flame Red	--	1	
	JH 2330 72	Decal Cover Side RH Eb Black	--	1	
	JH 2330 79	Decal Cover Side RH Saf Blue	--	1	
13	JH 2330 18	Tank 3D Decal	--	2	
14	JH 2330 66	Decal 3D Cover Side Flame Red	--	2	
	JH 2330 73	Decal 3D Cover Side Eb Black	--	2	
	JH 2330 80	Decal 3D Cover Side Saf Blue	--	2	
15	JH 2330 34	Deal Pillion Seat Cover	--	1	
16	JH 2330 59	Decal Wheel	--	4	

1		2		3	
4		5		6	
7		8		9	
10		11		12	



Consumable Parts

No.	Part No.	Description	Supply Unit	Application
1	36 0010 61 83 0204 11 83 0203 34	Bajaj Genuine Oil 10W50 Bajaj Genuine Oil 10W30 Bajaj Genuine Oil 20W50 (BGO to be ordered to HPCL)	1.5 Ltr. 1 Ltr. 1 Ltr.	Dominar 400 100cc Models 125cc and above models
2	36 0010 58	Bajaj Coolant Koolex	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61 83 0203 25	Brake Fluid DOT4 Brake Fluid DOT3	100 ml 100 ml	Disc Brake Top-up/Replace Disc Brake Top-up/Replace
4	36 0010 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 83 0203 68	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 0010 52	HP Lithon RR Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04	Fork oil	160 ml	Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

13		14		15	
16		17		18	
19		20		21	
22		23		24	



Consumable Parts

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray		For Cleaning Carburetor
24	37 2540 39	Corrosion Protection Spray Proto quick LTP902 (To be ordered on Vendor)	--	For Preventing vehicle parts from rusting

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JH0002	CHAIN CASE UPPER + LOWER	JH181200	ASSEMBLY CHAIN CASE UPPER	1
			JH181203	ASSEMBLY CHAIN CASE LOWER	1
2	36JH0003	BLOCK & PISTON	JH521004	CYLINDER BLOCK C101_ALUMINIUM	1
			JH521200	ASSEMBLY PISTON C101	1
3	36JH0004	FRICTION PLATE	JH551402	PLATE FRICTION C101	5
4	36JH0005	CHAIN GUIDE	JE521025	GUIDE TIGHT SIDE SILENT CHAIN D106A	1
			JE541037	GUIDE SLACK SIDE SILENT CHAIN D106A	1
5	36JH0006	CHAIN SPROCKET	JH551201	SPROCKET OUTPUT C101	1
			DX151023	SPROCKET 42 T 4 RUBBER	1
			PA141016	CHAIN 428 H SERIES 124 LINKS	1
6	36JH0052	KIT ASSLY CLUTCH COVER - V12	JH541201	COVER CLUTCH C101	1
			JL541227	WINDOW OIL GUAGE	1
			DS101215	CLIP WIRE	1
			30101142	SEAL OIL	1
			31101064	PLUG	1
			BA102004	PLUG	1
7	36JH0008	VALVE REPAIR	28101129	SEAT SPRING	1
			39201719	SEAL VALVE STEM	1
			JZ511202	SPRING VALVE	1
			JA511203	RETAINER VALVE SPRING	1
			DG101029	COTTER VALVE	2
8	36JH0009	BOSS KICK SET	JA621202	LEVER KICK	1
			PA621202	BOSS KICK LEVER D105A UG	1
			30101234	SPRING	1
			30101236	BALL STEEL	1
			22150241	WASHER - PLAIN	1
			30101235	PIN	1
			39085517	E-TYPE CIRCLIP	1
9	36JH0010	PRIMARY DRIVE & DRIVEN GEAR	JZ531006	GEAR PRIMARY DRIVE	1
			JZ551403	CLUTCH HSG ASSLY HTTS DISCO-H	1
10	36JH0011	FORK CYLINDER COMP	JH121015	SEAT PIPE	1
			DG181017	RING-FORK PISTON	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			JH121049	CAP OIL LOCK	1
			DG181019	SPRING-REBOUND	1
11	36JH0012	CARB O RINGS&GASKET	DP121059	O RING FLOAT CHAMBER	1
			Je581209	O RING	1
			Dh121130	O RING	1
			DH121148	O RING	1
			-- ---- --	O RING	1
12	36JH0013	CARB JETS	-- ---- --	NEEDLE JET	1
			Jz581219	JET HOLDER	1
			-- ---- --	MAIN JET	1
			-- ---- --	PILOT JET	1
13	36JH0014	CARB THROTTLE VALVE	-- ---- --	DIAPHRAGM	1
			-- ---- --	PISTON VALVE ASSLY	1
			-- ---- --	SPRING	1
			-- ---- --	HOLDER	1
			-- ---- --	SPRING	1
			-- ---- --	E RING	1
			-- ---- --	WASHER	1
			-- ---- --	JET NEEDLE	1
14	36JH0015	CARB FLOAT CHAMBER BODY	-- ---- --	SCREW	3
			-- ---- --	O RING	1
			-- ---- --	DRAIN SCREW	1
			-- ---- --	O RING	1
			-- ---- --	FLOAT BODY	1
15	36JH0016	CARB IDLING SCREW	-- ---- --	PILOT SCREW	1
			-- ---- --	SPRING	1
			-- ---- --	WASHER	1
			-- ---- --	O RING	1
			-- ---- --	O RING	1
16	36JH0017	CARB TOP CAP	-- ---- --	DIAPHRAGM COVER	1
			-- ---- --	SCREW	2
17	36JH0018	CARB PLUNGER ASSLY	-- ---- --	O RING	1
			-- ---- --	DUST CAP	1
			-- ---- --	PLUNGER ASSLY	1
			-- ---- --	GUIDE HOLDER	1
			-- ---- --	O RING	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
18	36JH0001	PISTON RINGS	JH521203	PISTON RING TOP C101	1
			JH521204	PISTON RING SECOND C101	1
			JH521205	PISTON RING OIL C101	1
19	36JH0021	KIT ASSLY C'CASE LH	39218919	OIL SEAL	1
			39256220	NEEDLE ROLLER BRG.	1
			JH541001	CRANKCASE LH C101	1
			JA541005	BUSH BENDIX	1
			39219019	OIL SEAL	1
			JZ541005	NOZZLE OIL JET	1
20	36JH0022	KIT ASSLY C'CASE RH	PA541043	CRANKCASE RH	1
			PF541018	BUSHING DRUM BM150 4 SPD	1
			31101064	PLUG	1
21	36JH0023	CYL HEAD COVER WITH NIPPLE	JH511001	CYLINDER HEAD MACHINED	1
			Jh511012	CYLINDER HEAD COVER C101	
			Jh511014	NIPPLE BREATHER HEAD COVER C101	1
22	JH232602	ASSEMBLY LOCK SET - NON EVAP	JZ401400	IGNITION SWITCH 2 PT. MOUNTING	1
			JH232600	KEY SET	1
			JH171033	CAP FUEL TANK	1
			DH161231	LOCK SIDE COVER	1
23	JH541202	ASSEMBLY MAGNETO COVER	JH541203	MAGNETO COVER C101	1
			Ja541005	BUSH BENDIX	1
			Ja541233	CAP TDC FINDER	1
			30101195	RING - O	1
24	36JH0019	VALVE INTAKE & EXHAUST	JH511202	VALVE INTAKE	1
			JH511203	VALVE EXHAUST	1
25	36PA0143	KIT STEERING CONE-DIS 100 M	JZ151090	BEARING CONE	1
			DH181026	BEARING RACE	2
			DH181025	BEARING CONE	1
			36001052	GREASE LETHON RR3 -10GM	1
			36314002	KIT BALL STEEL STEERING	1
26	36DT0053	KIT FR.NUMBER PLATE	Ju232800	NUMBER PLATE FRONT	1
			LBU00009	SCREW MUSHROOM HEAD	2
			39214124	WASHER NYLON 5.3X11.5X1.5	2

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
27	36JL0089	KIT RR.NUMBER PLATE	Dp161145	PLATE -NO.:RR-SAME AS SECURITY PL	1
			KADD0610	BOLT-FLANGE-KAD ST-D DIA-06 L-10	2
28	36JH0025	Kit Engine Gasket-V15	JH511016	GASKET CYLINDER HEAD C101	1
			CS101128	GASKET	1
			JH521001	GASKET CYLINDER BLOCK C101	1
			JH541015	GASKET CRANKCASE C101	1
			Ja541016	GASKET CASE OIL PUMP	1
			PF541240	GASKET MAGNETO COVER B104D	1
			JA541212	GASKET CLUTCH COVER	1
			36001050	KIT 5 ml Loctite 243 Tube	1
			36001051	KIT LOCTITE 5702 10 gm	1
29	36JH0027KIT	CYL HEAD + COVER V12	JH511048	ASSEMBLY OHC COVER C101B	1
			JH511030	CYLINDER HEAD MACHINED C101B	1
			CB101220	PLUG	1
			KJAC1824	O RING	1
			39166005	STUD-M8	2
30	36JH0028	KIT VALVE V12	DY511200	VALVE INTAKE B105A	1
			DY511201	VALVE EXHAUST B105A	1
31	36JH0029	KIT VALVE REPAIR V12	28101129	SEAT SPRING	2
			CB101009	SEAL VALVE STEM	2
			JZ511202	SPRING VALVE	2
			DY511202	RETAINER VALVE B105A	2
			CB101022	COTTER VALVE	4
32	36JH0030	KIT BLOCK PISTON V12	JH521002	CYLINDER BLOCK C101B	1
			JH521207	ASSEMBLY PISTON C101B	1
33	36JH0031	KIT CYL FORK	JH121055	SEAT PIPE	1
			30181020	PISTON RING	1
			JH121049	CAP OIL LOCK	1
			DM181008	REBOUND SPRING	1
34	36JH0032	KIT PISTON RINGS	PA521225	RING PISTON TOP D105D	1
			PA521226	RING PISTON SECOND D105D	1
			PA521227	RING PISTON OIL D105D	1

THE INVINCIBLE

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
35	36JH0053	Kit Assly Clutch Cover - V15	JH541201 JL541227 DS101215 30101142 31101064 BA102004 JE541245	COVER CLUTCH C101 WINDOW OIL GUAGE CLIP - WIRE SEAL - OIL PLUG PLUG JET CLUTCH COVER K11	1 1 1 1 1 1 1

THE INVINCIBLE

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
01 1701 22	23	70	31 1011 73	4	14
14 1510 33	15	30	31 1811 08	7	80
15 1610 69	3	104	31 2010 01	3	100
15 1910 26	12	72	31 2010 81	4	24
22 1502 41	14	38	36 3015 09	12	66
30 1010 61	21	16	36 DH19 02	4	74
30 1010 96	3	30	36 DJ40 32	11	76
30 1011 42	7	26	36 DJ40 33	12	76
30 1011 95	5	28	36 DK00 65	11	76
30 1410 31	12	56	36 DK00 66	12	76
30 1510 32	19	66	36 DT00 53	2	106
30 1510 33	7	64	36 JE00 24	16	30
30 1510 33	20	66	36 JF00 22	9	34
30 1510 38	4	66	36 JF00 24	6	34
30 1510 69	10	66	36 JH00 01	4	12
30 1510 69	16	68	36 JH00 02	1	104
30 1510 75	18	68	36 JH00 03	5	12
30 1510 95	22	72	36 JH00 04	16	30
30 1511 05	9	66	36 JH00 06	10	68
30 1511 05	3	68	36 JH00 08	6	8
30 1511 18	15	66	36 JH00 09	11	38
30 1611 57	2	60	36 JH00 11	14	80
30 1810 26	5	80	36 JH00 12	2	34
30 1810 29	17	82	36 JH00 12	9	36
30 1910 35	11	72	36 JH00 13	3	34
30 1910 36	13	72	36 JH00 14	4	34
31 1010 06	8	2	36 JH00 15	5	34
31 1010 64	6	26	36 JH00 17	7	34

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 JH00 18	8	34	36 JZ01 22	9	10
36 JH00 19	1	8	36 PA01 15	9	10
36 JH00 21	1	24	36 PA01 44	4	50
36 JH00 22	2	22	36 PA01 44	18	82
36 JH00 23	1	2	36 PD00 36	11	74
36 JH00 25	2	24	36 PD00 43	5	76
36 JH00 27	1A	2	36 PD00 44	13	76
36 JH00 28	1	8	36 PD00 45	14	76
36 JH00 29	6	8	36 PF00 88	8	14
36 JH00 30	5	12	39 0198 11	14	72
36 JH00 31	14	80	39 0240 11	12	30
36 JH00 32	4	12	39 0242 11	11	66
36 JH00 33	16	30	39 0258 11	4	88
36 JH00 39	10	36	39 0292 15	7	54
36 JH00 40	16	36	39 0296 15	8	94
36 JH00 42	14	36	39 0422 15	11	60
36 JH00 43	11	36	39 0422 15	7	78
36 JH00 44	12	36	39 0454 11	9	54
36 JH00 45	13	36	39 0553 02	10	54
36 JH00 46	2	24	39 0594 17	3	10
36 JH00 52	1	26	39 0694 15	19	72
36 JH00 53	1	26	39 0714 11	18	54
36 JH00 57	16	30	39 0738 17	3	38
36 JL00 89	3	106	39 0740 11	10	84
36 JZ00 03	8	14	39 0781 11	9	64
36 JZ00 03	4	30	39 0789 12	18	72
36 JZ00 23	8	14	39 0789 12	20	82
36 JZ00 23	4	30	39 0801 15	15	68

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 0807 08	20	72	39 1673 04	15	10
39 0980 04	7	30	39 1673 04	13	26
39 0987 17	6	16	39 1674 04	17	4
39 0992 06	4	18	39 1674 04	2	48
39 0993 11	6	38	39 1680 04	4	72
39 0999 06	20	4	39 1740 04	11	22
39 0999 06	18	26	39 1789 24	15	92
39 0999 06	2	28	39 19 5604	16	84
39 0999 06	4	32	39 1964 04	10	22
39 1000 06	20	4	39 1970 15	3	52
39 1000 06	2	12	39 2141 24	13	96
39 1000 06	10	24	39 2166 11	11	16
39 1001 20	15	30	39 2179 24	9	84
39 1013 21	13	66	39 2189 19	5	24
39 1020 21	7	2	39 2190 19	6	24
39 1041 19	14	26	39 2200 11	13	30
39 1053 15	12	54	39 2295 15	9	40
39 1075 04	2	58	39 2366 15	15	54
39 1181 01	21	82	39 2408 17	8	38
39 1225 15	11	52	39 2424 11	17	84
39 1283 21	13	2	39 2425 11	11	40
39 1501 11	9	106	39 2440 11	8	8
39 1540 11	17	72	39 2443 11	15	26
39 1553 04	7	30	39 2484 15	6	84
39 1612 11	6	2	39 2492 11	6	40
39 1660 05	21	4	39 2539 21	15	2
39 1671 21	11	26	39 2562 20	8	24
39 1673 04	9	2	39 2566 11	20	68

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 2567 11	29	70	52 JH03 59	2	108
39 2582 04	10	78	52 JH03 61	3	108
39 2583 20	7	24	52 JH03 64	7	110
39 2600 11	11	30	52 JH03 66	1	108
39 2608 01	11	2	52 JH04 10	2	112
39 2629 21	12	2	52 JH04 11	2	112
39 2669 21	13	10	52 JH04 12	2	112
39 2726 12	16	54	52 JH04 13	3	112
52 JA00 28	14	30	52 JH04 14	3	112
52 JA00 29	3	22	52 JH04 15	3	112
52 JH00 18	1	56	52 JH04 25	1	112
52 JH00 19	3	56	52 JH04 26	1	112
52 JH00 22	1	72	52 JH04 27	1	112
52 JH00 32	7	110	52 JH04 31	11	78
52 JH00 32	7	112	52 JH04 31	7	84
52 JH00 59	7	110	52 JH04 33	11	78
52 JH00 60	3	108	52 JH04 33	7	84
52 JH00 64	3	108	52 JH04 46	1	108
52 JH00 67	2	108	52 JH04 48	7	112
52 JH00 69	2	108	52 JH04 49	7	112
52 JH00 73	1	108	52 JH55 05	8	2
52 JH00 75	1	108	52 JH55 06	22	4
52 JH00 81	3	108	52 JZ02 64	1	20
52 JH00 82	2	108	56 JH04 2V	5	108
52 JH00 86	7	110	56 JH04 3F	5	112
52 JH02 85	1	108	56 JH04 5N	5	112
52 JH02 86	1	108	56 JH04 7A	5	108
52 JH02 87	1	108	56 JH04 7M	5	108

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 JH04 X3	5	108	56 JH70 6S	6	108
56 JH04 X3	5	112	59 0400 06	27	78
56 JH05 2V	4	108	59 0400 14	14	46
56 JH05 7A	4	108	59 0400 38	12	22
56 JH05 7M	4	108	59 0400 38	12	24
56 JH05 X3	4	108	59 0400 38	19	26
56 JH05 X3	4	112	59 0400 38	4	28
56 JH10 4X	9	110	59 1500 03	4	64
56 JH10 4X	9	112	59 1500 03	21	66
56 JH11 4X	9	110	59 1500 14	2	14
56 JH11 4X	9	112	59 2000 36	5	22
56 JH45 2V	8	110	59 2100 23	16	24
56 JH45 3F	10	114	60 1114 15	9	102
56 JH45 5N	10	114	60 1114 20	25	102
56 JH45 7M	8	110	60 1115 34	11	102
56 JH45 7M	10	114	AP 1012 55	8	84
56 JH45 X3	8	110	BF 5612 19	6	20
56 JH45 X3	10	114	CB 1010 09	10	2
56 JH5W 36	9A	94	CB 1010 09	5	8
56 JH5W 36	6	108	CB 1010 22	4	8
56 JH5W 36	6	112	CF 1110 19	13	46
56 JH70 1W	9	94	CM 2010 54	12	88
56 JH70 1W	6	108	CS 1011 28	11	10
56 JH70 43	9	94	DD 1010 62	14	10
56 JH70 43	6	112	DD 1010 97	12	38
56 JH70 6E	9	94	DD 1110 12	7	46
56 JH70 6E	6	112	DD 1110 18	13	46
56 JH70 6S	9	94	DD 1211 81	10	26

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DD 1610 71	10	40	DG 1810 23	6	80
DD 1610 78	3	72	DG 1810 24	10	80
DD 1613 81	11	56	DG 1810 26	17	82
DD 1810 32	8	80	DG 1910 45	5	72
DD 1911 42	1	74	DH 1010 48	6	10
DD 2010 02	11	58	DH 1012 35	10	16
DE 1510 06	5	64	DH 1012 95	7	8
DE 1510 43	9	76	DH 1013 80	7	22
DE 1510 45	10	76	DH 1013 80	14	24
DE 1510 46	6	76	DH 1013 92	10	10
DE 1510 47	7	76	DH 1015 09	10	20
DE 1910 10	10	74	DH 1016 39	10	22
DE 1910 28	7	74	DH 1016 48	14	30
DE 1910 29	6	74	DH 1017 84	3	24
DE 1910 33	15	74	DH 1021 18	15	42
DF 1611 02	10	60	DH 1021 25	7	10
DG 1010 29	4	8	DH 1110 13	8	46
DG 1210 03	7	6	DH 1110 15	5	46
DG 1210 40	16	4	DH 1210 59	10	34
DG 1210 40	13	42	DH 1210 63	11	34
DG 1510 88	4	76	DH 1210 64	17	34
DG 1510 89	2	76	DH 1210 93	16	34
DG 1611 21	9	92	DH 1211 76	13	34
DG 1611 21	16	92	DH 1610 61	11	56
DG 1810 13	9	80	DH 1611 00	10	56
DG 1810 15	11	80	DH 1611 46	9	60
DG 1810 21	8	80	DH 1612 33	7	86
DG 1810 22	7	80	DH 1612 40	8	60

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DH 1710 19	17	68	DJ 2011 73	15	58
DH 1810 22	20	78	DJ 2012 19	10	102
DH 1910 37	25	98	DJ 2210 19	4	104
DJ 1010 64	8	40	DK 1013 86	7	10
DJ 1013 05	18	42	DK 1016 10	7	40
DJ 1013 05	9	58	DK 1017 51	2	8
DJ 1410 70	2	44	DK 1410 41	13	84
DJ 1510 34	19	68	DK 1510 12	12	68
DJ 1510 36	4	54	DK 1510 26	2	62
DJ 1510 37	5	54	DK 1510 26	10	64
DJ 1510 47	6	54	DK 1510 94	8	68
DJ 1610 69	4	58	DK 2210 24	6	104
DJ 1610 72	5	106	DL 1910 20	18	102
DJ 1612 29	3	92	DM 1810 10	11	80
DJ 1612 29	4	96	DP 1210 25	6	42
DJ 1612 29	11	96	DP 1210 59	12	34
DJ 1612 78	18	56	DP 1610 94	19	42
DJ 1810 65	7	96	DS 1011 17	4	38
DJ 1811 15	6	50	DS 1011 54	5	14
DJ 1910 23	14	74	DS 1012 15	9	26
DJ 1910 25	11	74	DS 1012 76	5	10
DJ 1910 26	10	74	DS 1013 55	25	16
DJ 1910 29	2	74	DS 1099 05	8	10
DJ 1910 30	3	74	DS 1211 26	4	42
DJ 1910 31	5	74	DS 1410 12	2	84
DJ 1910 56	8	74	DS 1410 12	11	92
DJ 1910 57	1	74	DS 1510 58	8	64
DJ 2011 09	9	74	DS 1510 73	9	68

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DS 1510 89	3	66	JA 5310 12	12	14
DS 1510 91	5	66	JA 5310 15	11	14
DS 1510 94	8	66	JA 5410 05	7	28
DS 1510 94	24	70	JA 5410 10	6	22
DS 1610 35	14	92	JA 5410 12	9	22
DS 1611 25	3	58	JA 5410 16	3	32
DS 1810 07	3	78	JA 5412 11	5	26
DS 1810 10	6	78	JA 5412 12	2	26
DS 1810 12	16	82	JA 5412 25	4	26
DS 1810 15	8	50	JA 5412 33	6	28
DS 1810 16	9	50	JA 5510 02	4	16
DS 1910 07	14	102	JA 5510 04	2	16
DS 1910 52	16	78	JA 5514 06	10	30
DS 2010 25	13	102	JA 5514 14	2	30
DT 1312 07	6	68	JA 5514 19	3	30
DT 4020 06	13A	102	JA 5514 20	12	30
DU 1611 02	12	92	JA 5814 06	24	36
DU 1811 08	6	80	JA 6210 02	5	38
DY 5112 04	1	10	JA 6210 06	6	38
DZ 1410 75	18	84	JA 6210 06	2	38
EC 4010 30	23	98	JA 6212 06	13	38
FD 1010 78	2	32	JB 1220 10	17	54
GF 1611 31	24	102	JB 1220 16	19	54
GH 2010 12	8	100	JB 1310 22	22	66
GL 6214 14	6	48	JB 5110 18	14	2
JA 1210 05	16	72	JB 5310 21	10	14
JA 1316 06	14	66	JB 5514 06	8	30
JA 5112 16	4	10	JB 5514 08	2	30

Parts Index



Part Number	Figure No.	Page No.
JB 5812 29	3	36
JB 5812 30	2	36
JB 5812 56	4	36
JB 5812 60	8	36
JB 5910 59	3	40
JB 5910 68	4	40
JC 1510 04	4	68
JC 1510 06	7	68
JC 1510 12	25	70
JC 1510 16	1	68
JD 1110 52	1	84
JD 1138 14	12	6
JD 1138 15	11	6
JD 1220 04	15	72
JD 1318 10	1	64
JD 1318 10	1A	64
JD 1318 10	1	76
JD 1318 11	11	64
JD 1318 11	3	76
JD 1410 03	14	68
JD 1610 02	6	72
JD 1610 06	7	72
JD 1718 01	11	84
JD 3512 06	10	46
JD 4022 17	12	102
JD 5310 04	9	14
JD 5514 00	9	30
JD 5610 04	6	18

Part Number	Figure No.	Page No.
JD 5610 06	5	18
JD 5610 11	3	18
JD 5612 04	7	20
JD 5614 16	14	20
JE 3514 03	3	12
JE 5110 67	2	6
JE 5112 36	8	10
JE 5112 37	5	10
JE 5310 01	6	14
JE 5410 28	4	22
JE 5410 38	7	14
JE 5510 01	1	16
JE 5512 00	8	16
JE 5512 01	5	16
JE 5512 02	3	16
JE 5512 03	7	16
JE 5512 06	16	16
JE 5512 11	20	16
JE 5512 12	18	16
JE 5512 15	19	16
JE 5512 16	17	16
JE 5514 08	3	26
JE 5514 09	13	30
JE 5610 05	2	18
JE 5610 06	1	18
JE 5612 00	3	20
JE 5810 35	4	6
JE 5810 39	5	6

Parts Index



Part Number	Figure No.	Page No.
JE 5812 18	15	34
JE 5812 23	14	34
JE 6210 03	9	38
JE 6210 04	15	38
JE 6214 03	5	48
JF 4018 03	4	102
JF 5110 52	14	2
JG 1710 29	18	44
JG 1710 86	7	44
JG 1812 36	16	96
JG 5710 24	15	24
JG 5814 42	15	42
JH 1110 00	1	50
JH 1110 18	15	50
JH 1130 04	8	56
JH 1130 05	16	56
JH 1130 06	2	56
JH 1130 09	9	56
JH 1130 10	20	56
JH 1130 11	17	56
JH 1130 12	22	56
JH 1130 19	8	56
JH 1130 20	16	56
JH 1130 21	20	56
JH 1130 22	9	56
JH 1130 23	17	56
JH 1132 00	7	60
JH 1132 01	1	60

Part Number	Figure No.	Page No.
JH 1132 03	5	56
JH 1132 05	7	60
JH 1134 00	2	52
JH 1134 01	1	52
JH 1134 02	6	52
JH 1134 03	9	52
JH 1134 10	7	52
JH 1134 15	6A	52
JH 1134 16	6B	52
JH 1138 00	13	54
JH 1138 02	22	102
JH 1138 05	12	50
JH 1138 10	10	50
JH 1138 13	14	50
JH 1210 05	13	80
JH 1210 06	19	82
JH 1210 09	1	80
JH 1210 10	23	82
JH 1210 11	22	82
JH 1210 12	2	80
JH 1210 13	3	80
JH 1210 14	24	82
JH 1210 16	16	82
JH 1210 19	25	82
JH 1210 32	15	82
JH 1210 33	12	80
JH 1210 38	1	80
JH 1210 39	2	80

Parts Index



Part Number	Figure No.	Page No.
JH 1210 40	3	80
JH 1210 41	13	80
JH 1210 42	26	82
JH 1210 43	19	82
JH 1210 47	23	82
JH 1210 48	22	82
JH 1210 50	1	80
JH 1210 51	23	82
JH 1210 52	22	82
JH 1210 53	2	80
JH 1210 54	3	80
JH 1210 56	15	82
JH 1210 79	17	64
JH 1210 79	16	74
JH 1220 03	14	54
JH 1220 04	11	54
JH 1220 09	3	54
JH 1220 11	1	54
JH 1220 12	20	54
JH 1220 13	2	54
JH 1220 14	8	54
JH 1220 15	14	54
JH 1310 01	1	62
JH 1310 06	3	62
JH 1310 11	2	64
JH 1310 11	1	66
JH 1310 23	3	62
JH 1310 25	1B	62

Part Number	Figure No.	Page No.
JH 1310 30	6	62
JH 1310 31	1A	62
JH 1312 01	4	62
JH 1312 02	5	62
JH 1312 03	27	70
JH 1312 04	30	70
JH 1312 08	30	70
JH 1312 18	4A	62
JH 1312 22	5	62
JH 1312 23	7	62
JH 1316 00	3	64
JH 1318 01	12	74
JH 1318 02	2	68
JH 1318 03	5	68
JH 1318 20	2	66
JH 1318 33	12	74
JH 1318 35	2	76
JH 1318 80	6	66
JH 1318 87	1A	64
JH 1318 87	1	76
JH 1510 01	12	78
JH 1510 02	17	78
JH 1510 03	18	78
JH 1510 06	1	78
JH 1510 07	2	78
JH 1510 09	9	78
JH 1510 11	20	78
JH 1510 18	2	50

Parts Index



Part Number	Figure No.	Page No.
JH 1510 21	2	78
JH 1510 41	20	78
JH 1610 02	2	72
JH 1610 04	8	72
JH 1612 00	3	90
JH 1612 02	4	90
JH 1612 03	5	86
JH 1612 04	6	86
JH 1612 09	3	90
JH 1612 10	4	90
JH 1710 08	3	84
JH 1710 14	7	50
JH 1710 16	11	50
JH 1710 17	5	84
JH 1710 18	19	44
JH 1710 19	17	44
JH 1710 20	2	44
JH 1710 20	11	44
JH 1710 21	6	44
JH 1710 22	8	44
JH 1710 23	14	44
JH 1710 24	15	44
JH 1710 33	7	84
JH 1710 45	15	84
JH 1710 47	21	102
JH 1710 48	16	44
JH 1710 72	8	44
JH 1716 01	12	44

Part Number	Figure No.	Page No.
JH 1716 02	20	44
JH 1718 00	12	84
JH 1718 01	14	84
JH 1812 07	3	88
JH 1812 15	15	96
JH 1812 20	9	110
JH 1812 20	9	112
JH 1812 21	9	110
JH 1812 21	9	112
JH 1812 23	1	96
JH 1812 28	5	92
JH 1812 31	20	34
JH 1812 33	6	96
JH 1812 34	4	92
JH 1812 38	19	96
JH 1812 39	20	96
JH 1812 41	8	96
JH 1812 42	9	96
JH 1812 43	11	86
JH 1812 53	2	88
JH 1812 55	10	86
JH 1812 59	13	88
JH 1812 62	29	98
JH 1812 63	10	106
JH 1812 65	19	36
JH 1812 71	24	98
JH 1812 80	21	34
JH 1812 80	20	36

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JH 1812 99	12	64	JH 2326 06	13	92
JH 1813 00	15	64	JH 2326 12	11	78
JH 1813 05	12	64	JH 2326 16	11	78
JH 1813 06	15	64	JH 2326 16	11A	78
JH 1814 03	5	58	JH 2328 00	1	106
JH 1814 04	7	58	JH 2328 09	1	106
JH 1814 05	6	58	JH 2330 14	12	110
JH 1814 08	1	58	JH 2330 15	11	110
JH 1814 11	8	58	JH 2330 16	11	110
JH 1910 00	1	86	JH 2330 18	13	110
JH 1910 03	12	86	JH 2330 18	13	114
JH 1910 14	1A	86	JH 2330 19	14	110
JH 2312 02	5	94	JH 2330 20	16	94
JH 2312 04	3	94	JH 2330 20	15	110
JH 2312 10	1	94	JH 2330 21	12	110
JH 2312 11	2	94	JH 2330 25	10	110
JH 2314 09	9	94	JH 2330 26	10	110
JH 2314 09	11	94	JH 2330 28	12	110
JH 2314 09	6	108	JH 2330 32	11	110
JH 2314 19	14	94	JH 2330 33	10	110
JH 2314 22	13	94	JH 2330 34	15	114
JH 2316 00	24	78	JH 2330 52	12	110
JH 2316 01	25	78	JH 2330 56	11	110
JH 2326 02	11	78	JH 2330 57	10	110
JH 2326 02	7	84	JH 2330 58	14	110
JH 2326 02	13	92	JH 2330 59	16	114
JH 2326 06	11	78	JH 2330 60	8	112
JH 2326 06	7	84	JH 2330 64	11	114

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JH 2330 65	12	114	JH 4022 00	7	102
JH 2330 66	14	114	JH 4022 01	16	102
JH 2330 67	8	112	JH 4022 02	17	102
JH 2330 71	11	114	JH 4022 07	7	102
JH 2330 72	12	114	JH 4022 11	7	102
JH 2330 73	14	114	JH 4022 27	7	102
JH 2330 74	8	112	JH 4024 00	1	88
JH 2330 78	11	114	JH 4024 04	1	88
JH 2330 79	12	114	JH 4026 00	4	84
JH 2330 80	14	114	JH 5010 01	1	22
JH 3510 05	2	46	JH 5010 03	1	22
JH 3510 07	2	46	JH 5010 30	1	22
JH 3512 00	4	46	JH 5010 31	1	22
JH 3512 03	6	46	JH 5110 16	19	4
JH 3512 05	9	46	JH 5110 17	2	10
JH 3512 07	4	46	JH 5110 28	9	8
JH 3516 00	1	48	JH 5110 44	19	4
JH 3516 01	1	48	JH 5110 45	23	4
JH 4010 00	5	100	JH 5110 50	7	2
JH 4010 01	6	100	JH 5112 07	3	8
JH 4010 06	1	100	JH 5112 08	1	10
JH 4010 07	2	100	JH 5112 10	3	8
JH 4010 17	1	100	JH 5210 01	1	12
JH 4010 18	2	100	JH 5210 05	12	10
JH 4014 00	22	78	JH 5210 07	1	12
JH 4014 01	23	78	JH 5310 00	1	14
JH 4014 02	23A	78	JH 5310 07	1	14
JH 4018 00	5	102	JH 5410 08	2	22

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JH 5410 15	11	24	JH 5514 11	1	30
JH 5410 21	13	24	JH 5514 12	17	30
JH 5412 02	1	28	JH 5514 13	5	30
JH 5412 05	10	28	JH 5514 16	1	30
JH 5412 07	8	28	JH 5514 18	6	30
JH 5412 09	20	26	JH 5514 19	3	30
JH 5412 10	16	26	JH 5610 00	8	18
JH 5412 11	12	28	JH 5612 12	8A	20
JH 5412 12	17	26	JH 5612 13	13	20
JH 5412 15	21	26	JH 5614 02	8	20
JH 5412 16	13	28	JH 5614 04	9	20
JH 5412 17	12	26	JH 5614 09	12	20
JH 5412 41	10	28	JH 5810 00	1	42
JH 5510 01	9	16	JH 5810 03	14	42
JH 5510 02	22	16	JH 5810 07	18	4
JH 5512 01	23	16	JH 5810 07	2	42
JH 5512 02	24	16	JH 5810 08	11	42
JH 5512 03	15	16	JH 5810 11	5	42
JH 5512 04	12	16	JH 5810 12	8	42
JH 5512 05	13	16	JH 5810 15	7	42
JH 5512 06	14	16	JH 5810 18	1	42
JH 5512 10	14	16	JH 5810 29	11	42
JH 5512 11	17	16	JH 5810 30	18	4
JH 5514 00	1	30	JH 5810 30	2	42
JH 5514 01	17	30	JH 5812 00	1	34
JH 5514 04	5	30	JH 5812 01	18	34
JH 5514 05	6	30	JH 5812 01	17	36
JH 5514 10	6	30	JH 5812 02	19	34

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JH 5812 02	18	36	JV 4018 02	5	102
JH 5812 06	1	34	JV 5410 06	17	24
JH 5812 07	1	36	JW 1318 07	8	76
JH 5814 01	2	2	JW 5612 06	2	20
JH 5814 10	2A	2	JW 5612 08	3	20
JH 5822 00	6	6	JW 5910 28	5	40
JH 5824 00	9	6	JW 5910 30	3	40
JH 5824 02	1	6	JY 1138 42	10	44
JH 5824 05	8	6	JY 1710 69	4	44
JH 5826 01	12	42	JY 1710 70	9	44
JH 5826 02	10	42	JY 1710 77	1	44
JH 5910 34	2	40	JY 1710 90	5	44
JH 5911 11	13	40	JY 1718 25	13	44
JH 6214 01	4	48	JY 5810 28	10	6
JH 6214 03	4	48	JZ 1112 92	13	50
JK 1210 07	9	80	JZ 1130 42	19	56
JK 1210 08	12	80	JZ 1132 09	4	60
JK 1210 09	10	80	JZ 1132 12	5	60
JL 1812 19	2	92	JZ 1318 75	9	72
JL 1812 59	28	98	JZ 1510 78	4	78
JL 1812 88	15	36	JZ 1510 79	5	78
JL 4014 06	15	102	JZ 1510 84	5	50
JL 4020 04	13B	102	JZ 1612 10	1	90
JL 5412 27	8	26	JZ 1612 24	2	90
JL 5911 48	7	88	JZ 1812 06	17	96
JL 5911 49	14	40	JZ 1813 22	1	92
JN 1812 11	16	64	JZ 1813 38	5	104
JN 3516 04	3	102	JZ 1813 65	6	88

Parts Index



Part Number	Figure No.	Page No.
JZ 1910 10	4	86
JZ 1910 11	3	86
JZ 2328 05	6	106
JZ 2328 14	4	106
JZ 4014 03	15	78
JZ 4018 09	6	102
JZ 4020 00	11	46
JZ 4022 18	8	102
JZ 5410 05	9	24
JZ 5510 10	1	16
JZ 5512 02	3	16
JZ 5512 13	7	16
JZ 5514 15	6	30
JZ 5610 02	7	18
JZ 5710 00	1	32
JZ 5710 01	5	32
KA CA08 20	10	94
KA CF06 55	21	78
KA CF08 30	4	80
KA CF10 50	7	94
KA DC06 20	30	98
KA DC06 25	10	96
KA DD06 12	16	50
KA DD06 14	20	42
KA DD06 14	14	64
KA DD06 18	13	64
KA DD06 18	17	74
KA DD06 20	4	100

Part Number	Figure No.	Page No.
KA DD06 22	8	86
KA DD08 12	4	94
KA DD08 12	2	102
KA DD08 20	6	56
KA DD08 50	6	94
KA DD08 65	4	52
KA DD08 A0	5	52
KA DD10 55	12	40
KA DD10 B5	10	52
KA DF06 08	23	102
KA DF06 10	3	50
KA DF06 10	20	102
KA DF06 12	8	92
KA DF06 14	10	92
KA DF06 30	13	6
KA DF08 50	8	52
KA ED06 14	12	46
KA ED06 20	9	2
KA ED06 20	24	4
KA ED06 20	15	10
KA ED06 20	12A	46
KA ED06 22	11	20
KA ED06 45	11	28
KA EF06 30	7	66
KA EF06 30	21	68
KA EF06 50	13	22
KA EG06 14	3	6
KA ER06 C0	14	22

Parts Index



Part Number	Figure No.	Page No.
KB AB06 08	9	28
KB BC06 08	9	28
KB BM04 08	17	66
KB RA35 10	17	42
KB RA42 16	3	96
KB RA42 32	16	42
KB UC05 25	8	106
KC AA10 08	23	72
KC GA05 05	6	84
KC GA05 05	5	88
KC GA06 06	14	6
KC GC05 05	6	92
KC GD10 10	7	100
KD BA05 12	2	96
KD BA08 18	13	56
KD CB08 16	7	56
KD DB04 08	16	66
KD DB10 18	21	72
KH AA20 15	15	20
KH AA20 15	10	72
KH AA25 20	14	56
KH AA32 35	3	60
KH BA08 28	24	72
KJ AC18 24	12	2
KP AC60 05	22	70
KP BB62 02	26	70
KP BB63 01	6	64
KP BB63 01	18	66

Part Number	Figure No.	Page No.
KP BB63 02	13	68
KP BF62 01	8	22
LA C000 23	15	56
LA C000 24	12	94
LA C000 52	3	46
LA C000 75	3	2
LA C001 21	15	56
LA D000 07	18	92
LA D000 11	17	4
LA D000 37	13	74
LA D000 53	2	104
LA D001 26	4	56
LA D001 38	5	2
LA D001 65	21	98
LA D001 67	5	2
LA E000 05	13	26
LA E000 21	8	78
LA E000 22	10	58
LA E000 40	18	96
LB R000 03	17	92
LB U000 02	26	98
LB U000 23	12	96
LB U000 33	25	36
LB U000 38	9	86
LB U000 38	13	86
LB U000 43	14	58
LB U000 44	14	96
LB U000 46	22	34

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LB U000 46	21	36	PA 5812 21	6	36
LB U000 76	15	94	PA 6210 07	1	38
LC A000 08	12	58	PA 6210 08	7	38
LC B000 05	11	68	PA 6212 03	10	38
LC G000 08	7	106	PD 1716 16	3	44
LD A000 07	14	86	PF 1210 54	27	82
LD A000 07	19	92	PF 1312 20	28	70
LD A000 18	7	92	PF 1610 09	13	78
LD A000 23	4	2	PF 1610 11	26	78
LD A000 25	3	14	PF 1610 15	14	78
LD B000 44	5	20	PF 5412 40	3	28
LJ A000 11	15	2	PF 5514 06	8	30
LJ A000 11	22	36	PF 5514 07	3	26
P No. Req'd	5	36	PF 5514 22	7	30
P No. Req'd	7	36	PF 5514 26	5	30
PA 1112 50	13	58	PF 5514 27	8	30
PA 1130 61	21	56	PF 5514 28	2	30
PA 1132 04	6	60	PF 5810 49	9	42
PA 1510 23	19	78	PF 6214 00	3	48
PA 1612 17	1	90	PF 6214 02	13	24
PA 1812 49	27	98	YJ H010 01	22	98
PA 1910 10	2	86	YJ H010 03	11	88
PA 3510 25	1	46	YJ H010 04	9	88
PA 4016 00	1	102	YJ H010 05	8	88
PA 5610 02	1	18	YJ H010 06	10	88
PA 5612 09	4	20	YJ H010 07	5	96
PA 5810 53	3	42	YJ H010 08	19A	102
PA 5812 05	23	36	YJ H010 09	19B	102

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
YJ H010 10	1	40			
YJ H050 01	5	96			
YJ H050 02	22	98			
YJ H050 03	1	40			
YJ H050 04	9A	88			
YJ H050 05	14	88			
YJ H050 06	15	88			