

Parts Catalogue For GC MAX CNG / RE 600

Bajaj Auto Limited
Akurdi Pune 411 035 India
Tel +91 20 27472851
Fax +91 20 27407385



All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71111450

REV. 01. NOV.11

Foreword

GC MAX CNG
RE 600 CNG

We have pleasure in presenting the provisional Spare Parts Catalogue for 'RE 600 CNG / RE 600 LPG' Vehicles. This catalogue has been specially designed to assist you in selecting the correct parts to maintain your vehicle in best running condition..

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve performance and efficiency of the vehicle, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications/ alterations which are carried out after the issue of this catalogue, will be conveyed to you through our service circulars. You are requested to make necessary corrections in the parts catalogues as per the circulars so as to keep your catalogues up to date. This will ensure the appropriate and speedy delivery of the spare parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Service Department
Akurdi, Pune 411 035 India
Phone : 020-27406278
Fax : 020-27407385
E-mail : service@bajajauto.co.in

Instructions for using the Catalogue

**GC MAX CNG
RE 600 CNG**

1. How to Read the Catalogue : Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

2. How to Order Spare Parts : The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

3. Part Number System: We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

4. Abbreviations : The following abbreviations are used in this catalogue.

assly.	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
o/s.	Over size	Fr	Front
Std.	Standard	L	Length
A/t.	Alternate	Rr	Rear
R.H.	Right hand	Hex.	Hexagonal
L.H.	Left hand	AR	As required

**GC MAX CNG
RE 600 CNG**

No.	Description	Page No.
1	Engine & Crankcase Clutch Side	1,2
2	Crank Case Magneto Side	3
3	Clutch Cover	4,5
4	Cylinder / Piston Assembly	6
5	Crank Shaft Assembly	7
6	Cylinder Head	8
7	Valve	9
8	Cam Shaft And Chain Tensioner	10
9	Clutch Plate Assly	11
10	Clutch Housing Comp	12
11	Clutch Lever Assly	13
12	Main Shaft	14
13	Gear Transmission	15
14	Differential Assembly	16
15	Differential Cover	17
16	Gear Shifter Assly	18
17	Starter motor	19
18	Sector Complete - Revere Gear	20
19	Cowling	21
20	Silencer Assembly	22
21	Fare meter Drive Unit	23
22	Engine Mounting	24,25
23	Magneto Assembly	26
24	Spark Plug And H.T. Coil	27
25	Carburettor (for CNG /LPG Vehicle)	28,29
26	Air Filter Complete	30,31
27	Pump Assly Oil & Oil Strainer	32,33
28	Oil Cooler	34,35
29	Fuel Tank Assly.	36
30	Propeller Shaft SB-GC MAX CNG & SB- RE 600 CNG	37,37A
31	Trailing Arm Assembly	38,39
32	Rear shock Absorber/rear Axle.	40
33	Hand brake and reverse lever	41
34	Fork Assly	42,43
35	Front Shock Absorber& Linkage	44,45
36	Front Mudguard	46
37	Front Brake Drum	47
38	Auto Adjuster brake system	48,49
39	Wheel Cylinder (front)	50
40	Wheel Assembly	51
41	Brake Pedal	52

No.	Description	Page No.
42	Tandem Master Cylinder (antidrive)	53,54
43	Brake Pipe	55
44	Handle Bar Assembly	56,57
45	Handle Bar Assembly	58
46	Control Cables	59
47	Chassis/ Tray	60,61
48	Wind shield & Wiper motor	62
49	Driver cabin	63
50	Doors	64,65
51	Seat Assembly	66
52	Wiring harness	67
53	Dash board Assembly	68,69
54	Head lamp & front indicates Ass	70,71
55	Tail Lamp Assembly	72
56	Switches & horn	73,74
57	Battery & Relay	75
58	Electrical Units	76
59	CNG Cylinder	77
60	Valve of CNG Cylinder	78
61	Hoses	79
62	Relay & Solenoid	80
63	1 St Stage Reduction Unit	81,82
64	Regulator	83,84
65	Filler Valve	85
66	Multi valve (Zero Dag)	86

Pictorial Index

GC MAX CNG
RE 600 CNG

PLATE NO. : 1	PAGE NO.:
ENGINE & CRANKCASE CLUTCH SIDE	1 & 2




PLATE NO. : 3	PAGE NO.:
CLUTCH COVER	4 & 5




PLATE NO. : 5	PAGE NO.:
CRANKSHAFT ASSEMBLY	7




PLATE NO. : 2	PAGE NO.:
CRANKCASE MAGNETO SIDE	3




PLATE NO. : 4	PAGE NO.:
CYLINDER/ PISTON ASSEMBLY	6





PLATE NO. : 6	PAGE NO.:
CYLINDER HEAD	8



Pictorial Index

GC MAX CNG
RE 600 CNG

PLATE NO. : 7	PAGE NO.:
VALVE	9




PLATE NO. : 9	PAGE NO.:
CLUTCH PLATE ASSEMBLY	11




PLATE NO. : 11	PAGE NO.:
CLUTCH LEVER ASSEMBLY	13




PLATE NO. : 8	PAGE NO.:
CAM SHAFT AND CHAIN TANSIONER	10




PLATE NO. : 10	PAGE NO.:
CLUTCH HOUSING COMPLETE	12





PLATE NO. : 12	PAGE NO.:
MAIN SHAFT	14



Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 13 GEAR TRANSMISSION	PAGE NO.: 15
	
PLATE NO. : 15 DIFFERENTIAL COVER	PAGE NO.: 17
	
Plate No.17 STARTER MOTOR.	PAGE NO.: 19
	

PLATE NO. : 14 DIFFERENTIAL ASSEMBLY	PAGE NO.: 16
	
PLATE NO. : 16 GEAR SHIFTER ASSEMBLY	PAGE NO.: 18
	
PLATE NO. : 18 SECTOR COMPLETE- REVERSE GEAR	PAGE NO.: 20
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 19 COWLING	PAGE NO.: 21
	
PLATE NO. : 21 FARE METER DRIVE UNIT	PAGE NO.: 23
	
PLATE NO. : 23 MAGNETO ASSEMBLY	PAGE NO.: 26
	

PLATE NO. : 20 SILENCER ASSEMBLY	PAGE NO.: 22
	
PLATE NO. : 22 ENGINE MOUNTING	PAGE NO.: 24
	
PLATE NO. : 24 SPARK PLUG & H.T COIL	PAGE NO.: 27
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 25 CARBURETTOR	PAGE NO.: 28,29
	
PLATE NO. : 27 PUMP ASSEMBLY OIL & OIL STRAINER	PAGE NO.: 32,33
	
PLATE NO. : 29 Fuel Tank Assly	PAGE NO.: 36
	

PLATE NO. : 26 AIR FILTER COMPLETE	PAGE NO.: 30,31
	
PLATE NO. :28 OIL COOLER	PAGE NO.: 34,35
	
Plate no. 30 Propeller shaft sb-gc max cng	PAGE NO.: 37,37A
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 31 TRAILING ARM ASSEMBLY	PAGE NO.: 38,39
	
Plate No.33 : HAND BRAKE & REVERSE LEVER	
	
PLATE NO. :35 FRONT SHOCK ABSORBER & LINKAGE	PAGE NO.: 44,45
	

PLATE NO. : 32 REAR SHOCK ABSORBER/ REAR AXLE	PAGE NO.: 40
	
PLATE NO. : 34 FORK ASSEMBLY	PAGE NO.: 42,43
	
PLATE NO. : 36 FRONT MUDGUARD	PAGE NO.: 46
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 37 FRONT BRAKE DRUM	PAGE NO.: 47
	
PLATE NO. : 39 WHEEL CYLINDER(FRONT)	PAGE NO.: 50
	
PLATE NO. : 41 BRAKE PEDAL	PAGE NO.: 52
	

PLATE NO. : 38 AUTO ADJUSTER BRAKE SYSTEM	PAGE NO.: 48,49
	
PLATE NO. : 40 WHEEL ASSEMBLY	PAGE NO.: 51
	
PLATE NO. : 42 TANDEM MASTER CYLINDER	PAGE NO.: 53,54
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 43 BRAKE PIPE	PAGE NO.: 55
	
PLATE NO. : 45 HANDLE BAR SLEEVES	PAGE NO.: 58
	
PLATE NO. : 47 CHASSIS/Sray	PAGE NO.: 60,61
	

PLATE NO. : 44 HANDLE BAR ASSEMBLY	PAGE NO.: 56,57
	
PLATE NO. : 46 CONTROL CABLES	PAGE NO.: 59
	
PLATE NO. : 48 WINDSHIELD & WIPER MOTOR	PAGE NO.: 62
	

Pictorial Index

GC MAX CNG
RE 600 CNG







Plate No. 49 DRIVER CABIN	PAGE NO.: 63
	
PLATE NO. : 51 SEAT ASSEMBLY	PAGE NO.: 66
	
PLATE NO. : 53 DASHBOARD ASSEMBLY	PAGE NO.: 68,69
	

PLATE NO. : 50 Doors	PAGE NO.: 64,65
	
PLATE NO. : 52 WIRING HARNESS	PAGE NO.: 67
	
PLATE NO. : 54 HEAD LAMP & FRONT INDICATOR ASSLY	PAGE NO.: 70,71
	

Pictorial Index

GC MAX CNG
RE 600 CNG







PLATE NO. : 55 TAIL LAMP ASSEMBLY	PAGE NO.: 72
	
PLATE NO. : 57 BATTERY & RELAY	PAGE NO.: 75
	
Plate No 59. CNG CYLINDER	PAGE NO.: 77
	

PLATE NO. : 56 SWITCHES & HORN	PAGE NO.: 73,74
	
PLATE NO. : 58 ELECTRICAL UNITS	PAGE NO.: 76
	
PLATE NO. : 60 VALVE OF CNG CYLINDER	PAGE NO.: 78
	

Pictorial Index


**GC MAX CNG
RE 600 CNG**

PLATE NO. : 61 HOSES	PAGE NO.: 79
PLATE NO. : 63 1ST STAGE REDUCTION UNIT	PAGE NO.: 81,82
PLATE NO. : 65 FILLER VALVE	PAGE NO.: 85


Pictorial Index

GC MAX CNG
RE 600 CNG


[illegible]




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RC 5010 01	Engine Assly. comp.	1	--	N.I.
1a	AN 1013 35	Engine Assly. comp.	--	1	N.I.
2	AA 1011 23	Spring plate upper	1	1	
3	AA 1012 49	Spacer pad - hand start	1	1	
4	AA 1011 24	Spring plate lower	1	1	
5	39 0508 09	Rivet	2	2	
6	39 1013 21	'O' ring	1	1	
7	AA 1011 45	Bush starter gear	1	1	
8	39 1719 05	Stud (Long) magneto cover	2	2	
9	39 0682 05	Stud (Short)	2	2	
10	AA 1011 43	Rubber pad	1	1	
11	39 1214 20	Ball bearing	1	1	
12	21 1704 19	Circlip	1	1	
13	03 1003 35	Needle roller bearing	1	1	
14	AA 1010 04	Guide chain metallic	1	1	
15	39 0745 01	Scrow pan cross - M6	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	AB 1010 14	Guide starter gear	1	1	
17	39 1000 06	Hollow dowel pin	2	2	
18	39 1075 04	Bolt flanged small	6	6	
19	39 1676 04	Bolt flanged small	6	6	
20	AA 1013 28	Gasket (Crankcase)	1	1	
21	28 1011 41	Oil plug	1	1	
22	39 1796 11	Plain washer	1	1	
23	AN 1010 70	Crank case clutch side	1	1	
24	39 1630 15	Nut flange	2	2	
24	39 1053 15	Nut - Hexagon with flange :- m14	2	2	
25	AA 1012 21	Tube assly.	1	1	
26	28 1010 80	Rubber bush	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	39 1719 05	Stud	2	2	
2	39 2528 20	Needle roller bearing	1	1	
3	39 1324 20	Ball bearing	1	1	
4	39 1435 20	Needle roller bearing	1	1	
5	Ap 1012 68	oil seal mag side	1	1	
6	39 1716 19	Oil seal (Main Shaft)	1	1	
7	24 1301 05	Ball bearing (Differential)	1	1	
8	39 1917 19	Oil seal	1	1	For starting handle sector gear
9	39 1870 19	Oil seal(Differential)	1	1	
10	39 0427 06	Spring type straight pin	1	1	
11	39 1075 04	Flanged bolt	1	1	
12	39 0747 01	Screw	1	1	
13	AN 1010 33	Crankcase magneto side	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1011 09	Clutch cover	1	1	
2	AA 1013 96	Spring clip	1	1	
3	39 1000 06	Hollow dowel pin	2	2	
4	AN 1010 83	Breather w/ o pipe	1	1	
5	AB 1010 38	Grommet breather	1	1	
6	AA 1016 67	stick dip -clutch cover	1	1	
7	39 1537 21	'O' ring dip stick	1	1	
8	AA 1010 77	Gasket clutch cover	1	1	
9	39 1065 04	Bolt flanged small(40long)	5	5	
10	39 1963 04	Bolt(65 long)	4	4	
11	39 1721 04	Flanged bolt (88 long)	3	3	
12	AA 1013 37	Bracket for clutch cable	1	1	
13	39 1062 04	Bolt flanged small	2	2	
14	AN 1010 83	Breather tube assly	1	1	
15	AA 1014 68	Pipe complete banjo	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	AA 1014 75	Banjo bolt	1	1	
17	39 1727 11	Gasket	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1012 74	Cylinder block piston assembly	1	1	Alt-AN101123
1	AA 1011 69	Bush - clutch cover	1	1	
2	AN 1010 07	Cylinder block comp.	1	1	NS
3	39 1543 21	'O' ring	1	1	
4	39 1000 06	Hollow dowel pin	2	2	
5	AN 1012 59	Piston assly	1	1	
6	AN 1012 75	Piston ring set complete	1	1	Alt-AN 1010 66
7	39 1478 17	Wire clip	2	2	
8	AN 1010 06	Pin piston	1	1	
9	AA 1010 13	Block gasket	1	1	
10	AN 1010 02	Piston	1	1	NS




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1010 72	Crank shaft assly	1	1	AT- An101033
2	AA 1015 89	Primary pinion	1	1	
2	AA 1010 31	Primary pinion	1	1	
3	AA 1014 24	Oil pump drive gear	1	1	For Sintering route
4	31 1011 73	Key woodruff	2	2	
5	39 1927 07	Roller pin	1	1	
6	AA 1011 38	Plunger oil	1	1	
7	AA 1011 39	Spring plunger	1	1	
8	39 1885 15	Nut	1	1	
9	AA 1013 45	Woodruff key	1	1	
10	01 1006 12	Fan disc washer	1	1	
11	39 1053 15	Nut	1	1	
12	AA 1017 07	Damper spring	1	1	From Aug.11
13	AA 1014 99	Kit connecting rod	1	1	N.I.
14	39 2561 20	bearing - ball 6305-crank shaft	2	2	
15	AA 1011 16	sprocket - crankshaft	1	1	
16	39 2154 20	NRB:big end- 3x18x16	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1010 13	Cylinder head assly	1	1	For Cyl. head / Ext.tube
2	59 0500 01	Stud	2	2	
3	AN 1010 12	Head gasket	1	1	
4	28 1011 19	Cam shaft cover	1	1	
5	39 1264 21	'O' ring	2	2	
6	39 1871 05	Stud	2	2	For camshaft cover
7	39 0219 11	Plain washer	2	2	
8	39 1826 12	Spring washer	2	2	
9	39 0834 15	Hex nut	2	2	
10	13 1010 31	Cap	2	2	
11	LJ A000 03	'O' ring insulator	2	2	For carburettor
12	AA 1015 94	Insulator	1	1	
13	39 1283 21	'O' ring	2	2	
14	DD 1015 21	Plain Washer	4	4	
15	LCF 0000 1	nut domed cap m8x1.25xcl10	4	4	
16	AA 1015 77	Inlet manifold	1	1	
17	39 1674 04	Flange bolt	3	3	
18	39 1000 06	Hollow dowel	2	2	
19	28 1011 18	Bush (Cylinder head gasket)	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1010 09	Valve Intake	1	1	
2	AN 1010 10	Valve exhaust	1	1	
3	39 1035 19	Oil Seal	2	2	
4	31 1010 22	Spring engine valve	2	2	
5	31 1010 19	Collet	4	4	
6	31 1010 18	Retainer valve spring	2	2	For Intake For exhaust
7	28 1011 29	Seat spring	2	2	
8	31 1010 20	Rocker arm	2	2	
9	39 1024 01	Screw	2	2	
10	39 0973 15	Nut	2	2	
11	AA 1011 37	Rocker Arm shaft	1	1	
12	13 1010 24	Rocker Arm shaft	1	1	
13	28 1010 57	Stopper	1	1	
14	Dx 1010 74	Screw pan cross	1	1	
15	28 1011 25	Valve guide	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1016 66	assembly cam shaft decomp	1	1	
1a	AA 1016 54	Decompression unit	1	1	
2	28 1011 67	sprocket - camshaft	1	1	
3	39 1062 04	Flange bolt	2	2	
4	AA 1015 65	Guide chain- Non tensioner side	1	1	17.04.2009
5	AA 1015 64	Guide chain- Tensioner side	1	1	17.04.2009
6	AA 1011 35	Pin guide chain	1	1	
7	AA 1016 04	Tensioner assly clinch type	1	1	05.03.2010
7	36 AA40 21	for replacing aa101604	1	1	Kit
7	36 AA40 20	for replacing o ring type tend.	1	1	Kit
8	AN 1310 22	spring tension	1	1	
9	39 2040 21	'O' ring	1	1	
9a	AA 1016 22	Tensioner gasket	1	1	05.03.2010
10	39 1674 04	Flange bolt	2	2	
11	AA 1015 69	Timing chain	1	1	
12	39 1724 20	Ball bearing	1	1	
13	39 0557 17	Circlip	1	1	
14	39 1794 06	pin - dowel	1	1	NI
15	DD 1010 62	Flange bolt	1	1	fig no




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1015 93	Clutch comp	—	1	
1	AA 1014 69	Clutch comp	1	—	
2	AA 1014 70	Clutch plate assly	1	1	
3	AA 1014 71	Wheel clutch	1	1	
4	AA 1014 78	Plate friction	7	7	
4	36 Aa40 16	kit friction plate	1	1	
5	AA 1014 72	Plate clutch	6	6	
6	AA 1014 73	Hub clutch	1	1	
7	AA 1013 64	Spring clutch	6	6	
8	39 0980 04	Hex bolt	6	6	
9	AA 1014 74	Holder clutch	1	1	
10	39 1938 15	Flange Nut	1	1	
11	AN 1010 69	clutch assembly complete 200 cc.	—	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1015 92	Clutch housing assly	—	1	NS NS
1A	AA 1010 63	Clutch housing assly	1	—	
2	AA 1015 90	Gear primary helical	—	1	
2A	AA 1010 06	Gear - primary assembly	1	—	
3	AA 1010 09	Bush gear primary	1	1	
4	AA 1012 07	Housing clutch	1	1	
5	AA 1011 42	Holder	1	1	
6	39 1033 09	Rivet	3	3	
7	AA 1014 00	Spring damper	3	3	
8	AA 1014 01	Spring damper	2	2	
9	31 1011 41	Spring (Beleville washer)	1	1	
10	39 1057 11	Plain washer	1	1	
11	39 2008 11	Plain washer	1	1	
12	AA 1012 13	Collar			




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1014 81	Inner clutch release assly.	1	1	
2	AA 1010 73	Rod push	1	1	
3	AA 1014 79	Release clutch outer	1	1	
4	AA 1014 84	Bellow	1	1	
5	AA 1014 91	Gasket release	1	1	
6	39 2038 04	Hex.socket head bolt	2	2	For mtg. release clutch outer
7	AA 1011 68	Dowel pin (Clutch release)	1	1	
8	30 1011 97	Ball steel	1	1	
9	39 1441 01	Screw set	1	1	
10	39 0793 15	Hex. lock nut	1	1	
11	39 1744 19	Oil seal	1	1	
12	AB 1011 00	Arrestor pin	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1015 67	shaft - main	1	1	
2	AA 1012 95	Drive bush	1	1	
3	AB 1010 67	Cross	1	1	
4	AA 1010 54	Guide stem	1	1	
5	AA 1011 08	Gear selector	1	1	
6	39 0213 11	Plain washer	1	1	
7	28 1010 38	Spring	2	2	
8	11 801 23	Steel ball---main shaft	2	2	
9	AA 1010 61	Cup gear shifter	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1010 50	1st speed gear	1	1	
2	AA 1010 51	2nd speed gear	1	1	
3	AA 1010 52	3rd speed gear	1	1	
4	AA 1010 53	4th speed gear	1	1	
5	15 1011 71	Spacer ring	1	1	
6	21 1007 11	Circlip	2	2	
7	01 1007 11	Shoulder ring No. 1	1	1	
7a	01 1007 12	Shoulder ring No. 2	1	1	Selective
7b	01 1007 13	Shoulder ring No. 3	1	1	
7c	01 1007 14	Shoulder ring No. 4	1	1	
8	AA 1015 55	Reverse control gear	1	1	
8a	AN 1011 05	Reverse control gear	1	1	
9	AA 1010 55	Thrust washer	1	1	
9a	39 2008 11	Washer - plain	1	1	
10	AA 1013 92	Multiple gear shaft	1	1	
11	AA 1015 88	Multiple gear	1	1	
12	AA 1011 56	Thrust washer (M.G.Shaft)	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RE 3310 01	Assembly differential gear	1	1	
1a	AA 1310 02	Differential gear	1	1	
1a	Aa 1310 02	gear - differential :- r.e.	1	1	
1b	AN 1310 03	gear - differential	1	1	
2	AA 1310 33	Satellite gear Hsg. assly	1	1	
2a	AN 1310 04	Satellite gear Hsg. assly	1	1	
3	24 1301 11	Bush bevel gear housing	1	1	
4	22 1310 18	Satellite gear	2	2	
5	22 1310 14	Spacer	2	2	
6	24 1310 32	Bevel gear pin	1	1	
7	24 1301 13	Pin	1	1	
7a	Al 1310 55	cross - differential	1	1	
8b	24 1310 09	gear - bevel	2	2	
9	39 0435 01	Screw hexagon head	1	1	
9a	AN 1310 18	bolt differential - pre coating (gc-cng)	6	6	
10	AA 1010 57	Idler gear	1	1	
10a	AN 1010 25	gear - idler	1	1	
11	AA 1010 58	Thrust washer (Idler gear)	2	2	
12	39 0265 12	Spring washer	6	6	
13	22 1703 45	Lock plate	3	3	
14	22 1710 80	plate - lock	3	3	
15	39 1788 21	ring - o	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1016 14	Differential cover	1	1	Fr.Aug.2011
1a	AN 1310 47	Differential cover	1	1	ns
1b	AA 1310 14	cover differential	1	1	1.06.2009
2	30 1510 39	Bearing ball	1	1	
3	39 1435 20	Needle roller bearing	1	1	
4	24 1301 05	Ball bearing	1	1	
5	24 1310 75	Oil seal	1	1	
6	39 1869 19	Oil seal	1	1	
7	05 1010 51	Breather assly	1	1	
8	05 1510 12	Adjuster with nut	1	1	
9	LA D000 35	Bolt flanged	7	7	
10	39 1759 04	Bolt flanged	1	1	
11	39 1000 06	Hollow dowel pin	2	2	
12	AA 1310 49	Gasket - Differential cover	1	1	
13	AA 1310 17	Dipstick - Differential	1	1	
14	39 1537 21	'O' ring	1	1	
15	35 1010 60	Oil plug	1	1	
16	39 1585 11	Washer oil plug	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1012 61	Sector with lever	1	1	
2	39 0550 11	Plain washer*	1	1	
3	BA 1321 41	Slider block	1	1	
4	05 1010 83	Adjuster with nut*	2	2	
5	39 1046 19	Seal oil	1	1	
6	39 0426 06	Spring type straight pin	1	1	
7	AA 1016 64	Flange (Gear shifter)	1	1	
8	39 1197 04	Bolt socket	2	2	
9	39 0219 11	Plain washer	2	2	
10	39 1826 12	Spring washer	2	2	
11	AA 1010 84	Gasket sector flange	1	1	
12	39 0804 11	Plain washer	2	2	
13	AP 1110 23	Switch neutral	1	1	
13	AA 2010 41	switch - neutral	1	1	
14	AA 1012 58	Cover (Gear shifter)	1	1	
15	39 0197 11	Plain washer	2	2	
16	39 0758 01	Screw pan cross	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1110 92	Starter motor	1	1	
2	39 1791 04	Flange bolt	1	1	
3	AN 1110 06	Support bracket assly.	1	1	
4	39 2234 04	Hex flange bolt	3	3	For Mounting Starter motor
5	39 0198 11	Plain washer	2	2	
6	39 1826 12	Spring washer	2	2	
7	AA 1110 78	Drive end bracket	1	1	
8	AA 1110 79	End cover assly.	1	1	
9	AA 1110 80	Intermediate bracket	1	1	
10	AA 1110 82	Armature assly.	1	1	
11	AA 1110 83	Gear shaft assly.	1	1	
12	AA 1110 85	Brush Box assembly	1	1	
13	AA 1110 87	Circlip/JMP ring	1	1	
14	AA 1110 49	grommet for starter motor bracket	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	39 0426 06	Spring type straight pin	1	1	
2	AN 1310 39	Seal rubber	1	1	
3	AN 1310 22	Tension spring	1	1	
4	AN 1011 04	Sector complete reverse control	1	1	
5	AA 1012 12	Pin for tension spring	1	1	
6	AA 1015 70	Bush sintered	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1016 86	Cowling -clutch side	1	1	
2	39 0834 15	Hex. nut	2	2	
3	39 0219 11	Plain washer	2	2	
4	39 1826 12	Spring washer	2	2	
5	AA 1016 68	Cover fan	1	1	
5a	AA 1016 92	Cover fan	1	1	
6	AA 1012 62	Central cover	1	1	
6a	AF 1010 18	Cover central	1	1	
7	39 0747 01	Bolt	7	7	
8	AA 1013 22	Elbow for fan cover	1	1	
9	AA 1015 12	Internal cowling comp.	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AZ 5910 00	silencer assembly complete	1	1	
2	13 1011 65	Gasket	1	1	
3	39 0798 15	Nut flanged	2	2	
4	39 1829 12	Spring washer	2	2	
5	39 0080 04	Hexagon head bolt	1	1	
6	39 0312 15	Hex. nut	2	2	
7	39 0201 11	Plain washer	4	4	
8	AA 1012 83	Gasket	2	2	
9	AZ 5910 01	Exhaust tube assly.	1	1	
10	39 1552 04	Flanged bolt	3	3	
11	AZ 5910 03	Muffler assly. comp.	1	1	
12	AA 1015 85	Silencer shield comp.	1	1	
13	39 0711 11	Plain washer	8	8	
14	39 0897 04	Bolt	2	2	
15	39 1826 12	Spring washer	3	3	
16	39 0834 15	Hex.nut	3	3	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	39 1587 21	'O' ring	1	1	
2	AA 1310 25	Fare meter housing assly	1	1	Includes item 3, 4 & 5
3	24 1310 07	Plastic bush	1	1	
4	24 1310 08	Plug	1	1	
5	03 1701 09	Pin	1	1	
6	24 1310 02	Faremeter pinion assly	1	1	
6	24 1310 03	WIRE	1	1	
6a	An 1310 26	faremeter gear gc cng	1	1	
7	24 1302 09	Faremeter gear	1	1	
7	An 1310 26	faremeter gear gc cng	1	1	
8	AE 1310 03	Bush	1	1	
9	23 1613 05	Grease nipple	1	1	
10	39 0897 04	Hex bolt	1	1	
11	39 0292 15	Hex nut	1	1	
12	59 0400 29	Hex bolt flange type	3	3	
13	AA 1310 04	Gasket	1	1	
14	AA 2510 01	Faremeter cable comp.	1	1	
15	AA 2510 03	Inner cable (Faremeter)	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	39 2393 04	Hexagon bolt	2	2	For rubber isolator
2	39 0296 15	Hex nut	6	6	
3	39 0201 11	Plain washer	2	2	
4	39 1829 12	Spring washer	2	2	
5	24 1610 03	Hex bolt	1	1	
6	39 0251 11	Plain washer	1	1	
7	21 1604 17	Reinforcement plate	2	2	
8	24 1609 24	Rubber plug	2	2	
9	39 0248 11	Plain washer	6	6	
10	AA 1011 94	Bracket front mounting	1	1	
11	39 0083 04	Bolt	2	2	
12	BA 1021 60	Rubber isolator (GB)	2	2	
13	39 1079 01	Hex screw	4	4	
14	39 0198 11	Plain Washer	4	4	
15	39 0263 12	Spring washer	4	4	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	39 0834 15	Flange nut	4	4	For rubber isolator
17	AZ 1834 00	Engine mounting member rear	1	1	For engine mtg. member
17a	AN 1609 00	assembly engine mtg member rear	1	1	
17a	AN 1610 71	Engine mounting member rear	1	1	
18	39 0944 04	Flange Bolt	2	2	
19	an 1609 09	assy front engine mount	1	1	
20	BH1134 02	isolator rubber	1	1	
21	39 1827 12	washer - spring	2	2	
22	39 0714 11	washer - plain	2	2	
23	39 0467 15	nut - hexagon :- m12 x 1.5	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AZ 3510 00	Magneto assly	1	1	
2	AZ 3510 02	Rotor assly	1	1	
3	AZ 3510 01	Stator assly	1	1	
4	01 1103 67	Screw	3	3	
4	AP 1012 10	Bolt socket	3	3	
5	39 0197 11	Plain wahser	5	5	Stator plate & pulser coil mtg.
6	39 0262 12	Spring washer	5	1	Stator plate & pulser coil mtg.
7	39 0761 01	Screw pan cross	2	2	Pulser coil mounting.
8	AA 1110 52	Pulser coil assly.	1	1	
9	AA 1013 84	Fan	1	1	
10	39 1075 04	Bolt Flange small	3	3	
11	39 1826 12	Spring washer	3	3	
12	AA 1012 20	Grommet for pickup	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AZ 3512 02	H. T. Coil assly C-Core	--	1	
1a	AN 1110 32	Coil assy ht c core with cap 1k	1	--	
2	AA 1110 74	Spark plug cap	1	1	with 1k resistive
3	AA 1110 76	Grommet spark plug cap	1	1	
3a	AA 1110 61	Grommet for spark plug cap	1	1	
4	39 0197 11	Plain washer	2	2	
5	39 0262 12	Spring washer	2	2	
6	39 0408 04	Bolt	2	2	
7	AA 1110 77	Cap (H.T.Cable)	1	1	
8	AA 1110 58	Spark plug	1	1	
9	39 0897 04	Bolt hex head	1	1	For H.T.Coil earthing




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RC 5812 02	Carburetor comp.	1	1	
2	24 1210 69	Pin float	1	1	
3	JA 5812 21	Needle valve assly.	1	1	
4	36 RC00 01	Jet kit	1	1	
5	AF 1214 55	Seal	1	1	
6	24 1210 62	'O' ring flange	1	1	
7	36 RC00 03	Piston valve assly. Kit	1	1	
8	DD 1210 55	Spring throttle valve	1	1	
9	36 AF00 01	Mixing Cap assly. kit	1	1	
10	AF 1214 45	Float	1	1	
11	36 AF00 08	Idling adjuster kit	1	1	
12	DH 1211 18	'O' ring	1	1	
13	CB 1210 46	Screw	3	3	
14	DZ 1210 48	Hose Drain	1	1	
15	AA 1211 37	Vent Hose	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	JA 5813 14	Drain Screw	1	1	
17	AA 1410 46	Clip hose	1	1	
18	JA 5812 36	Air screw kit	1	1	
19	29 1210 81	Plunger assly kit	1	1	
19	24 1210 53	Plunger assly	1	1	
20	AZ 5812 02	Jet needle	1	1	Flange type
21	36 AF00 14	O ring kit	1	1	NI
22	36 AF00 15	Flaot assly kit	1	1	NI
23	24 1213 65	float assembly	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RC 5810 06	Air filter assly	1	1	
2	AL 1210 62	Element air filter	1	1	
3	AL 1210 71	Housing air filter	1	1	
4	AL 1210 68	Seal ring flat	1	1	
5	AL 1210 69	Clamp flat	1	1	
6	AL 1210 70	Cover air filter	1	1	
7	BG 5810 06	Clamp flat	1	1	
8	39 2295 15	Nut flanged	1	1	
9	BB 1210 29	Flap air intake	1	1	
10	AZ 5810 16	Assly. integral duct comp.	1	1	
10	AZ 5810 26	Mixture body	1	1	
11	AM 1210 77	Mixture tube	1	—	
12	AZ 5810 09	Arrester back fire	1	1	
13	AL 1210 75	Tube air intake	1	1	
14	BB 1210 42	Clip	1	1	
15	BA 1220 62	Pipe band	1	1	
16	BG 5814 09	Assly. Intake Z tube	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
17	BG 5814 01	Hose air intake top	1	1	
18	BG 5814 02	Hose air intake bottom	1	1	
19	BG 5814 05	Mesh air intake	1	1	
20	RC 1138 01	assembly bkt air filter mtg	1	1	
20	RC 1110 03	Bracket air filter	1	1	
21	RC 5810 02	Duct A/F inlet	1	1	
	RC 5810 04	Duct A/F inlet completer	1	1	
22	AZ 5810 10	Inlet Restrictor	1	1	
22	24 1216 48	Breather restrictor	1	1	
23	RC 5810 05	Bellow intake elbow comp.	1	1	
23a	AN 1211 84	Bellow - intake elbow	1	1	
24	RC 5814 00	assembly air intake re600 gas	1	1	
25	BG 5814 07	hose air intake - elbow	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1210 60	Pump assly oil	1	1	
2	AA 1210 59	Gear oil pump	1	1	
3	39 1575 11	Plain washer	1	1	
4	39 0855 17	Circlip	1	1	
5	39 1075 04	Flange bolt	1	1	
6	39 1674 04	Flange bolt	2	2	
7	39 1013 21	'O' ring	2	2	
8	39 0999 06	Hollow dowel pin	1	1	
9	AA 1015 48	Oil strainer	1	1	
10	28 1010 22	Cap strainer	1	1	
11	59 2100 22	'O' ring, Strainer	1	1	
12	39 1657 21	'O' ring, Cap	1	1	
13	AA 1210 06	Oil filter assembly	1	1	
14	AN 1210 81	Spring oil filter	1	1	
15	39 1738 21	'O' ring , Oil filter	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	AF 1214 65	Oil filter cover	--	1	
16	AN 1210 85	oil filter cover	1	--	
17	AA 1210 10	Gasket, Oil filter	1	1	
18	39 1673 04	Flange bolt	3	3	
19	AN 1210 82	Rubber seal oil filter	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 1211 35	Oil cooler	1	1	
2	AT 6012 03	Connector oil filter cover	1	1	
3	DK 1012 37	Washer copper	6	6	
4	AA 1016 43	pipe oil hot	1	1	
5	AA 1016 24	pipe oil cool	1	1	
6	AN 1211 11	Connector clutch cover	1	1	
7	39 2484 15	Falnge nut	2	2	
8	39 1553 04	Flange bolt	2	2	
9	39 1573 11	Plain washer	2	2	
10	DG 1410 19	Damper	2	2	
11	30 2110 05	Coller	2	2	
12	39 1672 04	Screw	4	4	
13	DK 1013 40	'O' ring	2	2	
14	AA 1211 36	Guard oil cooler	1	1	
15	39 2697 04	Flange bolt	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	AA 1015 95	Oil cooler mtg. bracket	1	1	
17	39 1972 15	Nut flanged M5X0.8	2	2	
18	39 0697 05	Stud M5X0.8	2	2	
19	AA 1015 97	Oil cooler bracket	1	1	
20	39 0291 15	Hex nut	2	2	
21	AA 1016 28	Bracket for oil cool pipe mtg.	1	1	
22	39 1672 04	Bolt flange	1	1	
23	DK 1012 77	Bracket upper (oil cooler pipe)	1	1	
24	DK 1012 78	Bracket lower (oil cooler pipe)	1	1	
25	39 2345 01	Bolt flanged	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1410 22	Fuel tank assy.	1	1	
2	CS 1410 06	Cap fuel tank	1	1	
3	AN 1410 38	Pipe filter to solenoid	1	—	
3a	RC 1718 01	Pipe filter to solenoid	—	1	
4	AN 1410 32	Sleeve filter to solenoid valve	—	—	
5	AN 1410 39	Pipe solenoid to carburettor	1	—	
5a	RC 1718 02	Pipe solenoid to carburettor	1	—	
6	AN 1410 32	Sleeve solenoid to carburettor	—	—	
7	AN 1410 08	Pipe tank to filter	1	—	
7	RC 1718 00	pipe fuel tank to filter	—	1	
8	AN 1410 28	Sleeve tank to filter	—	—	
9	RA 4026 01	Solenoid petrol	1	1	For vanaz kit
10	AB 1210 19	Fuel filter	1	1	
10	24 1216 52	Fuel filter	1	1	
14	33 1410 07	Clip for pipes	6	6	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
11	39 1680 04	Hex bolt	2	2	
12	39 0295 15	Hex nut	3	3	
13	DG 2010 57	Washer	3	3	
15	BA 1220 03	Clip for pipes	5	5	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BA 1321 71	Flange sg. Hsg. Side	1	--	Solid
2	24 1710 14	Lock washer assembly	2	--	
3	39 0119 04	Bolt	2	--	
4	BA 1321 72	Flange diff. Gear side	1	--	
5	AL 1311 09	Flange wheel side	2	--	
6	AN 1310 48	Assembly shaft propeller-rh	1	--	
7	AN 1310 49	Assembly shaft propeller-lh	1	--	
8	24 1704 25	Pin for propeller shaft	4	--	
9	AL 1710 65	Slider block	8	--	
10	AL 1310 23	Sleeve Rubber buffer	4	--	
11	BB 1311 49	Rubber bellow shaft	2	2	
11a	BG 1412 54	Rubber bellow-diff side	2	2	
12	39 1182 15	Nut	2	2	
13	24 1710 66	Spring clip	2	2	
14	BB 1310 24	Clamp-2	1	1	
15	BB 1310 40	Hose clamp	3	3	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AY1412 00	Flange sg. Hsg. Side	--	1	Solid with hole
2	24 1710 14	Lock washer assembly	--	2	
3	39 0119 04	Bolt	--	2	
4	AY 1412 01	Flange diff. Gear side	--	1	
5	AY 1412 02	Flange wheel side	--	2	
6	AY 1412 07	Assembly shaft propeller-rh	--	1	
7	AY 1412 08	Assembly shaft propeller-lh	--	1	
8	24 1704 25	Pin for propeller shaft	--	4	
9	AL 1710 65	Slider block	--	8	
10	BG 1412 52	Rubber bufferA- gear side	--	2	
10a	BG 1412 53	Rubber bufferB- wheel side	--	2	
11	24 1310 74	Rubber bellow-wheel side	--	2	
11a	BG 1412 54	Rubber bellow-diff side	--	2	
12	39 1182 15	Nut	--	2	
13	24 1710 66	Spring clip	--	2	
14	BB 1310 24	Clamp-2 engine rh side	--	1	Spring clip2
15	BB 1310 40	Clamp Dia 60	--	3	
16	23 1613 05	Grease nipple	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			CNG	LPG	
1	AH 1710 03	Trailing arm assembly LH	---	1	
2	Ah 1710 09	Trailing arm assembly RH	---	1	
3	AA 1710 06	Silent bush	---	4	
4	Aa 1710 08	Distance piece assly	---		
5	Aa 1710 09	Spacer sintered	---	4	
6	01 1003 23	Washer	---	4	
7	59 2000 12	Needle bearing	---	1	
8	22 1710 07	Oil seal	---	2	
9	01 1003 42	Bearing	---	2	
10	39 0342 17	Circlip	---	2	
11	24 1710 24	Oil seal	---	2	
12	AA 1710 11	Pivot pin assembly	---	2	
13	39 0269 12	Spring washer	---	2	
14	39 0303 15	Nut	---	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			CNG	LPG	
1	AL 1710 16	Trailing arm assly comp. LH	1	--	
2	AL 1710 02	Trailing arm assly comp. RH	1	--	
3	AL 1710 11	Silent bush-tr. arm	4	--	
4	AL 1710 12	Distance piece	1	--	
5	AL 1710 62	Spacer ring	4	--	
6	59 2000 12	Needle bearing	2	--	
7	22 1710 07	Oil seal (dia 52)	2	--	
8	AL 1710 10	Ball bearing	2	--	
9	39 0428 17	Internal circlip	2	--	
10	AL 1710 19	Oil seal	2	--	
11	AL 1710 20	Pivot pin assly.	2	--	
12	39 0303 15	Nut	2	--	
13	39 0269 12	Spring washer	2	--	




No.	Part No.	Description	AN	RC	Remarks
1	AL 1710 31	Rear shock absorber	2	-	
1a	BA 1710 09	Rear shock absorber	--	2	
2	AL 1710 36	Mounting rubber with sleeve	2	-	
2	24 1710 49	Mounting rubber with sleeve	--	2	
3	39 0467 15	Hexagon nut	2	2	
4	24 1705 07	Bolt for shock absorber	2	2	
5	39 1827 12	Spring washer	2	2	
6	39 0467 15	Nut	2	2	
7	AL 1710 39	Spring ii- rear suspension (proposal ii)	2	--	
7a	BG 1220 00	Spring rear suspension	--	2	
8	BA 1710 08	Cup washer top side	4	4	
9	BA 1710 07	Rubber bush for cup washer	4	4	
10	24 1711 18	Rear Axle assly.	--	2	
10a	AL 1710 68	Rear Axle assly.	2	--	
11	22 1704 34	Bolt for rear axle	--	8	
11a	AL 1710 25	Bolt for axle	6	---	
12	24 1710 75	Grease nipple	2	2	
13	22 1511 06	Brake drum rear	2	2	
13a	AL 1511 51	Drum - brake :- rear (cast iron)	2	2	




No.	Part No.	Description	AN	RC	Remarks
1	BB 1510 01	Hand brake lever assembly	1	1	
2	AL 1511 03	Operating hand rod	1	1	
3	AL 1511 04	Control lever brake	1	1	
4	AL 1511 05	Spring hand brake	1	1	
5	AL 1511 13	Hand grip	1	1	
6	AL 1511 38	Plate assly	1	1	
7	AT 1610 01	Reverse lever assembly	1	1	
8	24 1910 19	Spring-Return of reverse leve	1	1	
9	AT 1610 02	Reverse shaft assly	1	1	
10	24 1510 61	Lever assly- handbrake control	--	1	
11	22 1505 07	Ratchet	--	1	
12	24 1510 67	Bracket rear cable guide	--	1	
13	24 1510 68	Pin rear cable guide	--	1	
14	24 1510 69	Spacer	--	1	
15	24 1511 45	Lever LH -parking brake	--	1	
16	24 1511 54	Lever RH- parking brake	--	1	
17	24 1511 46	Pivot Pin	--	1	
18	24 1511 47	Split pin	--	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AP 1810 17	Fork assembly	—	1	
1a	AL 1810 37	Fork assembly	1	—	
2	AA 1810 23	Dust cover bottom	—	1	
2a	AL 1810 06	Cover dust lower	1	—	
3	AA 1810 22	Bearing race lower inner	—	1	
3a	AL 1810 04	Bearing race lower	1	—	
4	AB 1810 12	Balls with cage	—	1	
4a	AL 1810 07	balls with cage	1	—	
5	AB 1810 33	Bearing race lower outer	—	1	
5a	AL 1810 03	bearing race - lower :- outer	1	—	
6	24 1810 33	Dust cover top	---	1	
6a	AL 1810 05	Cover - dust :- top	1	---	
7	24 1810 46	Bearing race upper inner	1	1	
8	AB 1810 17	Steel ball with cage upper	1	1	
8a	ALI 1810 09	Steel ball with cage upper	1	—	
9	AB 1810 19	Bearing race upper outer	1	1	
10	AB 1810 20	Spacer washer bearing	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
11	24 1810 47	Lock ring nut	2	2	
12	24 1810 32	Lock - steering With key	1	1	
13	06 1803 03	Spring	1	1	
14	15 1810 32	Cover plate	1	1	
15	15 1810 33	Spring Washer	1	1	
16	15 1810 34	Hammer screw driver	1	1	
17	AL 1810 12	Mud flap	1	1	
17a	AP 1810 13	Mud flap assly	1	1	
18	39 0071 04	Screw	2	2	
19	39 1765 11	Plain washer	2	2	
20	39 1830 12	Spring washer	2	2	
21	24 1614 43	Dust Cover top	1	1	
22	AF 1810 14	Rubber flap for fork	1	1	
23	05 1910 27	Tie blet	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 1710 47	Front shock absorber	2	2	
2	39 1054 11	Plain washer	2	2	
3	39 0789 12	Spring washer	2	2	
4	39 0296 15	Hexagon Nut	2	2	
5	AL 1710 91	Link assly. LH	1	1	
6	AL 1710 93	Link assly.RH	1	1	
6a	Al 1710 95	Bearing sleeve-igus	1	1	
7	AL 1710 48	Bearing sleeve	--	2	Link LH & RH
8	35 1710 40	Grease nipple	--	2	Link LH & RH
9	AB 1710 16	Bush	2	2	
10	AL 1711 81	Bush link pivot	--	2	
11	AL 1710 58	Locking Pin	2	2	Link LH & RH
12	39 1562 21	"O" Ring	--	4	Link LH & RH
12a	39 1564 21	RING - O-igus	4	4	
13	Al 1710 50	Cap Link pivot	--	4	
13a	Al 1711 04	Cap Link pivot	4	4	
14	AL 1710 51	Bolt For Link pivot	2	2	Link LH & RH
15	39 0939 15	Hex nyloc nut	2	2	Link LH & RH




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16a	39 2516 04	Shoulder bolt	2	2	For shock absorber
17	AP 1710 01	Spring Fr. suspension	2	2	
17a	Al 1710 45	Spring (R-4) Fr.susp	2	2	
18	39 0740 11	Washer (Non metallic)	2	2	For Grease nipple
19	AL 1710 67	Rubber Bush	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BG 2312 04	mudguard front	1	1	
2	39 0505 04	Hexagon head Bolt	8	8	
3	39 0219 11	Plain Washer	8	8	
4	05 1612 56	Clip Nut-M6	8	8	
5	39 2484 15	Nut flange	6	6	
6	AL 1613 77	Rear Mudguard	2	-	
6	BG 2312 01	Rear Mudguard	---	2	
7	39 1680 04	Flanged bolt	8	8	
8	AL 1612 26	Mudguard flap	2	2	
9	AL 1612 29	Strip	2	2	
10	39 0071 04	Screw	6	6	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AP 1510 19	Fr. Brake Drum	-	1	
1	AL 1510 93	drum - brake :- front with studs	1	-	
2	AP 1510 02	Front Wheel Axle	-	1	
2a	AL 1510 04	Axle - front wheel	1	-	
3	39 2240 20	Ball Bearing	-	2	
3a	39 2465 20	bearing - ball	2	-	
4	AP 1510 25	Distance piece assly	-	1	
5	39 2464 17	Circlip	1	1	
6	AP 1510 26	Spacer assly.	-	1	
6a	Al 1510 08	Spacer assly.	1	-	
7	AL 1510 89	Special Nut-M16	2	2	
8	AL 1510 11	Collar Nut	2	2	
9	AL 1510 12	Locking Clip	2	2	
10	39 11 80 11	Plain washer	4	4	
11	39 1829 12	Spring washer	4	4	
12	24 1810 47	Hex nut.	4	4	
13	39 2038 04	Hex socket head bolt	2	2	For locking clip
14	39 1079 01	Hex head screw	2	2	For locking clip
15	39 0263 12	Spring washer	2	2	
16	39 1737 19	Oil Seal	2	2	
17	AP 1510 22	Flange Back Plate	-	1	
17a	Al 1510 27	Flange - back plate	1	-	
18	39 2534 04	Bolt Flange M8	4	4	
19	35 1710 33	Nipple - grease - bm6	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 1510 56	Disc complete-shoe holder- RH	1	--	front & LH
1a	AL 1510 29	Disc complete-shoe holder-	2	--	
2	AL 1510 30	Disc shoe holder-	3	--	
3	AL 1510 58	Adj screw sub assy.RH.thd	2	--	
3a	AL 1510 57	Adj screw sub assy.LH.thd	1	--	
4	AL 1511 76	Leading brake shoe comp.	3	--	
4	AL 1510 33	Leading brake shoe comp.	3	--	
5	AL 1511 79	Trailing shoe comp.WHbl	1	--	
5a	AL 1511 78	Trailing shoe comp. WHbl LH	1	--	
5b	AL 1511 77	Trailing shoe comp.WHbl RH	1	--	
6	AL 1510 36	Strut sub assy.LH	2	--	
6a	AL 1510 61	Strut sub assy.RH	1	--	
7	AL 1510 37	Shoe set pin	6	--	
8	AL 1510 38	Rocker	3	--	
9	AL 1510 59	Shoe set spring (trailing) LH	2	--	
9a	AL 1510 60	Shoe set spring (trailing) RH	1	--	
10	AL 1510 40	Shoe set spring (leading)	3	--	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
11	AL 1510 34	Grommet	3	--	
12	AL 1510 41	Shoe return spring	3	--	
13	AL 1510 63	Strut spring RH	2	--	
14	AL 1510 43	Shoe return spring	3	--	
15	AL 1510 55+	Grommet	1	--	
16	AL 1510 27	Flange-back plate Fr.	1	--	
17	39 0268 12	Spring washer	4	--	
18	39 0423 04	Bolt	4	--	
19	AL 1710 53	Lock plate	6	--	




No.	Part No.	Description	Qty. per Veh.		Remarks
			AN	RC	
1	AP 1510 15	Panel assembly front brake	--	1	
1a	24 1511 19	Panel assly LH	--	1	
1b	24 1511 20	Panel assly RH	--	1	
2	AP 1510 17	Back panel assly front	--	1	
2a	24 1511 74	Back plate assly. LH	--	1	
2b	24 1511 78	Back Plate assly. RH	--	1	
3	24 1511 36	Brake shoe assly.	--	3	NS alt kit-
4	24 1511 33	Spring main	--	3	
5	24 1511 34	Spring strut LH holding	--	3	
6	24 1511 35	Spring shoe holding	--	3	
7	24 1511 37	Pin pivot shoe	--	6	
8	24 1511 38	Spring shoe clamping	--	6	
9	24 1511 69	Strut assembly front Complete	--	1	Include fig. 4,5,6,7 & 13
9a	24 1511 76	Strut assembly LH Complete	--	1	Include fig. 4,5,6,7 & 13
9b	24 1511 80	Strut assembly RH Complete	--	1	Include fig. 4,5,6,7 & 13
10	24 1511 70	Ratchet kit (Fr. & LH)	--	1	Include fig. 4,7 & 13
10a	24 1511 81	Ratchet kit (RH)	--	1	Include fig. 4,7 & 13




No.	Part No.	Description	Qty. per Veh.		Remarks
			AN	RC	
11	24 1511 71	Brake shoe kit	--	1	Include fig. 3,11 & 12
12	24 1511 72	Shoe clamp spring kit	--	1	Include fig. 11& 12
13	24 1511 73	Spring kit (Common for Front & LH)	--	1	Include fig. 8,9 & 10
13a	24 1511 82	Spring Kit RH	--	1	Include fig. 8,9 & 10
14	24 1511 68	Auto Adjuster assly front	--	1	Include fig. 5 & 6
14a	24 1511 75	Auto adjuster assly rear LH	--	1	Include fig. 5 & 6
14b	24 1511 79	Auto adjuster assly rear RH	--	1	Include fig. 5 & 6




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	24 1511 63	Wheel Cylinder assly. Front	--	1	
1a	Al 1511 46	Wheel Cylinder	1	--	
2	24 1511 64	Wheel Cylinder assly. Rear	--	1	
2b	Al 1511 44	Wheel cylinder RH	1	--	
3	24 1511 07	Major kit	1	1	N.I
3a	Al 1511 30	Major Kit	1	1	
4	24 1511 14	Minor kit	1	1	N.I
4b	Al 1511 31	Major Kit	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	24 1511 09	Assembly - wheel	--	4	not to service
1a	AL 1510 13	Wheel complete (4.5 x 10")	4	--	
2	24 1511 10	Wheel rim assly	--	4	w/o tube tyre
2a	AL 15101 4	Rim assembly - wheel with central part	4	--	
3	21 1503 07	Tyre 4.00 x 8"	--	4	Not to service
3a	AL 1510 18	Tyre (4.5 X 10")	4	--	
4	21 1503 06	Tube for tyre	4	4	Not to service
4a	AL 1510 19	TUBE	4	4	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AB 1511 26	Brake pedal assembly	--	1	
1a	AL 1511 60	Brake pedal assembly	1	--	
2	AB 1510 14	Spring brake pedal retainer	1	1	
3	39 0208 11	Plain washer	2	2	
4	39 0630 08	Split pin	1	1	
5	39 1702 07	Clevis pin with head	1	1	
6	39 0199 11	Plain washer	1	1	
7	39 0146 08	Split pin	1	1	
8	BA 1910 29	Pad Brake pedal	--	1	
8a	AL 1910 27	Pad - brake pedal	1	--	
8b	AL 1613 44	Bracket assembly: brake pedal mounting.	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AB 1510 63	TMC comp with oil container	1	1	KBX make
1a	AL 1511 71	TMC comp with oil container	1	1	Endurance make
2	AB 1510 69	Push rod complete	1	1	For AB151063
2a	24 1510 87	Push rod complete	1	1	For 24151171
3	39 2205 04	Hexagon nut	3	3	For Ab151063
3a	24 1510 94	Hexagon nut	3	3	For 24151171
4	AB 1510 07	Fork brake actuation	1	1	For Ab151063
4b	24 1510 90	Fork rod push	1	1	For 24151171
5	AB 1511 04	Oil container with cap	1	1	For Ab151063
5a	AB 1510 54	Oil container with cap	1	1	For 24151171
6	AB 1511 05	Cap br. oil reservoir	1	1	For Ab151063
6a	AB 1510 72	Cap br. oil reservoir	1	1	For 24151171
7	24 1510 92	seal-oil supply port	2	2	For Ab151063
8	39 0761 01	Screw pan cross	2	2	For Ab151063
8a	24 1510 93	Screw reservoir mtg.	2	2	For 24151171
9	AB 1510 73	Major kit	1	1	For Ab151063
9a	24 1510 97	Major kit	1	1	For 24151171
10	AB 1510 74	Minor kit	1	1	For Ab151063
10a	24 1510 98	Minor kit	1	1	For 24151171




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
11	39 1224 11	Plain washer	2	2	
12	39 1582 11	Plain washer	2	2	
13	39 1389 04	Hexagon bolt	2	2	For Ab151063
13a	24 1510 95	Hexagon bolt	2	2	For 24151171
14	BA 1611 34	Bracket master cylinder mtg.	1	1	
14	AL 1511 55	bracket assembly tmc mtg.	1	1	
15	39 0200 11	Plain washer	3	3	
16	39 0265 12	Plain washer	3	3	
17	39 0310 15	Hex nut	3	3	
18	24 1510 79	Boot ring	1	1	For 24151171




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 1511 69	Single piece brake pipe	2	2	
2	24 1504 06	Clamp for sleeve	2	2	
3	24 1504 07	Sleeve	2	2	
4	22 1504 35	Hex. bolt	2	2	
5	AL 1511 86	Hose flexible front brake	1	1	
6	AB 1510 49	Banjo bolt	4	4	
7	21 1504 22	Packing - copper washer	12	12	
8	AL 1511 70	Pipe brake assly. front	1	1	
8a	AL 1511 88	Pipe assy front brake	1	1	
9	AL 1511 87	Clamp brake hose	1	1	NI




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AP 1610 48	Handle Bar Body	1	1	
2	22 1810 58	Steering lock plate	1	1	
3	39 1830 12	Spring washer	2	2	
4	39 1379 04	Hex head screw	2	2	
5	21 1802 07	Lining -Steering lock plate	2	2	
6	39 0192 10	Eyelet rivet	2	2	
7	39 1377 04	Hex. bolt with collar	1	1	
8	39 0201 11	Plain washer	2	2	
9	39 1829 12	Spring washer	1	1	
10	39 0296 15	Hex nut	1	1	
11	AB 1810 22	Lower plate assly	1	1	
11a	Ab 1810 23	Upper plate assembly	1	1	
12	24 1810 51	Upper plate assembly	1	1	
13	39 2295 15	Flange nut	2	2	
14	21 1803 07	Knob	1	1	
15	39 0198 11	Plain washer	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	21 1803 08	Spring	1	1	
17	AP 1610 47	Handle bar top cover	1	1	
18	KU BC04 10	Screw	3	3	
18	39 2592 01	Screw pan cross -m4	3	3	
19	39 2451 11	Plain Washer	3	3	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	24 1910 96	Tube assembly gear control	1	1	
1	Bg 1510 01	assembly gear control tube	1	1	
1	24 1810 74	assembly gear control tube	1	1	
2	24 1911 00	Pulley gear control	1	1	
3	24 1910 98	Tube assly. comp. - throtl.	1	1	
4	24 1911 01	Pulley gas control	1	1	
5	CM 1910 49	Spring clip	1	1	For fitment of pulley control
6	06 1910 89	Hand grip	2	2	
7	AA 1910 32	Clutch lever	1	1	
8	24 1911 05	Special screw	1	1	
9	01 1902 05	Spring washer	1	1	
9	31 902 04	Plain washer	1	1	
10	03 1902 06	Plain washer	1	1	
11	39 0326 15	Nylock nut	1	1	
12	24 1910 99	Ring gear indicator	1	1	
13	LH C000 01	Spring clip	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	An 1910 32	Choke cable comp	1	—	
1a	AZ 1612 01	Choke cable comp	—	1	
2	AZ 1612 00	Cable accelerator	—	1	
2a	AN 1910 33	Cable accelerator	1	--	
3	AZ 1612 03	Cable clutch	--	1	
3a	AN 1910 28	Cable clutch	1	--	
4	BA 1910 51	Cable complete - gear :- white	1	1	white
5	BA 1910 52	Cable complete - gear :- black	1	1	black
6	BG 1318 02	Cable Assly. H/Br. Front	--	1	
7	24 1510 59	Cable Assly. H/Br. Rear LH	--	1	
7a	AL 1511 40	Cable - LH :- brake - hand	1	--	
7b	24 1510 60	Cable Assly. H/Br. Rear RH	--	1	
7c	AL 1511 41	Cable - RH :- hand brake	1	--	
8	AZ 1612 02	Cable reverse	1	1	
8a	AN 1910 37	Cable reverse fixed end	1	1	
9	AL 1910 39	Knob	1	1	
10	39 0291 15	Nut	1	1	
11	AL 1910 26	Release Spring	1	1	
12	Af 1213 28	bellow for accelerator cable	1	1	
13	BA 1910 50	Cable - inner :- gear	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1611 15	frame assembly	1	--	
1a	RC 1110 01	frame assembly	—	1	
2	AL1614 84	GC Max Lable	1	—	
3	24 1613 56	CNG Lable	—	1	
4	BH 2326 00	Lock Set	--	1	(N.I.)
5	AN 1810 09	Lock set GC CNG BSIII	1	—	
6	AZ 1610 00	Reserve Lever	—	1	
7	AZ 1610 01	Reserve spring	1	—	
8	AP 1610 35	Bush reverse lever	1	1	
9	24 1614 46	Water bottle holder	1	1	
10	24 1614 24	Matting front	1	1	NI
11	BG 2210 00	Tray low deck	--	1	
12	AL 2412 36	Tray assembly wider low deck	1	—	ALT-52AL0237
13	AL 2412 28	Tray wider high deck	1	—	ALT-52AL0253 NS
14	AL 2412 34	Assembly rear door-whd	1	—	
15	AL 2410 40	Door - engine for tray	1	—	
16	BG 2210 01	Door - engine for tray	--	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
17	AL1610 69	Packing between chassis & tray - frame	6	6	
18	AL 1416 84	Grey Lable GC Max	1	—	
19	30 2010 69	Reflector reflex	1	1	
20	AL 1511 04	Lever - control :- hand brake	1	1	
21	AL 1511 05	Spring - hand brake	1	1	
22	AL 1511 13	Grip - hand :- hand brake	1	—	
23	AL 1511 38	Plate assembly - hand brake	1	—	
24	BB 1610 37	Grill complete rear: swivel	1	—	NI
25	BB 1610 49	Rest: heel :- clutch side	1	—	
26	BB 1610 50	Rest : heel :- brake side	1	—	
27	AL 1511 68	Pad: heel rest	4	4	
28	BG 2330 02	Emblem bajaj re for scudo	1	1	
29	24 2312 45	Knob for rear door	2	—	
30	AF 1610 40	Label - CNG as per `delhi	1	1	
31	AL 2412 27	Pipe structure wider high deck	1	—	Ni
32	AS 2200 02	Fire extinguisher with bkt	1	--	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BG 2010 01	Windshield assly.	--	1	ALT
1a	AL 2410 25	Windshield assly.	1	-	ALT-52AL0278
2	AA 2310 22	One piece glass(w.s)	1	1	
3	AA 2310 26	Beading W/Shield Glass	1	1	
4	AL 2412 85	Packing Shield / windshield	1	1	
5	AL 2410 23	Wiper arm blade assly.	1	1	
6	AL 2411 84	Joint plate L.H.+	1	1	
6a	AL 2411 85	Joint plate R.H.	1	1	
7	CI 2010 23	wiper motor(pigtail & coupler)	1	1	
7a	AL 2010 22	Wiper motor	1	--	
8	AL 1613 83	cover wiper motor	1	1	
9	AL 2410 79	Brkt Assly Wiper motor	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BG 2316 02	Mirror assly. RH	--	1	
1a	AL 2210 27	Mirror assembly rear view RH	1	--	
2	BG 2316 01	Mirror assly. LH	1	1	
2a	AL I2210 26	Mirror assembly rear view LH	1	--	
3	BG 2010 00	Driver cabin assly.	1	1	
4	AL 2414 06	Cabin assy with door-driver	1	1	
5	AL 2010 73	Cabin light assembly	1	1	
6	AL 2010 88	Lens for cabin light	1	1	
7	AL 2010 83	Lamp 12V (capless type)	1	1	
8	AL 2410 37	Packing Upper cabin	1	1	
9	22 1612 21	Front number plate	1	1	
10	BG 1138 08	Box for horn & number plate mtg	1	1	
11	39 0078 04	Flange bolt	2	2	for no. Plate
12	39 1680 04	Flange bolt	2	2	for bracket
13	22 2707 09	driver back glass	1	1	
14	AL 2410 65	Beading	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 2412 58	Door assly LH	1	1	
2	AL 2411 42	Door hinge link windshield	2	2	
3	AL 2411 43	Door hinge link scudo	2	2	
4	AL 2411 44	Door hinge pin	4	4	
5	BG 2422 03	latch mechanism lh	1	1	
5a	AL 2413 44	latch striker door	1	1	
6	AL 2411 49	Door glass lock assy	2	2	
7	AL 2412 08	Fixed window glass	-	1	
8	AL 2412 81	Swelling glass assly RH	1	1	
8	AL 2412 82	Swelling glass assly LH	1	1	
9	AL 2411 86	Strip door limiting	1	1	
10	AL 2411 98	Beading for fixed glass	1	1	
11	AL 2412 57	door assy comp RH	1	1	
12	AL 2412 19	Door lock assy RH	1	1	
12a	BG 2422 04	latch mechanism RH	1	--	
13	AL 1810 32	Lock barral LH	--	1	
13a	AL 2412 71	Lock barral LH	--	1	
14	AL 2411 99	Beading for swelling glass	1	1	Front LH
14a	AL 2412 12	Beading for swelling glass	1	1	Front RH
15	AL 2412 00	Beading for swelling glass	2	2	Rear
16	39 0407 01	Screw	2	2	
17	AL 2412 53	Handle assly. LH	1	1	
18	AL 2412 55	Handle assly. RH	1	1	
19	39 1348 01	Screw	8	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
20	39 2706 04	Hex bolts	4	4	
21	39 2479 15	Flange nuts	4	4	
22	AL 2411 88	Bracket	4	4	
23	39 0963 15	Dom nut	4	4	
24	39 0898 04	Flange bolt	4	4	
25	39 0292 15	Flange nut	4	4	
26	AL 2411 90	Nylon washer	12	12	
27	AL 2412 01	Cover door lock LH	1	1	
27a	AL 2412 02	Cover door lock RH	1	1	
28	39 1581 15	Flange nut	10	10	
29	39 0761 01	Screw	4	4	
30	39 1781 01	Screw	4	4	
31	Al 2411 97	Beading Door	2	2	N.I.
32	AL 2411 93	Washer	8	8	
33	AL 2412 16	Block assly comp. LH	1	1	
34	AL 2412 17	Block assly comp. RH	1	1	
35	39 1943 04	Flange bolt	4	4	
36	39 0804 11	Plain Washer	4	4	
37	AL 2411 92	Bolt	2	2	
38	39 1508 11	Plain washer	4	4	
39	AL 2411 89	Spring	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BB 2110 12	Driver seat	--	1	
1a	AN 2110 01	Driver seat	1	--	
2	BG 1910 01	Driver seat Frame	--	1	
2b	AL 2110 05	frame - driver seat	1	--	
3	24 2311 46	Clip	2	2	
4	39 1972 15	Flanged nut	9	9	
5	39 1946 04	Bolt Flange	2	2	
6	39 0230 11	Plain washer	4	4	
7	39 0265 12	Spring washer	1	1	
8	BG 1910 03	backrest driver	--	1	
8a	BG 1910 02	Driver backrest	1	--	
9	BB 2210 04	Jack assly.	1	1	
10	39 0119 04	Bolt hex head	2	2	
11	39 1224 11	Plain washer	2	2	
12	39 0788 12	Spring washer	2	2	
13	39 0294 15	Hex nut	2	2	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 2010 24	Harness wiring combined BSIII	1	--	
2	RC 4022 02	Harness wiring(front)(bifuel)	--	1	
3	RC 4022 03	Harness wiring(chassis)(bifuel)	--	1	
4	RB 4022 02	Cable assembly	--	1	
5	AN 2010 25	Cable for battery GC CNG BSIII	1	--	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RC 4024 01	Instrument cluster	-	1	
1a	AT 4024 01	Cluster instrument with lamp ref	1	-	
2	AL 1910 28	Screw	3	3	
3	30 2010 84	Lamp 12V 3W	4	4	
4	AL 1910 19	Cable complete - speedometer	-	1	
4a	AN 1910 20	Cable complete : speedometer	1	-	
5	AL 1910 20	Cable - speedometer - inner	-	1	
5a	AL 1910 21	Cable - speedometer - inner	1	-	
6	CE 1810 15	Clip Nut	15	15	
7	AL 1613 84	Dashboard assly plastic	1	1	
8	AL 1613 85	Upper Trim	1	1	
9	AL 1613 79	Switch cover	-	1	
9	AN 1610 86	cover switch	1	-	
10	AL 1613 81	Cover middle portion	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
11	AL 1613 61	Lock tool box	1	1	With Key
12	AL 1611 72	Lock Stereo lid	1	1	
13	39 0663 01	Slotted ch head screw	4	4	
14	39 0291 15	Hexagon nut	4	4	
15	39 0012 01	Cheese head screw	16	16	
16	39 0242 11	Plain washer	26	26	For mtg. of Dash Board
17	35 1610 60	Clip nut	8	8	
18	AL 1910 29	Sealing ring	1	1	
19	AL 2011 00	Charger mobile	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 2010 65	H/L Assly. LH	1	1	
1a	AL 2010 66	H/L Assly. RH	1	1	
2	CI 2010 23	Lamp 12V-35/35w-HS1	2	2	
3	AL 2010 32	Spring - Head lamp Mtg	6	6	
4	39 0758 01	Screw pan cross-M5	6	6	
5	39 1839 11	Plain washer	14	14	
6	AL 2010 43	Cable assly.-Front Light LH	1	1	
7	AL 2010 44	Cable assly.-Front Light RH	1	1	
8	AP 1210 66	Rubber cap	2	2	
9	CL 2010 22	Cable assly.	2	2	
10	AL 2010 51	Ind assly. Front LH/ Lamp	1	1	
10a	AL 2010 17	Ind assly. Front RH/ Lamp	1	1	
11	06 2010 82	Lamp 12V 5W	2	2	
12	06 2010 83	Lamp 12V 10W	2	2	
13	39 0921 01	Screw pan cross	8	8	
14	Bg 1138 02	Head lamp-Blinker Hsg LH	-	1	
14a	AL 1615 65	Housing headlamp-blinker-lh	1	--	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
14b	BG 1138 03	Head lamp-Blinker Hsg RH	-	1	
14c	AL 1615 67	housing headlamp-blinker-rh	1	-	
15	39 1698 01	Screw pan	4	4	
16	39 0242 11	Plain washer	8	8	
17	AL 1611 91	Spacer	4	4	
18	39 0830 01	Screw Pan-M5	4	4	
19	35 1610 60	Clip Nut	12	12	
20	AL 1611 80	Clip Nut	8	8	
21	AP 1610 80	Flap assy LH headlamp housing	-	1	
21a	AP 2010 66	rubber cap new head lights	1	-	
22	AP 1610 82	Flap assy RH headlamp housing	-	1	
22a	AP 2010 66	rubber cap new head lights	-	1	
23	AL 1615 87	Beading headlamp housing	2	-	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AA 2012 25	Tail light LH with Lamp	1	1	
1a	AA 2012 26	Tail light RH with lamp	1	1	
2	AA 2011 61	Lens tail lamp LH	1	1	
2a	AA 2011 70	Lens tail lamp RH	1	1	
3	AC 2010 21	Packing for tail light LH & RH	2	2	
4	06 2010 83	Lamp 12v 10W	4	4	
5	62 010 82	Lamp 12V 21/5W	2	2	
5a	AA 2012 27	Lamp 12V 18/5W	2	2	
6	AA 2010 90	Mounting bracket tail light RH	1	1	
7	39 0798 15	Flange Nut	8	8	
8	AL 1611 52	No. Plate	1	1	
8	22 1612 21	plate -number(dimen.=security no. Plate)	1	1	
9	39 0817 15	Flange nut	2	2	
10	39 1680 04	Flanged bolt	2	2	
10a	AA 2011 59	lamp (light) assembly - tail :- lh	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AL 2010 61	Control switch RH	1	1	
2	AL 2010 87	Switch cover RH	1	1	
3	AL 2010 62	Screw	4	4	
4	AL 2010 60	Control switch LH	1	1	
5	AL 2010 86	Switch cover LH	1	1	
6	BG 4014 00	Ignition parking switch(st sw	--	1	With key
6	AN 2010 30	Ignition parking switch(st sw	1	--	
7	AP 2010 12	Label parking OFF/ON switch	1	1	
8	AP 2010 99	Horn (DC)	--	1	
8a	AP 2010 93	Horn (DC)	1	1	
9	39 2383 15	Screw pan	2	2	
10	39 0197 11	Plain washer	2	2	
11	39 0262 12	Spring washer	2	2	
12	AF 2010 94	Brake switch	1	1	
13	AP 2010 58	Cabin light assembly	1	1	
14	24 2014 16	Cable assly cabin light	1	1	
15	AF 2010 53	Switch G O P selection	1	1	
15	AL 2010 31	Switch (2 position)	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
16	Ab 2010 76	Relay Flasher	1	1	
17	AB 2010 77	Hazard Switch	1	1	
18	AF 2011 46	Starter switch	1	1	
19	24 2014 20	Cable Reverse switch	1	1	
20	24 2014 42	Indicator assly CNG	1	--	
21	BB 2010 23	Beeper - d/c operation	1	1	
22	AT 2010 35	Button - start	1	1	
23	AT 4014 02	Oil pressure switch	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	BA 2010 01	Battery 12V 32Ah	1	1	
2	BG 1138 05	Battery base tray	--	1	
2a	AN 1610 48	liner: battery base tray	1	--	
3	BB 2010 30	Lock battery	1	1	
4	AN 1610 74	Clamp Assly	1	1	
5	39 0817 15	Nut	2	2	
6	AN 1610 75	Tie rod	1	1	
7	AI 2010 12	Relay head light	1	1	
8	AP 2010 37	Plate Electrical unit Front	1	1	
9	AN 2010 12	Fuse box assembly	1	1	
10	AK 2010 12	Fuse blade type 10 Amp	6	6	
10a	DG 2010 84	Fuse :- 30 amps (blade type)	1	1	
11	39 1681 04	Flange Bolt	2	2	
12	BA 1610 29	Packing Battery	--	1	
13	39 2208 04	Flanged bolt	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AF 2010 36	Assly. regulator	1	1	
2	39 0198 11	Plain washer	8	8	
3	39 0263 12	Spring washer	8	8	
4	39 0291 15	Hex nut	5	5	
5	AB 2010 76	Assembly D.C.Flasher	1	1	
6	AA 2010 12	Starter relay	1	1	
7	AN 1110 14	DC ignitor and gas controller	1	1	
7	AN 11 0 07	cdi digitl start intlck(bifuel ign advan	--	1	
8	AL 2010 12	Relay head Lamp	1	1	
9	AA 1610 60	Plate assly.mtg. electrical units	1	1	
10	39 0944 04	Bolt	3	3	
11	AA 1610 80	Cover - plate electrical unit	1	1	
12	AA 1610 81	Packing - cover	1	1	
13	39 0239 11	Plain washer	2	2	
14	39 0732 12	Spring washer	2	2	
15	39 0696 01	Slotted ch.hd.screw	2	2	
16	AF 2010 01	RELAY	1	1	NI




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AN 1610 06	Cylinder strap	1	—	
1a	AF 1610 98	Cylinder strap	—	1	
2	AN 1610 08	Packing strap upper	1	—	
3	AN 1610 09	Packing strap lower	1	—	
3a	AF 1611 00	Packing lower for gas cylinder	—	1	
4	AF 1410 59	Cylinder EKC dia 267 30 ltrs w/o valve	1	—	
4a	AN 1410 41	Cylinder cng EKC dia 316 wc40l	1	—	
5	39 0296 15	Hex. nut	4	4	For clamping of cylinder
6	59 1500 12	Nut Nyloc	4	4	
7	39 0201 11	Plain washer	4	4	
8	AF 1610 59	Pin CNG cylinder strap	2	2	
9	24 1410 91	Clip spring	2	2	
10	AN 1611 04	Beading for strap	1	—	NI
10a	AF 1610 97	Beading for strap	—	1	NI




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AF 1410 08	Hand wheel	1	1	
2	AF 1410 30	Valve for CNG	1	1	
3	AFi 2010 89	switch	1	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	24 1215 00	Hose HPR to solenoid	1	1	
2	24 1214 98	Hose solenoid to LPR	1	1	
3	AZ 1720 05	Low pressure hose pipe	1	1	From LPR to Mixture
3a	AN 1211 89	hose low pressure cng	1	1	
4	24 1213 54	Hose clip	4	4	
5	AF 1210 12	Washer	4	4	
6	RC 1110 02	Bracket LPR mounting	1	1	
7	JS 1720 14	Flange screw	2	2	
8	JS 1138 01	Bush LPR	2	2	
9	JS 1138 02	Washer	2	2	
10	DG 1410 19	Damper	2	2	
11	24 1614 23	Guard LPR breather	1	1	
12	AM 1211 05	Assly flex. Hose -1	--	1	Filler to MFV
13	24 1212 44	Washer	--	2	
14	24 1214 34	Assly. hose MFV to LPR	--	1	
15	RA 1720 06	Hose Regulator to mixture	--	1	
16	RA 4026 01	Solenoid Petrol	1	--	
	24 1216 56	Solenoid Petrol	--	1	




No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AF 2010 67	Solenoid -CNG paper filter	1	1	
2	AF 1213 27	Lock Nut	1	1	
3	AF 1213 16	Drain plug	1	1	
4	AF 1213 17	'O' ring	1	1	
5	AF 121319	Paper filter	1	1	
6	AF121320	'O' ring	1	1	
7	AF121322	'O' ring	1	1	
8	AF121323	Bolt	1	1	
9	AF121325	'O' ring	1	1	
10	AF121326	Plunger assembly	1	1	



No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AF 1210 04	Refueling Adaptor	1	1	
2	AF 1210 23	'O' ring	2	2	
3	AF 1210 24	String	1	1	
4	AF 1210 18	Dust plug	1	1	
5	AF 1210 25	Washer	1	1	
6	AF 1210 26	'O' ring	1	1	
7	AF 1210 27	1st stage Seat (NRV) sub assly.	1	1	
8	AF 1210 28	Spring	1	1	
9	24 2013 33	Pressure Gauge	1	1	
10	AF 1210 29	Washer	1	1	
11	AF 1210 30	Washer	1	1	
12	24 1214 56	Connector	1	1	
13	AF 1210 32	'O' ring	2	1	
14	AF 1210 34	Spring	1	1	
15	AF 1211 26	Piston assly.	1	1	
16	AF 1210 36	'O' ring	2	1	
17	AF 1211 25	1st stage Cylinder (SRV) sub assly.	1	1	



No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
17	AF 1210 37	Cylinder - reduction unit:3wh-4s-re-cng	1	1	
18	AF 1210 38	Lock nut	1	1	
19	AF 1210 44	Mounting plate	1	1	
20	AF 1210 45	Philips screw	2	2	
21	AF 2010 10	Micro switch	1	1	
22	AF 1210 46	Philips screw	2	2	
23	AF 1211 04	'O' ring	1	1	
24	AF 1211 05	Retainer	1	1	
25	AF 1211 06	'O' ring	1	1	
26	AF 1211 07	Filter	1	1	
27	AF 1211 08	Washer	1	1	
28	AF 1210 84	Pad	1	1	
29	24 1214 13	First stage reduction unit	1	1	
29	AN 1212 03	assembly 1st stage red. Unit	1	1	
30	AF 1210 41	Pad holder	1	1	
31	AF 1210 39	Relief valve spring	1	1	
32	AF 1210 40	Adjusting screw	1	1	
33	AN 1212 03	assembly 1st stage red. Unit	1	1	NI



No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	RC 1720 03	Regulator cng two stage	1	--	
	RA 1720 05	Regulator LPG	--	1	
2	JS 1720 15	Diaphragm-Sub assly.	1	1	
3	JS 1720 38	Washer	4	4	
4	JS 1720 36	Lever	1	1	
5	24 1212 99	Pin Lever	2	2	
6	AZ 1720 07	Seat	1	1	
7	JS 1720 35	Guide spring	1	1	
8	24 1213 04	Spring	1	1	
9	24 1213 06	Rubber washer	1	1	
10	JS 1720 23	Diaphragm	1	1	
11	JS 1720 27	Spring	--	1	
	24 1215 04	Spring	1	--	
12	24 1213 12	Lever sub assly	1	1	
13	24 1213 13	Seat	1	1	
14	24 1213 14	Rubber washer	1	1	
15	24 1213 15	Washer copper	1	1	
16	24 1215 05	Connector inlet	1	--	


RE 445M
RE 600

Part No.	Figure No.	Page No.
AA 1014 69	1a	11
AA 1014 70	2	11
AA 1014 71	3	11
AA 1014 72	5	11
AA 1014 73	6	11
AA 1014 74	9	11
AA 1014 75	16	5
AA 1014 78	4	11
AA 1014 79	3	13
AA 1014 81	1	13
AA 1014 84	4	13
AA 1014 91	5	13
AA 1014 99	13	7
AA 1015 12	9	21
AA 1015 48	9	32
AA 1015 55	8	15
AA 1015 64	5	10
AA 1015 65	4	10
AA 1015 67	1	14
AA 1015 69	11	10
AA 1015 70	6	20
AA 1015 77	16	8
AA 1015 85	12	22
AA 1015 88	11	15
AA 1015 89	2	7
AA 1015 90	2	12
AA 1015 92	1	12
AA 1015 93	1	11
AA 1015 94	12	8
AA 1015 95	16	35
AA 1015 97	19	35
AA 1016 04	7	10
AA 1016 14	1	17
AA 1016 22	9a	10
AA 1016 24	5	34


RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.



No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
17	JS 1720 29	Screw	8	8	
18	24 1213 27	Plug	1	1	
19	24 1213 21	'O' ring	1	1	
20	JS 1720 32	Body -Flow control	--	--	
21	JS 1720 30	Screw flow control	--	1	
22	JS 1720 20	Idling screw	1	1	
23	59 2100 17	'O' Ring	1	1	
24	AF 1211 06	'O' Ring	1	1	
25	AZ 1720 09	Breather hose	1	1	
26	JS 1720 33	Clamp	1	1	
27	AF 1211 04	'O' Ring	1	1	
28	JS 1720 18	Plug	1	1	
29	JS 1720 26	Breather -I	1	1	
30	AM 1210 91	Breather -II	1	1	
31	AM 121089	'O' Ring	1	1	
32	JS 1720 19	Flange screw	12	12	
33	AF 1210 70	Cheese headed screw	4	4	



No.	Part No.	Description	Qty/Veh.		Remarks
			AN	RC	
1	AU 1720 02	Multi valve - Assly vanaz	1	1	
2	36 2440 05	Spindle with pad	1	1	
3	AF 1210 69	Washer	1	1	
4	24 1212 66	Retainer - MV	1	1	
5	59 2100 13	'O' Ring	2	2	
6	24 1212 67	Knob - MFV	1	1	
7	59 1700 07	Criclip- External	1	1	
8	AU 1720 65	'O' Ring - MFV	1	1	
9	24 1212 68	Filter	1	1	
10	59 2100 15	'O' ring M-V Solenoid	1	1	
11	36 2440 04	NRV sub assly	1	1	
12	24 1212 83	'O' Ring	1	1	
13	AU 1720 52	Plug fusible	1	1	
14	AU 1720 74	Allen Screw	6	6	For mtg. Multivalve on cylinder
15	24 1212 90	Spring Conical	1	1	

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
01 1003 23	6	38	21 1503 07	3	51
01 1003 42	9	38	21 1504 22	7	55
01 1006 12	10	7	21 1604 17	7	24
01 1007 11	7	15	21 1704 19	12	1
01 1007 12	7a	15	21 1704 19	12	2
01 1007 13	7b	15	21 1802 07	5	56
01 1007 14	7c	15	21 1803 07	14	56
01 1902 05	9	58	21 1803 08	16	57
03 1003 35	13	1	22 1310 14	5	16
03 1003 35	13	2	22 1310 18	4	16
03 1701 09	5	23	22 1504 35	4	55
03 1902 06	10	58	22 1505 07	11	41
05 1010 51	7	17	22 1511 06	13	40
05 1010 83	4	18	22 1612 21	9	63
05 1510 12	8	17	22 1612 21	8	72
05 1612 56	4	46	22 1703 45	13	16
05 1910 27	23	43	22 1704 34	11	40
06 1803 03	13	43	22 1710 07	8	38
06 2010 82	5	72	22 1710 07	7	39
06 1910 89	6	58	22 1710 80	14	16
06 2010 82	11	70	22 1810 58	2	56
06 2010 83	12	70	22 2707 09	13	63
06 2010 83	4	72	23 1613 05	9	23
011 103 67	4	26	23 1613 05	16	37a
011 605 09	5a	27	24 1210 53	19	29
011 801 23	8	14	24 1210 62	6	28
13 1010 24	12	9	24 1210 69	2	28
13 1010 31	10	8	24 1212 44	13	79
13 1011 65	2	22	24 1212 66	4	85
15 1011 71	5	15	24 1212 67	6	85
15 1810 32	14	43	24 1212 68	9	85
15 1810 33	15	43	24 1212 83	12	85
15 1810 34	16	43	24 1212 90	15	85
21 1007 11	6	15	24 1213 21	19	84
21 1503 06	4	51	24 1213 27	18	84

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
24 1213 54	4	79	24 1510 90	4a	53
24 1213 65	23	29	24 1510 92	7	53
24 1214 13	29	82	24 1510 93	8a	53
24 1214 13	29	83	24 1510 94	3a	53
24 1214 34	14	79	24 1510 95	13a	54
24 1214 56	12	81	24 1510 97	9a	53
24 1214 98	2	79	24 1510 98	10a	53
24 1215 00	1	79	24 1511 07	3	50
24 1216 48	22	31	24 1511 09	1	51
24 1216 52	10	36	24 1511 10	2	51
24 1216 56	16a	79	24 1511 14	4	50
24 1301 05	7	3	24 1511 19	1a	48a
24 1301 05	4	17	24 1511 20	1b	48a
24 1301 11	3	16	24 1511 33	4	48a
24 1301 13	7	16	24 1511 34	5	48a
24 1302 09	7	23	24 1511 36	6	48a
24 1310 02	6	23	24 1511 37	7	48a
24 1310 03	6	23	24 1511 38	8	48a
24 1310 07	3	23	24 1511 36	3	48a
24 1310 08	4	23	24 1511 45	15	41
24 1310 09	8b	16	24 1511 46	17	41
24 1310 32	6	16	24 1511 47	18	41
24 1310 74	11	37a	24 1511 54	16	41
24 1310 75	5	17	24 1511 63	1	50
24 1410 91	9	77	24 1511 64	2	50
24 1504 06	2	55	24 1511 68	14	49a
24 1504 07	3	55	24 1511 69	9	48a
24 1510 59	7	59	24 1511 70	10	48a
24 1510 60	7b	59	24 1511 71	11	49a
24 1510 61	10	41	24 1511 72	12	49a
24 1510 67	12	41	24 1511 73	13	49a
24 1510 68	13	41	24 1511 74	2a	48a
24 1510 69	14	41	24 1511 75	14a	49a
24 1510 79	18	54	24 1511 76	9A	48a
24 1510 87	2	53	24 1511 78	2b	48a

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
24 1511 79	14b	49a	24 1911 05	8	58
24 1511 80	9b	48a	24 2013 33	9	81
24 1511 81	10a	48a	24 2014 16	14	73
24 1511 82	13a	49a	24 2014 20	19	74
24 1609 24	8	24	24 2014 42	20	74
24 1610 03	5	24	24 2311 46	3	66
24 1613 56	3	60	24 2312 45	29	61
24 1614 23	11	79	28 1010 22	10	32
24 1614 24	10	60	28 1010 38	7	14
24 1614 43	21	43	28 1010 57	13	9
24 1614 46	9	60	28 1011 18	19	8
24 1704 25	8	37	28 1011 19	4	8
24 1704 25	8	37a	28 1011 25	15	9
24 1705 07	4	40	28 1011 29	7	9
24 1710 14	2	37	28 1011 67	2	10
24 1710 14	2	37a	29 1210 81	19	29
24 1710 24	11	38	39 2465 20	3	47
24 1710 49	2	40	30 1011 97	8	13
24 1710 66	13	37	30 1510 39	2	17
24 1710 66	13	37a	30 2010 69	19	61
24 1710 75	12	40	30 2010 84	3	68
24 1711 18	10	40	30 2110 05	11	34
24 1810 32	12	43	31 1010 18	6	9
24 1810 33	6	42	31 1010 19	5	9
24 1810 46	7	42	31 1010 20	8	9
24 1810 47	11	43	31 1010 22	4	9
24 1810 47	12	47	31 1011 41	9	12
24 1810 51	12	56	31 1011 73	4	7
24 1810 74	1	58	03 1902 04	9	58
24 1910 19	8	41	33 1410 07	14	36a
24 1910 96	1	58	35 1010 60	15	17
24 1910 98	3	58	35 1610 60	17	69
24 1910 99	12	58	35 1610 60	19	71
24 1911 00	2	58	35 1710 33	19	47
24 1911 01	4	58	35 1710 40	8	44

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
36 2440 04	11	85	39 0201 11	7	77
36 2440 05	2	85	39 0208 11	3	52
36 AA40 16	4	11	39 0213 11	6	14
36 AA40 20	7	10	39 0219 11	7	8
36 AA40 21	7	10	39 0219 11	9	18
36 AF00 01	9	28	39 0219 11	3	21
36 AF00 08	11	28	39 0219 11	3	46
36 AF00 14	21	29	39 0230 11	6	66
36 AF00 15	22	29	39 0239 11	13	76
36 RC00 01	4	28	39 0242 11	16	69
36 RC00 03	7	28	39 0242 11	16	71
39 0012 01	15	69	39 0248 11	9	24
39 0071 04	18	43	39 0251 11	6	24
39 0071 04	10	46	39 0262 12	6	26
39 0078 04	11	63	39 0262 12	5	27
39 0080 04	5	22	39 0262 12	11	73
39 0083 04	11	24	39 0263 12	15	24
39 0119 04	3	37	39 0263 12	15	47
39 0119 04	3	37a	39 0263 12	3	76
39 0119 04	10	66	39 0265 12	12	16
39 0146 08	7	52	39 0265 12	16	54
39 0192 10	6	56	39 0265 12	7	66
39 0197 11	15	18	39 0268 12	17	49
39 0197 11	5	26	39 0269 12	13	38
39 0197 11	4	27	39 0269 12	13	39
39 0197 11	10	73	39 0291 15	20	35
39 0198 11	5	19	39 0291 15	10	59
39 0198 11	14	24	39 0291 15	14	69
39 0198 11	15	56	39 0291 15	4	76
39 0198 11	2	76	39 0292 15	11	23
39 0199 11	6	52	39 0292 15	25	65
39 0200 11	15	54	39 0294 15	13	66
39 0201 11	7	22	39 0295 15	12	36a
39 0201 11	3	24	39 0296 15	2	24
39 0201 11	8	56	39 0296 15	4	44

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.
39 0296 15	10	56
39 0296 15	5	77
39 0303 15	14	38
39 0303 15	12	39
39 0310 15	17	54
39 0312 15	6	22
39 0326 15	11	58
39 0342 17	10	38
39 0407 01	16	64
39 0408 04	6	27
39 0423 04	18	49
39 0426 06	6	18
39 0426 06	1	20
39 0427 06	10	3
39 0428 17	9	39
39 0435 01	9	16
39 0467 15	23	25
39 0467 15	3	40
39 0467 15	6	40
39 0505 04	2	46
39 0508 09	5	1
39 0508 09	5	2
39 0550 11	2	18
39 0557 17	13	10
39 0630 08	4	52
39 0663 01	13	69
39 0682 05	9	1
39 0682 05	9	2
39 0696 01	15	76
39 0697 05	18	35
39 0711 11	13	22
39 0714 11	22	25
39 0732 12	14	76
39 0740 11	18	45
39 0745 01	15	1

Part No.	Figure No.	Page No.
39 0745 01	15	2
39 0747 01	12	3
39 0747 01	7	21
39 0758 01	16	18
39 0758 01	4	70
39 0761 01	7	26
39 0761 01	8	53
39 0761 01	29	65
39 0788 12	12	66
39 0789 12	3	44
39 0793 15	10	13
39 0798 15	3	22
39 0798 15	7	72
39 0804 11	12	18
39 0804 11	36	65
39 0817 15	9	72
39 0817 15	5	75
39 0830 01	18	71
39 0834 15	9	8
39 0834 15	2	21
39 0834 15	16	22
39 0834 15	16	25
39 0855 17	4	32
39 0897 04	14	22
39 0897 04	10	23
39 0897 04	9	27
39 0898 04	24	65
39 0921 01	13	70
39 0939 15	15	44
39 0944 04	18	25
39 0944 04	10	76
39 0963 15	23	65
39 0973 15	10	9
39 0980 04	8	11
39 0999 06	8	32

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.
39 1000 06	3	4
39 1000 06	4	6
39 1000 06	18	8
39 1000 06	11	17
39 1013 21	6	1
39 1013 21	6	2
39 1013 21	7	32
39 1024 01	9	9
39 1033 09	6	12
39 1035 19	3	9
39 1046 19	5	18
39 1053 15	11	7
39 1054 11	2	44
39 1057 11	10	12
39 1062 04	13	4
39 1062 04	3	10
39 1065 04	9	4
39 1075 04	11	3
39 1075 04	10	26
39 1075 04	5	32
39 1079 01	13	24
39 1079 01	14	47
39 11 80 11	10	47
39 1182 15	12	37
39 1182 15	12	37a
39 1197 04	8	18
39 1214 20	11	1
39 1214 20	11	2
39 1224 11	11	54
39 1224 11	11	66
39 1264 21	5	8
39 1283 21	13	8
39 1324 20	3	3
39 1348 01	19	64
39 1377 04	7	56

Part No.	Figure No.	Page No.
39 1379 04	4	56
39 1389 04	13	54
39 1435 20	4	3
39 1435 20	3	17
39 1441 01	9	13
39 1478 17	7	6
39 1508 11	38	65
39 1537 21	7	4
39 1537 21	14	17
39 1543 21	3	6
39 1552 04	10	22
39 1553 04	8	34
39 1562 21	12	44
39 1564 21	12	44
39 1573 11	9	34
39 1575 11	3	32
39 1581 15	28	65
39 1582 11	12	54
39 1585 11	16	17
39 1587 21	1	23
39 1657 21	12	32
39 1672 04	12	34
39 1672 04	22	35
39 1673 04	18	33
39 1674 04	17	8
39 1674 04	10	10
39 1674 04	6	32
39 1680 04	11	36a
39 1680 04	7	46
39 1680 04	12	63
39 1680 04	10	72
39 1681 04	11	75
39 1698 01	15	71
39 1702 07	5	52
39 1716 19	6	3

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
39 1719 05	8	1	39 1927 07	5	7
39 1719 05	8	2	39 1938 15	10	11
39 1719 05	1	3	39 1943 04	35	65
39 1721 04	11	4	39 1946 04	5	66
39 1724 20	12	10	39 1963 04	10	4
39 1727 11	17	5	39 1972 15	17	35
39 1737 19	16	47	39 1972 15	4	66
39 1738 21	15	32	39 2008 11	11	12
39 1744 19	11	13	39 2008 11	9a	15
39 1759 04	10	17	39 2038 04	6	13
39 1765 11	19	43	39 2038 04	13	47
39 1781 01	30	65	39 2040 21	9	10
39 1788 21	15	16	39 2154 20	16	7
39 1791 04	2	19	39 2205 04	3	53
39 1794 06	14	10	39 2208 04	13	75
39 1826 12	8	8	39 2234 04	4	19
39 1826 12	10	18	39 2240 20	3	47
39 1826 12	6	19	39 2295 15	8	30
39 1826 12	4	21	39 2295 15	13	56
39 1826 12	15	22	39 2345 01	25	35
39 1826 12	11	26	39 2383 15	9	73
39 1827 12	21	25	39 2393 04	1	24
39 1827 12	5	40	39 2451 11	19	57
39 1829 12	4	22	39 2464 17	5	47
39 1829 12	4	24	39 2479 15	21	65
39 1829 12	11	47	39 2484 15	7	34
39 1829 12	9	56	39 2484 15	5	46
39 1830 12	20	43	39 2516 04	16	45
39 1830 12	3	56	39 2528 20	2	3
39 1839 11	5	70	39 2534 04	18	47
39 1869 19	6	17	39 2561 20	14	7
39 1870 19	9	3	39 2592 01	18	57
39 1871 05	6	8	39 2697 04	15	34
39 1885 15	8	7	39 2706 04	20	65
39 1917 19	8	3	52 AL01 80	1	52

Part Index

RE 445M
RE 600

Part No.	Figure No.	Page No.	Part No.	Figure No.	Page No.
59 0400 29	12	23	AA 1011 35	6	10
59 0500 01	2	8	AA 1011 37	11	9
59 1500 12	6	77	AA 1011 38	6	7
59 1700 07	7	85	AA 1011 39	7	7
59 2000 12	7	38	AA 1011 42	5	12
59 2000 12	6	39	AA 1011 43	10	1
59 2100 13	5	85	AA 1011 43	10	2
59 2100 15	10	85	AA 1011 45	7	1
59 2100 17	23	84	AA 1011 45	7	2
59 2100 22	11	32	AA 1011 56	12	15
AA 1010 04	14	1	AA 1011 68	7	13
AA 1010 04	14	2	AA 1011 69	1	6
AA 1010 06	2A	12	AA 1011 94	10	24
AA 1010 09	3	12	AA 1012 07	4	12
AA 1010 13	9	6	AA 1012 12	5	20
AA 1010 31	2	7	AA 1012 13	12	12
AA 1010 50	1	15	AA 1012 20	12	26
AA 1010 51	2	15	AA 1012 49	3	1
AA 1010 52	3	15	AA 1012 49	3	2
AA 1010 53	4	15	AA 1012 58	14	18
AA 1010 54	4	14	AA 1012 61	1	18
AA 1010 55	9	15	AA 1012 62	6	21
AA 1010 57	10	16	AA 1012 83	8	22
AA 1010 58	11	16	AA 1012 95	2	14
AA 1010 61	9	14	AA 1013 22	8	21
AA 1010 63	1A	12	AA 1013 37	12	4
AA 1010 73	2	13	AA 1013 45	9	7
AA 1010 77	8	4	AA 1013 64	7	11
AA 1010 84	11	18	AA 1013 84	9	26
AA 1011 08	5	14	AA 1013 92	10	15
AA 1011 16	15	7	AA 1013 96	2	4
AA 1011 23	2	1	AA 1014 00	7	12
AA 1011 23	2	2	AA 1014 01	8	12
AA 1011 24	4	1	AA 1014 24	3	7
AA 1011 24	4	2	AA 1014 68	15	4

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.

RE 445M
RE 600

Part No.	Figure No.	Page No.

Part No.	Figure No.	Page No.